

Manuals.plus /

› CUSIMAX /

› CUSIMAX Hot Plate Electric Double Burner CMHP-B201 Instruction Manual

CUSIMAX CMHP-B201

CUSIMAX Hot Plate Electric Double Burner

MODEL: CMHP-B201

1. Important Safety Information

Please read all instructions carefully before using your CUSIMAX Electric Double Burner. Keep this manual for future reference.

- **Household Use Only:** This appliance is designed for household use only. Do not use it for anything other than its intended purpose.
- **Electrical Safety:** Ensure the appliance is plugged into a properly grounded outlet. Do not immerse the appliance, power cord, or plug in water or any other liquid.
- **Hot Surfaces:** The hot plate and surrounding metal surfaces become extremely hot during and after use. **DO NOT TOUCH HOT SURFACES.** Use oven mitts or pot holders. Allow the unit to cool completely before handling or cleaning.
- **Overheat Protection:** The hot plate features an automatic safety shut-off function with a thermostat. If the temperature becomes too high, the unit will automatically power off. This is a normal safety feature.
- **First Use Smoking:** It is normal and safe for the new burners to emit smoke during the first use. This is due to a protective coating on the heating elements and internal accessories evaporating. To condition the coating, turn the appliance to the highest setting for 3-5 minutes without any cookware. Perform this procedure in a well-ventilated area.
- **Children:** Do not use the appliance within reach of young children. Unattended cooking can be dangerous.
- **Ventilation:** Ensure adequate ventilation around the appliance during operation.
- **Cookware:** The heating plates are compatible with pots and pans up to 7.4 inches in diameter.

2. Product Overview

The CUSIMAX Electric Double Burner is a versatile and portable countertop cooktop designed for efficient cooking. It features two thermostatically controlled cast iron heating plates, offering 900W + 900W power for a total of 1800W.

Product Details of High-quality Hot Plate



Image: Close-up of the CUSIMAX Hot Plate highlighting non-slip rubber feet, high-quality stainless steel body, durable cast iron plates, and temperature control knobs.

Key Features:

- **Dual Heating Plates:** One 7.4-inch and one 6.1-inch cast iron plate.
- **Powerful Performance:** 900W + 900W for a total of 1800W.
- **Temperature Control:** 7 thermostatically controlled heat settings for precise cooking.
- **Universal Cookware Compatibility:** Works with all types of flat-bottom cookware, including aluminum, copper, cast iron, and non-magnetic stainless steel.
- **Safety Features:** Overheat protection, automatic safety shut-off, and non-slip rubber feet.
- **Durable Construction:** Stainless steel body for frequent use and easy cleaning.
- **Portable Design:** Compact and lightweight, ideal for various settings like offices, camping, RVs, or as an extra burner.

3. Setup

1. **Unpack:** Carefully remove the hot plate from its packaging. Retain packaging for storage if desired.
2. **Placement:** Place the hot plate on a stable, flat, heat-resistant surface. Ensure there is adequate space

around the unit for ventilation.

3. **First Use Conditioning (Important):** Before first use, plug in the appliance and turn both temperature control knobs to the highest setting (MAX) for 3-5 minutes without any cookware. This process burns off the protective coating and may produce some smoke or odor. Ensure this is done in a well-ventilated area. After this initial conditioning, the appliance is ready for normal use.
4. **Power Connection:** Plug the power cord into a standard 120V AC electrical outlet.

4. Operating Instructions

The CUSIMAX Hot Plate is simple to operate with individual temperature controls for each burner.

1. **Place Cookware:** Place your desired pot or pan (with a flat bottom) onto the heating plate. Ensure the cookware is centered on the burner.
2. **Turn On:** Rotate the temperature control knob for the desired burner from 'OFF' to your preferred heat setting (1-7, or MAX).
3. **Indicator Light:** The indicator light next to the knob will illuminate when the burner is heating. It may cycle on and off during operation as the thermostat maintains the set temperature.
4. **Adjust Temperature:** Adjust the knob to select one of the 7 heat settings or 'MAX' for higher temperatures.
5. **Cooking:** Begin cooking your food. The cast iron plates provide even and consistent heat distribution.
6. **Turn Off:** Once cooking is complete, turn the temperature control knob back to the 'OFF' position. The indicator light will turn off.
7. **Cool Down:** Allow the hot plate to cool completely before moving or cleaning. This can take approximately 20 minutes.

Your browser does not support the video tag.

Video: Demonstrates the unboxing, setup, and cooking process using the CUSIMAX Electric Double Burner, showing how to plug it in, place cookware, and adjust temperature settings for cooking chicken and corn.

Your browser does not support the video tag.

Video: Provides an overview of the CUSIMAX Double Hot Plate, highlighting its durable cast iron heating plates and adjustable temperature control for various cooking needs, including boiling water.

5. Maintenance and Cleaning

Proper maintenance ensures the longevity and performance of your hot plate.

- **Always Unplug:** Before cleaning, ensure the appliance is unplugged from the power outlet and has cooled down completely.
- **Wipe Clean:** Simply wipe the stainless steel body and cast iron plates with a clean, damp cloth.
- **Avoid Harsh Cleaners:** Do not use harsh abrasives, steel wool pads, or caustic cleansers, as these can scratch or damage the surface of the unit.
- **Do Not Immerse:** Never immerse the appliance in water or any other liquid.
- **Storage:** Store the appliance in a cool, dry place when not in use.

6. Troubleshooting

If you encounter any issues with your CUSIMAX Hot Plate, refer to the following common troubleshooting steps:

- **Appliance Not Turning On:**

- Ensure the power cord is firmly plugged into a working electrical outlet.
- Check that the temperature control knob is turned to an 'ON' or numbered setting, not 'OFF'.

- **Smoking on First Use:** This is normal due to a protective coating. Follow the "First Use Conditioning" steps in the Setup section.

- **Overheating/Automatic Shut-off:** The appliance has built-in overheat protection. If the unit becomes too hot, it will automatically power off. Allow it to cool down before resuming use.

- **Slow Heating:** Ensure the cookware is appropriate for the burner size and has a flat bottom. For faster boiling, cover the pot with a lid.

7. Specifications

Feature	Specification
Model	CMHP-B201
Power	1800W (900W + 900W)
Voltage	120 Volts
Heating Elements	2 (Sealed Cast Iron)
Controls Type	Knob
Material	Stainless Steel
Color	Silver
Product Dimensions	8.9"D x 20.7"W x 2.7"H
Item Weight	9.9 Pounds
UPC	798789582656

8. Warranty and Support

CUSIMAX offers a 30-day hassle-free return policy and an 18-month product promise. All CUSIMAX products are covered by Product Liability Insurance of the United States. For any questions or support, please refer to the contact information provided with your purchase or visit the official CUSIMAX website.