

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Fraser Hill Farm](#) /

› [Fraser Hill Farm 7.5-Ft Slim Mountain Pine Flocked Artificial Christmas Tree with Dual Multicolor & Warm White LED Lights Instruction Manual](#)

Fraser Hill Farm FFMPS075-6SN

Fraser Hill Farm 7.5-Ft Slim Mountain Pine Flocked Artificial Christmas Tree Instruction Manual

Model: FFMPS075-6SN

1. INTRODUCTION

Thank you for choosing the Fraser Hill Farm 7.5-Ft Slim Mountain Pine Flocked Artificial Christmas Tree. This pre-lit tree is designed to bring a festive atmosphere to your home with its realistic snowy foliage and versatile LED lighting. Please read this manual carefully before assembly and operation to ensure safe and optimal use of your product.

2. IMPORTANT SAFETY INFORMATION

- Always unplug the tree from the power outlet before assembly, disassembly, or maintenance.
- This product is intended for indoor use only. Do not use outdoors.
- Keep the tree away from heat sources, open flames, and flammable materials.
- Ensure all light connections are secure before plugging into a power source.
- Do not overload electrical outlets.
- Keep small children and pets away from the tree during assembly and ensure all small parts are out of reach.
- The tree is flame retardant, but it is not fireproof.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Tree Sections (Top, Middle, Bottom)
- Metal Tree Stand
- Foot Pedal Control (for lights)
- Remote Control (for lights)

- Spare Bulbs and Fuses
- Instruction Manual



Image: Components of the tree stand, including the base and securing bolts.

4. SETUP INSTRUCTIONS

Follow these steps for quick and easy assembly:

1. **Assemble the Tree Stand:** Unfold the metal tree stand and ensure it is stable on a flat surface. Insert the provided bolts into the stand and tighten them to secure the base.
2. **Insert the Bottom Section:** Carefully insert the bottom section of the tree into the assembled stand. Tighten the bolts on the stand to hold the tree securely in place.
3. **Connect Middle Section:** Place the middle section of the tree onto the bottom section. Ensure the pole aligns correctly. The pre-wired lights will automatically connect as the sections are joined.
4. **Attach Top Section:** Place the top section of the tree onto the middle section, ensuring proper alignment and connection of the light wiring.
5. **Shape the Branches:** Gently spread out the hinged branches, starting from the bottom section and working your way up. Fluff each branch tip to create a full and natural appearance. This may take 30-45 minutes for optimal fullness.
6. **Connect Power:** Locate the power cord at the base of the tree. Connect the foot pedal control to the power cord, then plug the foot pedal into a standard electrical outlet.



EASY ASSEMBLY



SET UP THE STURDY METAL BASE



CONNECT POLES FROM EACH SECTION



FLUFF FOR ABOUT 30-45 MINUTES TO ACHIEVE FULL LOOK



PLUG IN AND USE FOOT PEDAL CONTROL FOR EASY OPERATION

TOP

MIDDLE

BOTTOM

BASE



Image: Visual guide illustrating the simple assembly process of the tree, showing the base, middle, and top sections.



PRELIT WITH LED LIGHTS

500 DUAL MULTICOLOR AND WARM WHITE LIGHTS

Image: Detail of the hinged metal branches and the EZ Connect light system, highlighting the ease of setup and storage.

Your browser does not support the video tag.

Video: A demonstration of the assembly process for a flocked slim pre-lit Christmas tree, showing how the sections connect and the lights illuminate.

5. OPERATING INSTRUCTIONS

Your Fraser Hill Farm Christmas tree features dual multicolor and warm white LED lights with multiple functions.

5.1 Light Functions

Use the included foot pedal or remote control to cycle through the 8 different light functions:

- Warm White Steady
- Multicolor Steady
- Warm White Flashing
- Multicolor Flashing
- Warm White Slow Fade
- Multicolor Slow Fade


- Warm White & Multicolor Flashing
- Warm White & Multicolor Slow Fade



DURABLE & LOW MAINTENANCE

HIGH-QUALITY PVC NEEDLES ARE FLAME
RETARDANT, NON-ALLERGENIC, & BUILT TO LAST

Image: A detailed view of the tree's branches, showcasing the integrated LED lights and the flocked finish.



EASY SETUP & STORAGE

HINGED METAL BRANCHES AND
FOLDING DESIGN WITH EZ CONNECT LIGHTS

Image: Close-up of the warm white LED lights illuminating the snow-flocked branches.



Image: Close-up of the multicolor LED lights illuminating the snow-flocked branches.

Your browser does not support the video tag.

Video: A demonstration of the various light functions (warm white, multicolor, flashing, fading) available on the pre-lit flocked Christmas tree.

6. MAINTENANCE AND STORAGE

6.1 Cleaning

To clean your tree, gently dust the branches with a soft, dry cloth. Do not use liquid cleaners or solvents, as they may damage the flocked finish or electrical components.

6.2 Bulb Replacement

If a light bulb burns out, replace it with a spare bulb of the same type provided in the package. Ensure the tree is unplugged before replacing any bulbs.

6.3 Storage

When storing your tree, carefully compress the branches and disassemble the tree sections in reverse order of assembly. Store the tree in its original box or a suitable storage bag in a cool, dry place away from direct sunlight and extreme temperatures. This will help preserve the flocked finish and extend the life of

your tree.

7. TROUBLESHOOTING

7.1 Lights Not Working

- Check that all tree sections are properly connected and seated.
- Ensure the power cord and foot pedal are securely plugged into the wall outlet.
- Check for any loose or burnt-out bulbs. Replace any faulty bulbs with spares.
- Verify that the fuse in the power plug is intact. Replace if necessary.

7.2 Tree is Not Full

- Spend additional time fluffing and shaping each individual branch tip. The more time spent on this step, the fuller the tree will appear.
- Ensure branches are evenly distributed and bent to fill any gaps.

8. SPECIFICATIONS

Feature	Detail
Brand	Fraser Hill Farm
Model Number	FFMPS075-6SN
Product Dimensions	42"D x 42"W x 90"H (7.5 ft tall)
Item Weight	36 Pounds
Material	Metal, Polyvinyl Chloride (PVC)
Tree Type	Slim Mountain Pine
Special Features	Flame Resistant, Flocked, Foldable, Prelit
Built-in Light	Yes
Light Color	Dual Multi-Color & Warm White LED
Tip Count	830
Assembly Required	Yes
Recommended Uses	Indoor



Image: Visual comparison of various tree heights, including 6.5 ft, 7.5 ft, and 9 ft options, demonstrating the slim profile.

9. WARRANTY AND SUPPORT

Your Fraser Hill Farm Christmas tree comes with a manufacturer's warranty. Please refer to the warranty information included in your package for details on coverage and how to contact customer support for assistance.

For further inquiries or support, please visit the official Fraser Hill Farm store or contact their customer service directly.

[Visit the Fraser Hill Farm Store](#)