

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Generisch](#) /

› [Generisch Arrow Symbol Sticker User Manual](#)

Generisch 246

Generisch Arrow Symbol Sticker User Manual

Model: 246

1. PRODUCT OVERVIEW

The Generisch Arrow Symbol Stickers are high-quality, machine-cut silhouette decals designed for various applications. Each sticker is precisely cut from a durable film, meaning only the arrow shape itself is the adhesive part, with no transparent background.

These stickers are engineered to be **weather-resistant**, ensuring longevity and performance in diverse conditions. They feature a **strong adhesive strength** for secure attachment, yet can be **removed without leaving residue**, allowing for flexibility in placement and future changes.

This package contains 10 individual arrow symbol stickers, in Black Gloss, each measuring 10 x 5.5 mm.

2. APPLICATION INSTRUCTIONS (SETUP)

Follow these steps for optimal application of your arrow symbol stickers:

- Prepare the Surface:** Ensure the surface where the sticker will be applied is clean, dry, and free of dust, grease, or any other contaminants. A clean surface is crucial for proper adhesion.
- Peel the Backing:** Carefully peel the sticker from its backing paper. Avoid touching the adhesive side with your fingers to maintain its stickiness.
- Position and Apply:** Gently place the sticker onto the desired surface. Once positioned, press down firmly from the center outwards, smoothing out any air bubbles with a soft cloth or a squeegee.
- Final Adhesion:** Allow the adhesive to cure for a few hours, ideally 24 hours, before exposing the sticker to harsh conditions or cleaning.



Image: Example of Generisch Arrow Symbol Stickers applied to a standard light switch, indicating directional control. The image displays the black arrow stickers clearly visible against the white switch plate.

Note: The sticker is a silhouette design; only the colored arrow shape will adhere to the surface. The switch shown in the image is for illustrative purposes only and is not included with the stickers.

3. CARE AND MAINTENANCE

To ensure the longevity and appearance of your Generisch Arrow Symbol Stickers:

- **Cleaning:** Clean the stickers with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the film or adhesive.
- **Durability:** The stickers are weatherproof, designed to withstand outdoor conditions. However, extreme temperatures or prolonged exposure to direct sunlight may affect their lifespan over many years.
- **Removal:** If you need to remove the sticker, gently peel it off from one corner. The film is designed to be removed without leaving residue.

4. TROUBLESHOOTING

- **Bubbles During Application:** If air bubbles appear, gently press them towards the edge of the sticker with your finger or a soft cloth. For stubborn bubbles, a very fine needle can be used to prick a tiny hole, allowing the air to escape, then smooth down.
- **Sticker Not Adhering Properly:** Ensure the surface is completely clean and dry before application. Cold temperatures can affect adhesion; apply in a room temperature environment if possible.
- **Residue After Removal:** While designed for residue-free removal, in rare cases or after very long periods, a minimal residue might remain. This can typically be cleaned with a mild adhesive remover or rubbing alcohol.

5. SPECIFICATIONS

Brand	Generisch
-------	-----------

Model Number	246
Dimensions (per sticker)	10 x 5.5 mm
Quantity	10 pieces
Color	Black Gloss (for this variant)
Material	Durable Film
Special Features	Weatherproof, Silhouette Design, Residue-free Removal
Item Weight	20 g

6. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Generisch Arrow Symbol Stickers, please contact the seller directly through the platform where the purchase was made. Please refer to your purchase details for specific warranty information, if applicable.

We recommend keeping your order number handy when contacting support for faster assistance.