

POPULO PCBL-20

POPULO 20V Cordless Mini Electric Blower Kit

Model: PCBL-20

Brand: POPULO

1. SAFETY INSTRUCTIONS

Always read and understand all safety warnings and instructions before operating this product. Failure to follow the warnings and instructions may result in electric shock, fire, and/or serious injury.

- Keep work area clean and well lit. Cluttered or dark areas invite accidents.
- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust. Power tools create sparks which may ignite the dust or fumes.
- Keep children and bystanders away while operating a power tool. Distractions can cause you to lose control.
- Avoid unintentional starting. Ensure the switch is in the off-position before connecting to battery pack, picking up or carrying the tool.
- Do not overreach. Keep proper footing and balance at all times. This enables better control of the power tool in unexpected situations.
- Dress properly. Do not wear loose clothing or jewelry. Keep your hair and clothing away from moving parts. Loose clothes, jewelry or long hair can be caught in moving parts.
- Use personal protective equipment. Always wear eye protection. Protective equipment such as dust mask, non-skid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.
- Do not use the blower as a vacuum cleaner.
- Do not point the blower nozzle at people or animals.

2. PRODUCT OVERVIEW

The POPULO 20V Cordless Mini Electric Blower Kit is a versatile tool designed for light-duty cleaning and inflation tasks. It features a compact and lightweight design, making it easy to handle and store.

COMPACT & LIGHTWEIGHT DESIGN



3.6LB



20V LI-ION



62 CFM

12.2"



Figure 2.1: The POPULO 20V Cordless Mini Electric Blower, highlighting its compact size (12.2 inches long), lightweight design (3.6 lbs without battery), 20V Li-ion battery compatibility, and 62 CFM airflow.

Key Features:

- **Lightweight & Compact:** Weighs only 3.6 lbs (without battery) for easy handling in restricted areas.
- **Powerful Performance:** Delivers up to 150 mph wind speed and 62 CFM airflow.
- **Cordless Design:** Provides freedom of movement without cable constraints.
- **2-in-1 Functionality:** Functions as both a blower for cleaning and an inflator for air mattresses and other inflatables.
- **Portable Storage:** Includes a compact portable storage bag for convenience.

3. SETUP

Before first use, ensure the battery is fully charged.

3.1 Battery Installation and Charging

1. Insert the 20V Li-ion battery into the battery slot on the blower handle until it clicks securely into place.

2. To charge the battery, remove it from the blower by pressing the release button and sliding it out.
3. Connect the battery to the included charger. Plug the charger into a standard electrical outlet. The indicator light on the charger will show the charging status.
4. Once fully charged, disconnect the charger and re-insert the battery into the blower.

3.2 Nozzle Attachment

1. Align the desired nozzle (blowing or inflation adaptor) with the blower's air outlet.
2. Push the nozzle firmly onto the outlet and twist slightly to ensure a secure fit.

4. OPERATING INSTRUCTIONS

4.1 Blowing Function

The blower is ideal for clearing leaves, dust, wood chips, and pebbles from small areas.



Figure 4.1: Clearing small debris from a gravel path using the blower's focused airflow.



Figure 4.2: The blower effectively removes sawdust and debris from a workbench after woodworking tasks.



Figure 4.3: The blower can be used to quickly ignite charcoal for barbecues.

1. Ensure the battery is installed and the blowing nozzle is securely attached.
2. Hold the blower firmly by the handle.
3. Press the trigger to start the blower. The blower features a variable speed trigger for controlled airflow.
4. Direct the nozzle towards the debris you wish to clear.
5. Release the trigger to stop the blower.

4.2 Inflation Function

The blower can also be used to inflate air mattresses, inflatable boats, and other items using the provided adaptors.

2-IN-1 FUNCTION

Inflation and Blowing



Figure 4.4: Inflating an inflatable boat quickly and efficiently with the blower and appropriate adaptor.

Video 4.1: A demonstration by GJ Trade showing the PCBL-20 small blower's features, including its use for inflation and general blowing tasks. This video highlights the product's versatility and ease of use.

1. Attach the appropriate inflation adaptor to the blower's air outlet.
2. Insert the adaptor into the inflation valve of the item you wish to inflate.
3. Press the trigger to start the blower and inflate the item.
4. Monitor the inflation process to prevent over-inflation.
5. Release the trigger to stop the blower and remove the adaptor.

5. MAINTENANCE

5.1 Cleaning

- Always remove the battery pack before performing any cleaning or maintenance.
- Wipe the exterior of the blower with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Ensure the air intake and exhaust vents are free from debris to maintain optimal performance. Use a soft brush

if necessary.

5.2 Storage

- Store the blower, battery, charger, and accessories in the provided portable storage bag.
- Store in a cool, dry place away from direct sunlight and moisture.
- Keep out of reach of children.

6. TROUBLESHOOTING

If you encounter issues with your POPULO 20V Cordless Mini Electric Blower, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Blower does not start	Battery not charged Battery not properly installed Switch/trigger issue	Charge the battery fully Ensure battery is securely clicked into place Contact customer support if switch/trigger is faulty
Low airflow	Blocked air intake/exhaust Low battery charge	Clear any debris from vents and nozzle Recharge the battery
Battery gets warm during charging	Normal operation Overcharging	Slight warmth is normal. Ensure proper ventilation. Disconnect charger once battery is full.

7. SPECIFICATIONS

- **Brand:** POPULO
- **Model Name:** PCBL-20
- **Power Source:** Battery Powered
- **Voltage:** 20 Volts
- **Form Factor:** Handheld
- **Wind Speed:** 150 Miles per Hour
- **Airflow:** 62 CFM (Cubic Feet per Minute)
- **Noise Level:** 62 Decibels
- **Item Weight:** 3.6 lbs (without battery) / 4 lbs (with battery)
- **Included Components:** Blower, Battery, Charger, Inflating Adaptors, Portable Storage Bag
- **Battery Type:** Lithium Ion

8. WARRANTY AND SUPPORT

POPULO is committed to product quality and customer satisfaction.

- **Warranty Period:** This product comes with a 2-year warranty.
- **Hassle-Free Replacement:** If any issues arise within 6 months of purchase, you may be eligible for a free replacement of parts, batteries, or even the entire blower.
- **Contact Support:** To verify eligibility for replacement or for any other support inquiries, please contact POPULO by email. Refer to your product packaging or the official POPULO website for contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question