

SHA CERLIN 3482

SHA CERLIN 68-Inch Multi-Level Cat Tree Instruction Manual

1. PRODUCT OVERVIEW

The SHA CERLIN 68-Inch Multi-Level Cat Tree is designed to provide a comprehensive activity center for your cats. It features multiple levels for climbing, resting, and playing, catering to their natural instincts.

- **Scratching Posts:** Equipped with natural sisal rope, ideal for scratching and maintaining claw health.
- **Comfortable Lounging:** Soft, plush-covered perches and enclosed condos offer warm and comfortable spots for rest and sleep.
- **Multi-Level Design:** The varied structure allows multiple cats to play simultaneously or provides a diverse environment for a single cat.
- **Stability:** Constructed from high-quality particle board with a plush covering, featuring a strengthened base for stability.



Figure 1: Overview of the SHA CERLIN 68-Inch Multi-Level Cat Tree.

2. PRODUCT COMPONENTS

Before assembly, ensure all components are present and undamaged. The package includes:

- Plush-covered platforms and perches
- Cat condos (enclosed resting areas)
- Hammocks
- Sisal rope scratching posts
- Sisal-covered ramp/scratching board
- Hanging furball toys
- Base plate
- Assembly hardware (screws, wrench)
- Wall anchor strap and hardware

PRODUCT DIMENSIONS




Figure 2: Product dimensions and key components. Note the weight capacity: Hammock: 22 lbs, Other platforms: 33 lbs.



Soft Plush Flannel



Natural Sisal Rope



**Eco-friendly
Particle Board**

PREFERRED MATERIAL

Premium and durable,
you can rest assured

Figure 3: Materials used in the cat tree construction, including soft plush flannel, natural sisal rope, and eco-friendly particle board.

3. SETUP AND ASSEMBLY

Assembly is designed to be straightforward. All pieces are labeled, and a wrench is included for convenience. It is recommended to assemble the unit in its intended location due to its size.

Assembly Steps:

1. Unpack all components and verify against the parts list in your included manual.
2. Follow the step-by-step instructions provided in the separate assembly guide. Ensure all screws are tightened securely.
3. Once assembled, position the cat tree in a stable location.
4. For enhanced stability and safety, use the provided wall anchor strap and hardware to secure the cat tree to a wall. This helps prevent tipping, especially with active cats.



Figure 4: Instructions for attaching the anti-wobbling wall anchor to ensure stability.

4. OPERATING INSTRUCTIONS

The cat tree is designed for indoor use by cats of all life stages. No specific operational steps are required beyond assembly and placement.

Usage Guidelines:

- Place the cat tree in a location where your cat feels comfortable and safe.
- Encourage initial exploration by placing treats or toys on different levels.
- Ensure the wall anchor is properly installed to prevent accidental tipping during vigorous play.

5. MAINTENANCE

Regular maintenance will extend the life of your cat tree and keep it hygienic for your pets.

Cleaning:

- The plush covering can be hand washed only. Do not machine wash or tumble dry.
- Use a vacuum cleaner or a pet fur brush to remove loose fur and debris regularly.
- Spot clean any soiled areas with a mild detergent and damp cloth, then allow to air dry completely.

Inspection:

- Periodically check all screws and connections to ensure they remain tight. Retighten as necessary.
- Inspect sisal scratching posts for wear and tear. While durable, sisal will fray over time with use.
- Check hanging toys for secure attachment and replace if damaged to prevent choking hazards.

6. TROUBLESHOOTING

This section addresses common concerns and solutions.

Stability Issues:

- **Problem:** Cat tree wobbles or feels unstable.
Solution: Ensure all assembly screws are fully tightened. Verify that the wall anchor strap is securely attached to both the cat tree and the wall. Place the tree on a flat, even surface.

Damaged Components:

- **Problem:** Hanging toys detach or break.
Solution: These are designed to be replaceable. You can reattach them if possible or replace them with other cat-safe toys.
- **Problem:** Sisal scratching board/posts show excessive wear.
Solution: This is normal with use. If the damage compromises the structure or creates sharp edges, consider replacing the affected part if available, or reinforce it.

7. SPECIFICATIONS

Feature	Detail
Brand	SHA CERLIN
Model Number	3482
UPC	749655409669
Product Dimensions (L x W x H)	37.8" x 30" x 68"
Item Weight	65 Pounds
Material	Engineered Wood, Flannel, Sisal
Number of Levels	7
Hammock Weight Capacity	22 lbs

Other Platform Weight Capacity	33 lbs
Color	Beige
Recommended Use	Indoor
Target Species	Cat (All Life Stages)

8. WARRANTY AND SUPPORT

This product comes with a manufacturer's warranty. For specific details regarding the warranty period and coverage, please refer to the documentation included with your purchase or contact SHA CERLIN customer support.

For returns or further assistance, please contact the retailer where the product was purchased. Amazon offers a 30-day easy return policy for eligible items.