oneisall K2S, K33S, K52NTS

oneisall Dog Clipper Guide Combs User Manual

Models: K2S, K33S, K52NTS Compatible

Introduction

Thank you for choosing oneisall Dog Clipper Guide Combs. These combs are designed to provide precise and consistent grooming lengths for your pet, ensuring a smooth and professional finish. This manual provides essential information on the product, its proper use, maintenance, and troubleshooting.

Product Overview

The oneisall Dog Clipper Guide Combs set includes eight different lengths, allowing for versatile grooming options. Each comb is color-coded and clearly marked with both imperial (inches) and metric (millimeters) measurements for easy identification.



This image displays the complete set of eight oneisall dog clipper guide combs. Each comb is color-coded and labeled with both imperial (inches) and metric (millimeters) measurements, ranging from 1/8 inch (3mm) to 1 inch (25mm). The combs are designed to attach to compatible oneisall clippers for precise grooming.

Comb Sizes and Colors:

- **No. 1:** 1/8 inch (3 mm) - Yellow
- **No. 2:** 1/4 inch (6 mm) - Green
- **No. 3:** 3/8 inch (10 mm) - Blue
- **No. 4:** 1/2 inch (13 mm) - Purple
- **No. 5:** 5/8 inch (16 mm) - Light Purple
- **No. 6:** 3/4 inch (19 mm) - Light Blue

- **No. 7:** 7/8 inch (22 mm) - Lime Green
- **No. 8:** 1 inch (25 mm) - Darker Lime Green

Compatibility

These guide combs are specifically designed to be compatible with the following oneisall dog clipper models:

- oneisall K2S
- oneisall K33S
- oneisall K52NTS

Please ensure your clipper model is listed above for proper fit and function.

Setup

Follow these steps to properly attach a guide comb to your oneisall clipper:

1. **Select Comb:** Choose the desired guide comb based on the hair length you wish to achieve. Refer to the comb sizes listed in the Product Overview section.
2. **Align:** With the clipper turned off, align the guide comb with the clipper blade. The comb should slide smoothly over the blade.
3. **Attach:** Gently push the comb down until you hear a distinct click, indicating it is securely locked into place. Ensure both sides of the comb are fully engaged.
4. **Verify:** Lightly tug on the comb to confirm it is firmly attached and will not detach during use.

Operating Instructions

For best grooming results, follow these operating guidelines:

1. **Prepare Pet:** Ensure your pet's fur is clean, dry, and free of tangles or mats before grooming. This prevents snagging and ensures an even cut.
2. **Select Comb:** Attach the appropriate guide comb as described in the Setup section.
3. **Begin Grooming:** Turn on your oneisall clipper. Hold the clipper with the comb flat against the pet's fur, moving it in the direction of hair growth.
4. **Maintain Consistency:** Use consistent pressure and maintain an even angle to achieve a uniform cut. Avoid pressing too hard, as this can cause uneven results or discomfort to your pet.
5. **Clean During Use:** Periodically remove accumulated hair from the comb during grooming to maintain optimal performance.

Maintenance

Proper maintenance will extend the life of your guide combs and ensure hygienic use:

1. **Remove Comb:** After each grooming session, turn off the clipper and carefully remove the guide comb by pressing the 'RELEASE' tab (if present) or gently pulling it off.
2. **Rinse:** Rinse the guide comb under cool running water to remove all hair and debris.
3. **Dry:** Thoroughly dry the comb with a clean cloth or allow it to air dry completely before storage. Do not store wet combs.

4. **Store:** Store the combs in a clean, dry place, preferably in their original packaging or a dedicated storage case, to prevent damage.

Troubleshooting

Issue	Possible Cause	Solution
Comb not attaching securely.	Improper alignment; debris obstructing attachment points.	Ensure comb is correctly aligned with clipper blade. Check for and remove any hair or debris from the attachment points on both the comb and clipper.
Uneven cut.	Comb not fully attached; fur not properly prepared (tangled/matted); inconsistent grooming angle.	Verify the comb is securely clicked into place. Ensure pet's fur is clean, dry, and detangled. Maintain a consistent angle and pressure during grooming.
Comb appears damaged or broken.	Excessive force during attachment/removal; accidental drop.	Handle combs with care. Avoid dropping them or applying excessive force. If a comb is damaged, replace it to ensure safe and effective grooming.

Specifications

- **Brand:** oneisall
- **Material:** Durable Plastic, Nylon
- **Number of Combs:** 8 (one set)
- **Comb Lengths:** 1/8" (3mm) to 1" (25mm)
- **Color:** Multicolored
- **Package Dimensions:** Approximately 13.8 x 11.5 x 5 cm
- **Package Weight:** Approximately 60 grams

Warranty and Support

oneisall products are manufactured to high-quality standards. For specific warranty information and terms, please refer to the product packaging or the official oneisall website. In case of any issues or questions regarding your guide combs, please contact oneisall customer support through the retailer's platform or the official brand website.
This product is subject to a 30-day refund/replacement policy from the date of purchase, as per standard retail terms.

© 2024 oneisall. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question