

Manuals.plus /

> [AIPER](#) /

> AIPER Cordless Robotic Pool Cleaner User Manual

AIPER Seagull 600

AIPER Cordless Robotic Pool Cleaner User Manual

Model: Seagull 600
Brand: AIPER

INTRODUCTION

The AIPER Cordless Robotic Pool Cleaner is designed to provide a hassle-free, smart, and simple solution for maintaining the cleanliness of your pool. This lightweight device features dual-drive motors for powerful suction and self-parking technology for convenient retrieval. It is ideal for above-ground and in-ground flat pools up to 40 feet. This manual provides essential information on the setup, operation, maintenance, and troubleshooting of your new pool cleaner to ensure optimal performance and longevity.

PRODUCT OVERVIEW



Figure 1: AIPER Cordless Robotic Pool Cleaner (Seagull 600)

This image shows the top view of the AIPER Seagull 600 robotic pool cleaner, highlighting its compact and ergonomic design with a central handle.

Key Features:

- **Cordless Design:** Offers freedom of movement without tangled cables.
- **Dual-Drive Motors:** Provides strong suction power and efficient movement at 52.5 ft/min.
- **Self-Parking Technology:** Automatically stops near the pool wall when battery is low or cleaning cycle is complete for easy retrieval.
- **Lightweight:** Weighs only 6.6 lbs, making it easy to handle and operate.
- **Fine Debris Collection:** Effectively picks up fine leaves, sand, dirt, and other debris.
- **Long Battery Life:** Lasts up to 90 minutes on a single charge.

SETUP

1. Installing the Bottom Brushes

The robotic pool cleaner comes with two bottom brushes that need to be installed before first use. Follow these steps:

1. Locate the align buckle positions on the underside of the cleaner.
2. Align the brush with the designated slots.
3. Press down firmly until you hear a distinct clicking sound, indicating it's locked into place.
4. Repeat for the second brush.

Your browser does not support the video tag.

Video 1: How to install the bottom brush on Seagull SE

This video demonstrates the step-by-step process of installing the bottom brushes onto the AIPER robotic pool cleaner, ensuring they are securely fastened.

2. Charging the Unit

Before initial use, fully charge the pool cleaner. The unit takes approximately 2.5 hours to fully charge.

Improved Charging

To minimize your wait



Figure 2: Improved Charging

The image illustrates the charging process of the AIPEr pool cleaner, highlighting its fast 2.5-hour charging time.

OPERATING INSTRUCTIONS

1. Activating the Cleaner

To begin cleaning, simply power the unit on and drop it into the pool. The cleaner will automatically start its cleaning cycle.

One-Click Activation



Figure 3: One-Click Activation

This image shows a hand pressing the power button on the AIPER pool cleaner, demonstrating its simple one-click activation.

2. Cleaning Performance

The dual motors provide powerful suction to pick up fine leaves, sand, dirt, and other debris. Two independent scrapers also work to scrub the bottom of your pool, removing grime and sediment.

Powerful Performance

Picks up dirt and debris with ease



Figure 4: Powerful Performance

The image depicts the AIPER pool cleaner actively cleaning the bottom of a pool, surrounded by leaves and debris, showcasing its powerful performance.

3. Self-Parking Technology

The Aiper Robotic Cleaner is equipped with self-parking smart technology. When the battery is too low or after completing a cleaning cycle, it will stop near the pool wall. This allows for easy and convenient retrieval using the included hook.

Self-Parking Technology




Figure 5: Self-Parking Technology

This image illustrates the self-parking feature of the AIPER pool cleaner, showing it automatically moving towards the pool edge for easy retrieval.

Your browser does not support the video tag.

Video 2: How to Use Robot Pool Vacuum Cleaner

This video provides a general overview of how to operate the robotic pool vacuum cleaner, including its movement and cleaning patterns in a pool.

MAINTENANCE

1. Cleaning the Filter

After each use, remove the cover and rinse the filter with a hose to clean it. This ensures optimal suction and performance for future uses.

Your browser does not support the video tag.

Video 3: How to disassemble the bottom brush of Seagull SE

This video demonstrates the process of disassembling the bottom brushes for cleaning, showing how to unbuckle and remove them from the unit.

Your browser does not support the video tag.

Video 4: Amazing Vacuum, Moves Really Fast and picks up everything

This video showcases the vacuum's efficiency in picking up debris and its fast movement across the pool floor, demonstrating its cleaning capabilities.

TROUBLESHOOTING

If your AIPER Robotic Pool Cleaner is not functioning as expected, please refer to the following common issues and solutions:

- **Unit not turning on:** Ensure the unit is fully charged. Check the power button for proper activation.
- **Reduced suction power:** Clean the filter basket thoroughly. Ensure there are no obstructions in the suction inlets.
- **Unit not moving:** Check for debris caught in the wheels or brushes. Ensure the battery is not depleted.
- **Unit not self-parking:** Verify the pool cleaner is operating in an open area without excessive obstacles.

For further assistance, please contact AIPER customer service.

SPECIFICATIONS

Feature	Detail
Power Source	Battery Powered
Item Weight	6.6 Pounds
Product Dimensions	24.8 x 18.9 x 14.96 inches
Battery Life	Up to 90 Mins
Charging Time	2.5 Hours
Pool Size Capacity	Up to 40 Feet (Flat Pools)
Model Name	Seagull SE
Color	White

WARRANTY AND SUPPORT

The AIPER Cordless Robotic Pool Cleaner comes with a 1-year warranty. For any warranty claims, technical support, or customer service inquiries, please contact AIPER directly.

Visit the [AIPER Store](#) for more information and product registration.

© 2025 AIPER. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09HZ5K5Y2>

More documents and user manuals: <https://manuals.plus/>