

## HOUSNAT RH-906

# HOUSNAT 5.5L 800W Popcorn Machine User Manual

Model: RH-906

## INTRODUCTION

---

Thank you for choosing the HOUSNAT 5.5L 800W Popcorn Machine. This appliance is designed to provide a quick and easy way to make delicious popcorn at home. Please read this manual thoroughly before first use to ensure safe and optimal operation. Keep this manual for future reference.

## IMPORTANT SAFETY INSTRUCTIONS

---

**WARNING: To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions.**

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical hazards, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer service for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.

- Do not use appliance for other than intended use.
- **Allow the appliance to cool completely before popping a second batch. Avoid prolonged continuous use.**
- **When the popcorn machine is operating, remove the black top cover for proper ventilation. This design prevents steam or condensation in the transparent lid and keeps the popcorn crispy.**
- The cool-touch handle design helps prevent burns when flipping the ejection plate.

## PRODUCT COMPONENTS

---

The HOUSNAT Popcorn Machine consists of the following main parts:

- Main Base Unit with Heating Plate and Electric Stirrer
- Transparent Lid (doubles as a serving bowl)
- Black Top Cover (for ventilation during operation)
- Measuring Cups (for oil/butter and corn kernels)

# FONCTIONNEMENT À UN SEUL BOUTON



**1** Ajouter l'huile ou le beurre, 180 g de grains de maïs dans la plaque à éclater



**2** Mettez le couvercle transparent, appuyez sur l'interrupteur "I"



**3** Veuillez éteindre l'alimentation immédiatement après avoir sauté, couvrez le capuchon noir du couvercle



**4** Tenez la plaque amovible et faites-la pivoter de 180 degrés immédiatement

Image: The HOUSNAT Popcorn Machine showing its main components: the red base with the heating plate and stirrer, and the clear lid.

# 5.5L Grande capacité

Capacité beaucoup plus grande  
que la machine à pop-corn à air chaud



Image: The popcorn machine demonstrating its 5.5L capacity, filled with freshly popped corn.

## SETUP

1. Unpack all components and remove any packaging materials.
2. Wipe the non-stick heating plate and the transparent lid with a damp cloth before first use. Ensure all parts are dry.
3. Place the main base unit on a stable, heat-resistant, and dry surface.
4. Ensure the power cord is not tangled and is placed away from hot surfaces.

## OPERATION

---

Follow these steps to make delicious popcorn:



Image: Visual guide for popcorn machine operation, showing the process from adding ingredients to serving.

1. **Prepare Ingredients:** Add the desired amount of oil or butter (as per your preference) and 180g of corn kernels to the non-stick heating plate. Use the provided measuring cups for accuracy.
2. **Assemble:** Place the transparent lid onto the base unit. Ensure the black top cover is removed for ventilation during popping.
3. **Start Popping:** Plug the appliance into a 220V AC power outlet. Press the 'I' switch to turn on the machine. The electric stirrer will begin to rotate, ensuring even heating of the corn kernels.
4. **Monitor:** Popcorn will start popping within approximately 4 minutes. The machine operates quietly.
5. **Finish Popping:** Once popping slows down significantly or stops, immediately turn off the power switch.
6. **Serve:** Carefully hold the removable plate (using the cool-touch handles) and pivot it 180 degrees. The transparent lid will now act as a serving bowl. You can then place the black top cover back on the lid if desired.
7. **Flavoring:** You can add spices, salt, butter, sauce, or sugar directly to the popcorn in the serving bowl.

**Important: Do not operate the machine continuously for prolonged periods. Allow the appliance to cool completely before preparing a second batch of popcorn.**

## CLEANING AND MAINTENANCE

---

Regular cleaning ensures the longevity and optimal performance of your popcorn machine.



Faire Demi-Tour



Servir

N'utilisez Pas L'appareil En Continu Pendant Une Longue Période.

Image: Cleaning the non-stick heating plate with a damp cloth.

- **Always unplug the appliance and allow it to cool completely before cleaning.**
- **Heating Plate:** The non-stick heating plate is easy to clean. Simply wipe it with a damp cloth. Do not immerse the base unit in water.
- **Transparent Lid:** The large transparent lid can be washed by hand with warm, soapy water or placed in a dishwasher. Ensure it is completely dry before storing.
- **Exterior:** Wipe the exterior of the base unit with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
- **Storage:** Ensure all parts are clean and dry before storing the appliance.

## STORAGE

The HOUSNAT Popcorn Machine is designed for convenient storage.



Image: The popcorn machine stored compactly with the lid inverted over the base unit.

- After cleaning and ensuring all parts are dry, the transparent lid can be inverted and placed over the base unit for compact storage.
- Store the appliance in a cool, dry place, away from direct sunlight and moisture.

## TROUBLESHOOTING

If you encounter any issues with your HOUSNAT Popcorn Machine, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Machine does not turn on.	Not plugged in; power switch off; power outage.	Ensure the machine is properly plugged into a working outlet. Check the power switch. Verify power supply.
Popcorn does not pop or pops poorly.	Old or dry corn kernels; insufficient oil/butter; too many kernels; black top cover not removed.	Use fresh, high-quality popcorn kernels. Ensure correct amount of oil/butter. Do not overfill (max 180g kernels). <b>Ensure the black top cover is removed during operation for ventilation.</b>
Popcorn burns.	Too much oil/butter; machine used continuously without cooling; stirrer not functioning.	Use recommended amounts of oil/butter. Allow the machine to cool completely between batches. Check if the stirrer is rotating.
Lid/bowl feels hot.	Normal during operation.	Use the cool-touch handles when handling the lid/bowl after popping. Always allow the machine to cool before cleaning.

If the problem persists after trying these solutions, please contact HOUSNAT customer support.

## SPECIFICATIONS

Feature	Detail
Brand	HOUSNAT
Model Number	RH-906
Color	Retro Red
Product Dimensions (L x W x H)	30 x 30 x 18 cm
Item Weight	2.23 kg
Capacity	5.5 Liters
Power	800 Watts
Voltage	220 Volts (AC)
Material	Non-stick plate
Automatic Shut-off	No
Noise Level	55 Decibels
Operating Time (per batch)	Approx. 4 minutes
Special Features	Quiet operation, non-stick and removable cooking plate, electric heating element with stirrer

Feature	Detail
UPC	699838314801

## WARRANTY AND SUPPORT

---

HOUSNAT products are manufactured to high-quality standards. For warranty information or technical support, please refer to the documentation included with your purchase or contact HOUSNAT customer service through the retailer where the product was purchased.

Please retain your proof of purchase for any warranty claims.