

[Manuals.plus](#) /

› [Wiltec](#) /

› XPOtool High Pressure Paint Sprayer System User Manual

Wiltec 63003

XPOtool High Pressure Paint Sprayer System User Manual

Model: 63003 | Brand: Wiltec

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your XPOtool High Pressure Paint Sprayer System. Please read this manual thoroughly before operating the device to ensure proper usage and to prevent damage or injury.

The XPOtool high pressure paint spraying system is designed for applying paint to large surfaces and for regular painting tasks. Its powerful 1010 watt motor enables a spray pressure of 207 bar and a flow rate of 1.5 liters per minute, facilitating even paint application on various surfaces. This system offers an efficient alternative to traditional brushes and rollers, saving time and delivering consistent results for both beginners and professionals.

Typical applications include initial painting, renovation, and repair of ceilings and interior walls. The compact design, low weight, and integrated carry handle enhance portability. A U-shaped stand provides stability during operation. The system includes a 10-meter spray hose, a 515 nozzle (0.38 mm), and a 45 cm nozzle extension rod for reaching high walls or spraying floors comfortably.

2. SAFETY WARNINGS

WARNING: Failure to follow these safety instructions could result in serious injury or property damage.

- Keep the product away from children.
- Protect your skin and eyes when handling the paint sprayer. Always wear appropriate personal protective equipment (PPE), including safety glasses, gloves, and a respirator.
- Avoid direct contact with liquids under pressure. High-pressure spray can cause severe injury.
- Ensure the work area is well-ventilated to prevent the accumulation of hazardous fumes.
- Always disconnect the power supply before performing any maintenance, cleaning, or when the unit is not in use.
- Do not operate the sprayer with flammable liquids or in explosive atmospheres.
- Check all hoses and connections for damage before each use. Replace damaged parts immediately.
- Never point the spray gun at people or animals.

3. PRODUCT OVERVIEW

The XPOtool High Pressure Paint Sprayer System is designed for efficient and uniform paint application. Below is an overview of the main unit and its components.



Figure 3.1: Complete XPOtool High Pressure Paint Sprayer System. This image displays the main sprayer unit, the high-pressure spray gun, the 10-meter spray hose, and the extension rod, illustrating all primary components included with the system.

Key features include:

- Powerful 1010 Watt Motor
- Maximum Spray Pressure: 207 bar
- Flow Rate: 1.5 liters per minute
- Compact and Portable Design with Carry Handle
- U-shaped Stand for Stability
- Includes 10m Spray Hose, 515 Nozzle (0.38 mm), and 45cm Extension Rod

Airless färgspruta



1010 W



207 bar



1.5 l/m



U-ram




Figure 3.2: Airless Paint Sprayer Key Specifications. This diagram highlights the core technical specifications of the sprayer, including its 1010W power, 207 bar pressure, 1.5 l/min flow rate, and the stable U-frame design, with an illustration of the motor's internal workings.

Smart design



Figure 3.3: Smart Design Features. This image details the practical design elements of the sprayer, such as the durable rubber hose, the ergonomic carry handle for easy transport, and the removable pump unit for simplified maintenance and cleaning.

4. SETUP

Proper setup is crucial for safe and effective operation. Follow these steps to prepare your paint sprayer system.

1. **Unpacking:** Carefully remove all components from the packaging. Verify that all included items are present: main sprayer unit, spray gun, 10m spray hose, 515 nozzle (0.38 mm), and 45cm extension rod.
2. **Placement:** Position the main sprayer unit on a stable, level surface. The U-shaped stand provides necessary stability. Ensure adequate ventilation in the work area.
3. **Hose Connection:** Connect one end of the 10-meter spray hose to the high-pressure outlet on the main unit and the other end to the spray gun. Ensure all connections are tight and secure to prevent leaks.
4. **Nozzle Installation:** Attach the 515 nozzle to the spray gun. If using the extension rod, connect it between the spray gun and the nozzle.

5. **Paint Preparation:** Prepare your paint according to the manufacturer's instructions. Ensure the paint is properly mixed and filtered to prevent clogging the nozzle. Place the paint suction tube into the paint container.
6. **Power Connection:** Connect the power cord to a grounded electrical outlet. Ensure the power switch on the unit is in the "OFF" position before connecting.

5. OPERATING INSTRUCTIONS

Once the system is set up, follow these steps for operation.

1. Priming the Pump:

- Ensure the pressure control knob is set to the lowest setting.
- Turn the power switch to "ON".
- Allow the pump to draw paint until it flows smoothly from the spray gun (without the nozzle attached). This purges air from the system.
- Once paint flows consistently, turn the unit "OFF" and attach the nozzle.

2. Adjusting Pressure:

Gradually increase the pressure using the control knob until the desired spray pattern is achieved. Test on a scrap surface first.

3. Spraying Technique:

- Maintain a consistent distance (typically 25-30 cm) from the surface.
- Move the spray gun in smooth, even strokes, overlapping each pass by approximately 50%.
- Release the trigger at the end of each stroke to avoid paint buildup.
- For best results, apply multiple thin coats rather than one thick coat.




Figure 5.1: Operating the Paint Sprayer on an Exterior Surface. This image shows an individual wearing protective gear, demonstrating the use of the XPOtool paint sprayer to apply paint to an exterior corrugated metal wall, highlighting its suitability for large outdoor projects.


Kraftfull teknik för perfekta resultat




Väggar



Staket



Möbler



Garage

Figure 5.2: Versatile Applications of the Paint Sprayer. This collage illustrates various surfaces that can be painted with the system, including interior walls, outdoor fences, furniture, and garage doors, showcasing its adaptability for diverse painting tasks.

För både professionellt bruk och DIY-projekt

Redo för omedelbar användning



Figure 5.3: Ready for Professional and DIY Use. This image depicts a person using the paint sprayer in a home renovation setting, emphasizing its ease of use and suitability for both professional contractors and do-it-yourself enthusiasts.

6. MAINTENANCE

Regular cleaning and maintenance will extend the life of your paint sprayer and ensure optimal performance.

1. Immediate Cleaning After Use:

- Disconnect power.
- Remove the nozzle and clean it thoroughly with appropriate solvent or water, depending on the paint type.
- Flush the system: Place the suction tube into a container of clean water or appropriate cleaning solution. Turn the unit on and spray until the liquid runs clear.
- Clean the exterior of the unit and spray gun with a damp cloth.

2. Filter Cleaning: Regularly check and clean the filters in the spray gun and suction tube. Clogged filters can affect spray quality and pressure.

3. **Storage:** Store the paint sprayer in a clean, dry place, protected from freezing temperatures. Ensure all components are thoroughly cleaned and dry before storage.
4. **Pump Lubrication:** Refer to the manufacturer's recommendations for pump lubrication, if applicable.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your paint sprayer.

Problem	Possible Cause	Solution
No spray or low pressure	Clogged nozzle or filter, air in system, insufficient paint, damaged hose.	Clean nozzle/filters. Re-prime the pump. Ensure paint container has enough paint. Check hose for damage and replace if necessary.
Uneven spray pattern	Partially clogged nozzle, incorrect pressure setting, improper spraying technique.	Clean nozzle. Adjust pressure. Review spraying technique (consistent distance and speed).
Paint leaks	Loose connections, damaged seals or O-rings, cracked hose.	Tighten all connections. Inspect and replace damaged seals/O-rings. Replace damaged hose.
Motor runs but no paint flow	Suction tube not submerged in paint, clogged suction filter, air in system.	Ensure suction tube is fully in paint. Clean suction filter. Re-prime the pump.

8. SPECIFICATIONS

Detailed technical specifications for the XPOtool High Pressure Paint Sprayer System.

- **Model Number:** 63003
- **Power Source:** Corded Electric
- **Motor Power:** 1010 Watts
- **Max. Spray Pressure:** 207 bar
- **Flow Rate:** 1.5 liters/minute
- **Product Dimensions (L x W x H):**21.5 x 21.5 x 37 cm
- **Item Weight:** 8 kg
- **Material:** Plastic
- **Color:** Orange, Black
- **Included Components:** Spray hose (10m), Nozzle (515 / 0.38 mm), Extension Rod (45cm)

Produkts dimensioner



Figure 8.1: Product Dimensions. This image provides a detailed dimensional breakdown of the main sprayer unit (350mm x 215mm x 370mm), the 10-meter hose (1000mm length), and the extension rod (490mm length), aiding in understanding the physical size of the components.

Lättvikt och bärbar

Lätt att transportera för en person

8 KG

Vikt



Figure 8.2: Lightweight and Portable Design. This image illustrates the portability of the 8 kg paint sprayer, showing a hand easily carrying the unit, emphasizing its design for single-person transport and convenience.

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact the manufacturer or your point of purchase. Keep your purchase receipt as proof of purchase.

Manufacturer: WilTec Wildanger Technik GmbH

Model Number: 63003

ASIN: B09J1J1P8L

For further assistance, please refer to the official Wiltec website or contact their customer service department.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09J1J1P8L>

More documents and user manuals: <https://manuals.plus/>