

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [PPLEE](#) /

› [PPLEE CR1018 Digital LED Mirror Alarm Clock User Manual](#)

PPLEE CR1018

PPLEE CR1018 Digital LED Mirror Alarm Clock User Manual

Model: CR1018 | Brand: PPLEE

INTRODUCTION

Thank you for choosing the PPLEE CR1018 Digital LED Mirror Alarm Clock. This manual provides essential information for the proper setup, operation, and maintenance of your new alarm clock. Please read it thoroughly before use and retain it for future reference.

PACKAGE CONTENTS

Ensure all items are present in the package:

- PPLEE CR1018 Digital LED Mirror Alarm Clock
- Power Adapter
- CR2032 Coin Cell Battery (pre-installed for backup)
- User Manual

PRODUCT OVERVIEW

Familiarize yourself with the alarm clock's components and controls.

Easy to Read

8.7" LED Display/Big Digit/Unique Mirror Screen



Figure 1: Front view of the alarm clock with its large 8.7-inch LED mirror display.



Figure 2: Top view showing control buttons for Dimmer, Hour, Minute, Time 12H/24H, Snooze, Alarm 1, Alarm 2, Volume/DST, and Alarm Off.

AC Powered & Memory Function



AC adapter (include)
To support time display and other function



CR 2032 backup battery (include)
To backup time/alarm setting during power outage

Figure 3: Rear view with DC IN 5V port, two 5V 1A USB charging ports, and the CR2032 battery compartment.

SETUP

1. **Power Connection:** Connect the provided power adapter to the DC IN 5V port on the back of the alarm clock and plug it into a standard wall outlet. The display will light up.

2. **Battery Backup:** A CR2032 coin cell battery is pre-installed. This battery serves as a backup to retain time and alarm settings during a power outage. The display will go blank and alarms will not sound during battery backup mode. Ensure the plastic pull tab is removed from the battery compartment if present.

OPERATING INSTRUCTIONS

Setting the Time

1. Press and hold the "SET TIME" button until the hour digits begin to flash.
2. Use the "HOUR" and "MINUTE" buttons to adjust the time.
3. Press "SET TIME" again to confirm and exit time setting mode.

Setting Alarms (Dual Alarms)

The clock supports two independent alarms (ALARM 1 and ALARM 2).

1. Press and hold the "ALARM 1" button until the hour digits for Alarm 1 begin to flash.
2. Use the "HOUR" and "MINUTE" buttons to set the desired alarm time.
3. Press "ALARM 1" again to confirm and activate Alarm 1. A small alarm icon will appear on the display.
4. Repeat steps 1-3 for "ALARM 2" if a second alarm is desired.

Dual Alarms Clock

Set different alarm according your habits

SNOOZE

Get extra
9 mins sleep



🕒 6:00 🕒 7:00



Figure 4: Dual alarm functionality allows setting two separate wake-up times.

Snooze Function

When an alarm sounds, press the large "SNOOZE" button to temporarily silence the alarm for 9 minutes. The alarm will sound again after 9 minutes. To turn off the snooze mode, press the "ALARM OFF" button.

Adjusting Brightness (Dimmer)

The display brightness can be adjusted to 8 levels. Press the "DIMMER" button repeatedly to cycle through the brightness levels. If you want a dark mode, switch the clock dimmer to "OFF", and the red indicator on top will stay on.

Adjusting Volume

The alarm volume can be adjusted from 90-110 dB, with 7 levels. Press the "VOLUME" button repeatedly to cycle through the volume levels.

7 Level Volume & 8 Level Brightness Adjustable



92db -----110db



Figure 5: Visual representation of adjustable brightness and volume levels.

12/24H Mode & DST Function

Press the "12/24H" button to switch between 12-hour and 24-hour time formats. Press the "DST" button to activate or deactivate Daylight Saving Time (DST) mode.



Figure 6: Switching between 12-hour, 24-hour, and DST display modes.

USB Charging Ports

The alarm clock is equipped with two 5V 1A USB charging ports on the back. You can use these ports to charge your mobile phone or other USB-powered devices.

Dual USB Charging Ports & 12/24H Time Format



Figure 7: Utilizing the dual USB charging ports for convenience.

MAINTENANCE

- **Cleaning:** Wipe the mirror display and body with a soft, dry cloth. Avoid abrasive cleaners or solvents.
- **Battery Replacement:** If the backup battery needs replacement, open the battery compartment on the back,

remove the old CR2032 battery, and insert a new one with the correct polarity.

- **Storage:** If storing the alarm clock for an extended period, disconnect it from power and remove the backup battery.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Display is blank	No power or power outage.	Ensure the power adapter is securely connected and plugged into a working outlet. If there's a power outage, the backup battery will maintain settings but the display will be off.
Alarm does not sound	Alarm is not activated or volume is too low.	Check if the alarm icon is displayed. If not, set the alarm again. Adjust the volume using the "VOLUME" button.
Time is incorrect	Time not set correctly or backup battery is depleted.	Reset the time using the "SET TIME" button. Replace the CR2032 backup battery if necessary.

SPECIFICATIONS

Feature	Detail
Model Number	CR1018
Display Type	Digital LED Mirror
Display Size	8.7 inches
Product Dimensions	7.79"W x 4.02"H
Power Source	AC Powered (Adapter included)
Battery Backup	1 x CR2032 (included)
USB Charging Ports	2 x 5V 1A
Brightness Levels	8 levels
Volume Levels	7 levels (90-110 dB)
Time Format	12H/24H
Special Features	Dual Alarms, Snooze, DST Function

OFFICIAL PRODUCT VIDEO

Video: Overview of the PPLEE Dual Digital Alarm Clock, highlighting its large number display, backup battery, and USB charger port. This video demonstrates key features and functionality.

WARRANTY AND SUPPORT

PPLEE provides a 1-year warranty, 90-day money-back guarantee, and 24-hour response service. If you have any questions or require support regarding your product, please contact us via Amazon. We are committed to providing prompt assistance.