Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Redragon M601WL-BA

REDRAGON M601-WL-BA RF Wireless Optical Mouse User Manual

Model: M601WL-BA

INTRODUCTION

This manual provides instructions for the setup, operation, and maintenance of your Redragon M601-WL-BA RF Wireless Optical Mouse. Please read this manual thoroughly before using the product to ensure proper functionality and longevity.



Image: The Redragon M601-WL-BA RF Wireless Optical Mouse positioned on its accompanying mouse pad, showcasing its design and the pad's red and black aesthetic.

Package Contents

- Redragon M601-WL-BA RF Wireless Optical Mouse
- Wireless USB Receiver
- User Manual (this document)
- Mouse Pad (as part of the combo)

Setup

1. Battery Installation

The Redragon M601-WL-BA mouse requires batteries for operation. Locate the battery compartment on the underside of the mouse. Insert the required batteries, ensuring correct polarity (+/-). Close the battery compartment cover securely.

2. Connecting the Wireless USB Receiver

1. Locate the wireless USB receiver, typically stored within the mouse's battery compartment or packaging.
2. Plug the USB receiver into an available USB port on your computer.
3. The computer should automatically detect and install the necessary drivers. This process may take a few moments.
4. Turn on the mouse using the power switch, usually located on the underside.
5. The mouse should now be connected and ready for use. If not, refer to the Troubleshooting section.



Image: An angled perspective of the Redragon M601-WL-BA mouse on its mouse pad, highlighting its ergonomic shape and button layout.

Operating Instructions

Basic Functions

- **Left Click:** Primary button for selecting items and interacting with software.
- **Right Click:** Secondary button for accessing context menus and additional options.
- **Scroll Wheel:** Used for vertical scrolling through documents and web pages. It can also function as a middle click button.

DPI Adjustment

The Redragon M601-WL-BA mouse features adjustable DPI (Dots Per Inch) settings, allowing you to change cursor sensitivity. Locate the DPI button, typically near the scroll wheel. Pressing this button will cycle through different DPI levels (e.g., 800, 1200, 1600, 2400 DPI), indicated by a change in LED color or a brief cursor speed alteration. Select the DPI setting that best suits your preference and task.



Image: A detailed angled view of the Redragon M601-WL-BA mouse, emphasizing its textured grip and side buttons.

Maintenance

Cleaning the Mouse

- Disconnect the mouse from your computer by removing the USB receiver.
- Use a soft, lint-free cloth lightly dampened with water or a mild cleaning solution to wipe the surface of the mouse.
- Avoid using harsh chemicals, abrasive cleaners, or spraying liquids directly onto the mouse.
- For the optical sensor, use a dry cotton swab to gently clean any dust or debris.

Cleaning the Mouse Pad

- The mouse pad can be gently hand-washed with mild soap and cold water.
- Rinse thoroughly and allow it to air dry completely before use. Do not machine wash or tumble dry.



Image: The underside of the Redragon mouse pad, rolled to show its non-slip rubber base.

Troubleshooting

- **Mouse not responding:**
  - Ensure the mouse is powered on.
  - Check battery levels and replace if necessary.
  - Verify the USB receiver is securely plugged into a working USB port. Try a different USB port.
  - Move the mouse closer to the USB receiver to rule out interference.
  - Restart your computer.
- **Cursor movement is erratic or slow:**
  - Clean the optical sensor on the underside of the mouse.
  - Ensure you are using the mouse on a suitable surface (e.g., the included mouse pad).
  - Adjust the DPI setting using the DPI button.
- **Wireless connection issues:**
  - Avoid placing the USB receiver near other wireless devices or large metal objects that might cause interference.
  - Ensure no other wireless devices are using the same frequency band if possible.

Specifications

Model	M601WL-BA
Connectivity	RF Wireless (USB Receiver)
Movement Detection Technology	Optical
DPI Settings	Up to 2400 DPI (Adjustable)
Hand Orientation	Right Hand
Power Source	Battery Powered
Product Dimensions	25.4 x 5.08 x 6.86 cm (Mouse)
Item Weight	320 g

Warranty and Support

Redragon products are designed for reliability and performance. This product is covered by a limited warranty against defects in materials and workmanship. For specific warranty terms, duration, and to obtain technical support, please refer to the warranty card included with your product or visit the official Redragon website.
For further assistance, please contact Redragon customer support through their official channels.

© 2025 Redragon. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09J22SQGN

More documents and user manuals: **https://manuals.plus/**