ProCase PC-08363119

ProCase Protective Case for iPad Air 4 (10.9 Inch, 2020) - Instruction Manual

Model: PC-08363119

1. PRODUCT OVERVIEW

This ProCase protective case is specifically designed for the iPad Air 4th Generation 10.9 inch (2020 models A2324, A2072, A2316, A2325). It offers robust protection and enhanced functionality for your device.

- **Compatibility:** Exclusively designed for iPad Air 4th Generation 10.9 inch (2020). Please verify your iPad model number (A2324/ A2072/ A2316/ A2325) on the back of your device before installation.
- **Protection:** Features a TPU shockproof border and a translucent PC frosted back to safeguard your iPad from fingerprints, scratches, drops, and impacts.
- **Smart Functionality:** Supports automatic sleep/wake function to conserve battery life.
- **Integrated Pen Holder:** Includes a built-in holder for secure storage and charging of the 2nd generation Apple Pencil.
- **Versatile Stand:** The tri-fold front cover provides two stable standing positions for comfortable viewing and typing.

Image 1.1: Compatibility chart for iPad Air 4 (2020) models. Ensure your iPad model matches one of the listed numbers (A2324, A2072, A2316, A2325) for proper fit.

2. SETUP AND INSTALLATION

1. **Prepare the Case:** Before installing your iPad, gently peel off any protective films from both the front and back of the clear PC frosted back cover. This ensures optimal clarity and appearance.

Please tear off the film on the front and back of the clear back

Image 2.1: Removing the protective film from the case's clear back panel.

2. **Insert iPad:** Carefully align your iPad Air 4 with the case. Start by inserting one side of the iPad into the flexible TPU border, then gently press the remaining edges until the iPad is fully seated within the case. Ensure all corners are securely covered.

3. **Check Fit:** Verify that all ports, buttons, and the camera cutout are correctly aligned and accessible. The flexible TPU bumper should snugly fit around the iPad's edges, providing shock absorption.

Image 2.2: Detailed view of precise cutouts for ports, buttons, and camera, ensuring full accessibility.

3. OPERATING INSTRUCTIONS

3.1 Using the Tri-Fold Stand

The front cover of the case is designed to fold into two distinct stand positions, offering versatility for different activities.

- **Viewing Mode (30° Angle):** Fold the front cover into a triangular stand to prop up your iPad at approximately a 30-degree angle. This position is ideal for watching videos, making video calls, or browsing content.
- **Typing Mode (65° Angle):** Fold the front cover into a lower triangular stand to position your iPad at approximately a 65-degree angle. This angle is optimized for comfortable typing and drawing.

Image 3.1: Demonstrating the 30° viewing angle and 65° typing angle provided by the tri-fold cover.

3.2 Apple Pencil Holder

The case features a dedicated slot for your 2nd generation Apple Pencil, ensuring it is always secure and ready for use.

- **Storing the Pencil:** Gently slide your Apple Pencil into the integrated holder located on the side of the case.
- **Charging:** The holder is designed to allow the Apple Pencil (2nd Gen) to magnetically attach and charge wirelessly while stored, ensuring it's always powered when you need it.

Image 3.2: The built-in pencil holder securely stores and charges the Apple Pencil.

3.3 Auto Sleep/Wake Function

The smart cover supports your iPad's auto sleep/wake feature, enhancing convenience and battery efficiency.

- **Sleep:** Closing the front cover will automatically put your iPad to sleep, turning off the screen.
- **Wake:** Opening the front cover will automatically wake your iPad, turning on the screen.

Image 3.3: Illustration of the auto sleep/wake function, saving battery life.

4. MAINTENANCE AND CARE

To ensure the longevity and appearance of your ProCase, follow these simple care guidelines:

- **Cleaning:** Wipe the case regularly with a soft, damp cloth. For stubborn marks, a mild soap solution can be used, followed by wiping with a clean, damp cloth and air drying. Avoid harsh chemicals or abrasive cleaners.
- **Avoid Extreme Conditions:** Do not expose the case to extreme temperatures, direct sunlight for prolonged periods, or corrosive substances, as this may cause material degradation or discoloration.
- **Handling:** While the case offers protection, avoid unnecessary drops or impacts to both the case and your iPad.

5. TROUBLESHOOTING

Most issues with a protective case are minor. Here are some common concerns and their solutions:

- **Case Does Not Fit:**
  Ensure your iPad is the 4th Generation 10.9 inch (2020 model numbers A2324, A2072, A2316,

A2325). This case is not compatible with other iPad models. Double-check the model number on the back of your iPad.

- **Auto Sleep/Wake Not Working:**
  Verify that the iPad's "Lock/Unlock" feature is enabled in Settings > Display & Brightness. Also, ensure the case cover is fully closed and making proper contact with the screen.

- **Apple Pencil Not Charging:**
  Ensure your Apple Pencil is a 2nd Generation model, as only this version supports wireless charging. Confirm the pencil is correctly seated in the holder and making magnetic contact with the iPad's charging strip.

- **Case Appears Scratched/Cloudy:**
  Confirm that all protective films have been removed from both sides of the translucent back panel. These films are often mistaken for scratches or cloudiness.

6. SPECIFICATIONS

Brand	ProCase
Model Number	PC-08363119
Compatible Devices	iPad Air 4th Generation 10.9 inch (2020) - Models A2324, A2072, A2316, A2325
Material	TPU (Thermoplastic Polyurethane) border, PC (Polycarbonate) frosted back
Form Factor	Case
Shell Type	Hard (back), Flexible (border)
Product Dimensions	10.3 x 7.5 x 0.6 inches
Item Weight	10.6 ounces
Special Features	Shockproof, Auto Sleep/Wake, Built-in Apple Pencil Holder, Tri-fold Stand

7. WARRANTY AND SUPPORT

For specific warranty information or technical support regarding your ProCase product, please refer to the official ProCase website or contact their customer service directly. Contact details are typically available on the product packaging or the manufacturer's official online channels.

You can visit the ProCase Store on Amazon for more information and product updates.