

[Manuals.plus](#) /

› [BesLowe](#) /

› BesLowe Outdoor Wall Light Fixtures Instruction Manual

BesLowe B04013P

BesLowe Outdoor Wall Light Fixtures Instruction Manual

Model: B04013P

INTRODUCTION

Thank you for choosing BesLowe Outdoor Wall Light Fixtures. These modern-style lanterns are designed to enhance the exterior of your home with durable, weather-resistant lighting. Featuring a sleek matte black finish and clear glass shades, they provide ample illumination while complementing various architectural styles. This manual provides essential information for safe installation, operation, and maintenance of your new lighting fixtures.



Image: Two BesLowe Outdoor Wall Light Fixtures, showcasing their modern design and clear glass panels.

IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or personal injury, please read and follow all instructions carefully. Keep this manual for future reference.

- **WARNING:** Risk of electric shock. Disconnect power at the fuse or circuit breaker before installing or servicing.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Consult a qualified electrician if you are unfamiliar with proper electrical wiring installations.
- Do not install this fixture in wet locations where water may directly contact electrical components.
- Ensure the fixture is securely mounted to a structural element of the building.
- Use only E26 base bulbs with a maximum wattage of 100W. Exceeding the maximum wattage may cause overheating

and fire.

- Do not touch the bulb when the fixture is operating or immediately after turning it off, as the bulb will be hot.
- Inspect the fixture for any damage before installation. Do not install if damaged.

WHAT'S INCLUDED

Verify that all components are present before beginning installation:

- 2 x Outdoor Wall Light Fixtures
- Mounting Hardware (screws, wire nuts, mounting plate)
- Instruction Manual

Note: E26 base bulbs are not included and must be purchased separately.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	BesLowe
Model Name	B04013P(2PK)
Color	Matte Black
Material	Metal + Glass
Product Dimensions	4.7"L x 4.7"W x 12.8"H (12cm x 12cm x 32.5cm)
Voltage	120 Volts (AC)
Max Wattage	100 Watts per bulb
Bulb Base	E26 Medium
Indoor/Outdoor Usage	Outdoor
Special Feature	Waterproof, Rust-resistant



✓ High-quality Metal	✗ Poor-quality Metal
✓ Sturdy Clear Glass	✗ Fragile Thin Glass
✓ Waterproof	✗ Not Waterproof
✓ Weather Resistant	✗ Not Sunproof or Snowproof
✓ Anti-rust	✗ Easy to Rust
✓ Anti-corrosion	✗ Easy to Corrode

Image: Detailed product dimensions and electrical specifications.

SETUP AND INSTALLATION

Before Installation

- Turn off power at the circuit breaker or fuse box.
- Ensure the mounting surface is clean, dry, and structurally sound.
- Unpack all components and inspect for any damage.

Installation Steps

1. Attach the mounting plate to the junction box using the provided screws. Ensure the plate is level and secure.
2. Connect the electrical wires:

- Connect the black wire from the fixture to the black (hot) wire from the junction box using a wire nut.
- Connect the white wire from the fixture to the white (neutral) wire from the junction box using a wire nut.
- Connect the ground wire from the fixture to the ground wire from the junction box (or to the green ground screw on the mounting plate) using a wire nut.

3. Carefully tuck all wires into the junction box.

4. Align the fixture with the mounting plate and secure it using the provided screws.

5. Install E26 base bulbs (not included) into the sockets. The open bottom design allows for easy bulb replacement.

6. Restore power at the circuit breaker or fuse box.



Work Well with Various E26 Base Bulbs(100W Max)

(Bulbs not Included)



Image: Example of installed fixtures on a house exterior.

OPERATION

These outdoor wall light fixtures are designed for simple operation via a standard wall switch (not included). Once

properly installed and powered, simply toggle your wall switch to turn the lights on or off.

Recommended Bulbs

The fixtures require E26 base bulbs (100W Max). They are compatible with various bulb types, including CFL, incandescent, LED, and halogen. For a classic and stylish look, ST58/ST64 LED Edison bulbs or incandescent bulbs are highly recommended to complement the clear glass design.



Image: Examples of compatible E26 base bulbs.

MAINTENANCE AND CARE

Regular maintenance will help preserve the appearance and functionality of your light fixtures.

- **Cleaning:** To clean the fixture, ensure power is off. Wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents, as they may damage the finish or glass. The open bottom design facilitates easy cleaning and bulb

replacement.

- **Weather Resistance:** These fixtures are constructed with a sturdy metal frame and thickened glass panels, making them waterproof and durable against various weather conditions, including sun, snow, rain, and ice. The high-quality metal is designed to resist rust and corrosion, maintaining its stylish appearance over time.
- **Bulb Replacement:** Always turn off power before replacing bulbs. Allow bulbs to cool completely before handling.



Image: Demonstrating the fixture's weather resistance in rain and snow.

TROUBLESHOOTING

If you encounter issues with your light fixture, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Light does not turn on.	No power, loose wiring, faulty bulb, faulty switch.	Check circuit breaker. Ensure all wire connections are secure. Replace bulb. Test switch.
Light flickers.	Loose bulb, incompatible dimmer switch, loose wiring.	Tighten bulb. Ensure dimmer is compatible with bulb type. Check wiring connections.
Glass is dirty or foggy.	Accumulated dust or moisture.	Clean glass with a soft, damp cloth. Ensure proper sealing if applicable.

If the problem persists after attempting these solutions, please contact customer support.

WARRANTY AND SUPPORT

Your BesLowe Outdoor Wall Light Fixtures come with a Limited Warranty. Please refer to the warranty information provided at the time of purchase for specific terms and conditions.

For technical assistance, replacement parts, or warranty claims, please contact BesLowe customer support through the retailer where you purchased the product or visit the official BesLowe website.

Visit the [BesLowe Store](#) for more products and information.

© 2025 BesLowe. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

