

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Ariete](#) /
- › [Ariete Sani-Jet Air Purifier and Humidifier ART2836 User Manual](#)

Ariete ART2836

Ariete Sani-Jet Air Purifier and Humidifier ART2836 User Manual

Model: ART2836

1. INTRODUCTION

The Ariete Sani-Jet Air Purifier and Humidifier ART2836 is a versatile device designed to improve air quality in various environments. It functions as both an air sanitizer, effectively removing germs and bacteria, and a humidifier, adding moisture to the air for a healthier and more comfortable atmosphere. This manual provides essential information for the safe and efficient operation, setup, and maintenance of your device.



Figure 1: The Ariete Sani-Jet Air Purifier and Humidifier in a modern living room setting.

2. SAFETY INSTRUCTIONS

Please read all safety instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always place the device on a stable, flat, and water-resistant surface.
- Do not immerse the device, power cord, or plug in water or other liquids.
- Keep the device out of reach of children and pets.
- Unplug the device from the power outlet before filling, cleaning, or when not in use.
- Use only the recommended Sani-Jet Clean sachets for sanitizing mode. Do not use other chemicals or additives.
- Ensure the voltage indicated on the appliance matches your local power supply before connecting.
- Do not block the mist outlet or air inlets.
- For sanitizing mode, operate the device in unoccupied rooms. Allow sufficient time for the air to clear before re-entering.
- Do not attempt to repair or modify the appliance yourself. Contact qualified service personnel for repairs.

3. PRODUCT OVERVIEW

Familiarize yourself with the main components of your Ariete Sani-Jet Air device:

- **Mist Outlet:** Where the mist is released.
- **Water Tank:** Holds the water for humidification and sanitization.
- **LED Touch Screen:** For controlling settings, modes, and timer.
- **Base Unit:** Contains the electronic components and water sensor.
- **Power Cord:** For connecting to an electrical outlet.



4. SETUP

Follow these steps to set up your Ariete Sani-Jet Air device:

1. **Unpack:** Carefully remove the device and all accessories from the packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the device on a firm, level, and water-resistant surface, at least 15 cm away from walls and heat sources. Avoid placing it near electronic devices.
3. **Fill Water Tank:** Remove the water tank from the base. Fill the tank with clean, cool water. For optimal performance and to prevent mineral buildup, it is recommended to use demineralized or distilled water, especially for humidification. The tank has a maximum capacity of 5000 ml (5 liters).
4. **For Sanitizing Mode:** If using the sanitizing function, dissolve one Sani-Jet Clean sachet in 700 ml of water before pouring it into the tank. Ensure the sachet is fully dissolved.
5. **Replace Tank:** Securely place the filled water tank back onto the base unit.
6. **Connect Power:** Plug the power cord into a suitable 220-volt electrical outlet. The device will enter standby mode.

5. OPERATING INSTRUCTIONS

5.1 General Operation

- **Power On/Off:** Touch the power icon on the LED screen to turn the device on or off.
- **LED Touch Screen:** All functions and settings are controlled via the intuitive LED touch screen.

5.2 Sanitizing Mode

The sanitizing mode uses the Sani-Jet Clean solution to purify the air and surfaces.

1. Ensure the water tank contains 700 ml of water with a dissolved Sani-Jet Clean sachet (refer to Setup section).
2. Turn on the device.
3. Select the sanitizing mode from the LED touch screen.
4. Set the desired operating time using the timer function.
5. **Important:** Operate the sanitizing mode only in unoccupied rooms. Ensure no people, pets, or sensitive plants are present during operation. Allow the room to ventilate and the mist to settle completely before re-entering.

5.3 Humidifier Mode

The humidifier mode adds moisture to the air, improving comfort and air quality.

1. Fill the water tank with clean, demineralized water (up to 5 liters).
2. Turn on the device.
3. Select the humidifier mode from the LED touch screen.
4. Adjust the humidity level. The device allows for adjustment up to 95% relative humidity.
5. The device operates quietly, providing a relaxing environment.

5.4 Timer Function

The integrated timer allows you to set the operating duration for both modes.

- Access the timer settings via the LED touch screen.

- Select the desired operating time. The device will automatically shut off once the set time has elapsed.

5.5 Automatic Shutoff

The device features an automatic shutoff function for safety and convenience. It will turn off automatically when the water level is too low or when the set timer expires.



Figure 3: The device in a commercial environment, such as a salon, highlighting its suitability for various spaces.

6. MAINTENANCE

Regular cleaning and maintenance ensure the longevity and efficient operation of your device.

- **Daily Cleaning:** Empty and rinse the water tank daily. Refill with fresh water.
- **Weekly Cleaning:**
 - Unplug the device before cleaning.
 - Remove the water tank and empty any remaining water.
 - Clean the water tank and base unit with a soft cloth and mild detergent. Rinse thoroughly.
 - Use a soft brush or cotton swab to clean the mist outlet and any small crevices.
 - For mineral deposits, fill the tank with a mixture of white vinegar and water (1:1 ratio) and let it sit for 30 minutes, then rinse thoroughly.
 - Do not use abrasive cleaners or harsh chemicals.
- **Water Quality:** Always use demineralized or distilled water for humidification to prevent mineral buildup and extend the life of the device.
- **Storage:** When not in use for extended periods, clean and dry the device thoroughly, then store it in its original packaging in a cool, dry place.

7. TROUBLESHOOTING

If you encounter issues with your Ariete Sani-Jet Air, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|----------------------------|--|--|
| Device does not turn on | No power, loose plug, power outage | Check power connection, try another outlet, ensure power supply is active. |
| No mist or low mist output | Low water level, clogged mist outlet, mineral buildup, incorrect mode selected | Refill water tank, clean mist outlet, descale the device, ensure correct mode (sanitizing/humidifier) is active. |
| Unusual noise | Device not on a level surface, foreign object in water tank, fan obstruction | Place on a stable surface, check water tank for debris, ensure no obstructions around the fan. |
| Device stops unexpectedly | Water tank empty, timer expired, tap water usage causing malfunction | Refill water tank, check timer settings, ensure demineralized water is used for humidification. |

If the problem persists after attempting these solutions, please contact customer support.

8. SPECIFICATIONS

Technical specifications for the Ariete Sani-Jet Air Purifier and Humidifier ART2836:

- **Brand:** Ariete
- **Model Number:** ART2836
- **Color:** White and Blue
- **Product Dimensions:** 21.5 x 21.5 x 29 cm
- **Item Weight:** 1.5 kg
- **Capacity:** 5000 ml (5 Liters)
- **Power/Wattage:** 30 watts
- **Voltage:** 220 volts
- **Special Features:** Timer, Automatic Shutoff
- **Manufacturer:** Ariete
- **First Available Date:** November 2, 2022

9. WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the warranty card included with your purchase or contact your retailer. Keep your proof of purchase for warranty claims.