

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Doohoeek](#) /

› [Doohoeek Bluetooth Backlit Keyboard Case with Trackpad for Samsung Galaxy Tab S8 Plus, S7 FE, and S7 Plus - User Manual](#)

Doohoeek SM-TKBD

Doohoeek Bluetooth Backlit Keyboard Case with Trackpad User Manual

Model: SM-TKBD

INTRODUCTION

This manual provides detailed instructions for setting up, operating, and maintaining your Doohoeek Bluetooth Backlit Keyboard Case with Trackpad. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.

COMPATIBILITY

The Doohoeek Keyboard Case is designed for specific Samsung Galaxy Tab models. Please verify your tablet's model number before use.

- Samsung Galaxy Tab S8 Plus 12.4" (2022)
- Samsung Galaxy Tab S7 FE 12.4" (2021) (Models: SM-T730/T733/T735/T736/T738)
- Samsung Galaxy Tab S7 Plus 12.4" (2020) (Models: SM-T970/T975/T976/T978)

To check your tablet's model number, navigate to **Settings > About Tablet** on your device.

PACKAGE CONTENTS

Ensure all items are present in the package:

- Bluetooth Keyboard (x1)
- Protective Case (x1)
- USB-C Charging Cord (x1)
- User Manual (x1)

Note: The tablet and S Pen are not included.

SETUP INSTRUCTIONS

1. Charging the Keyboard

Before initial use, fully charge the keyboard using the provided USB-C charging cord.



Image: The keyboard's USB-C charging port is located on the side. Connect the provided USB-C cable to charge the internal 650mAh rechargeable lithium battery. Charging typically takes 2-3 hours.

2. Attaching the Tablet to the Case

Place your Samsung Galaxy Tab into the protective case. The case is designed to securely hold your tablet while providing access to all ports and buttons.

3. Attaching the Keyboard

The keyboard is magnetically attached to the case. Simply place the keyboard onto the designated area within the case. This magnetic design allows for easy removal if you prefer to use the tablet without the keyboard.

MAGNETICALLY ATTACABLE DESIGN WITH ADJUSTABLE 3-LEVEL VIEWING ANGLE



Image: The tablet is shown securely held within the case, with the keyboard magnetically attached below it. The image also illustrates the adjustable kickstand feature.

4. Adjusting the Viewing Angle

The case features an adjustable 3-level kickstand. Extend the kickstand to achieve your preferred viewing or typing angle. The magnetic base ensures stability.

OPERATING INSTRUCTIONS

1. Powering On the Keyboard

Locate the power switch on the keyboard and slide it to the 'ON' position.

2. Bluetooth Pairing

1. Ensure the keyboard is fully charged.
2. Turn on the keyboard.
3. Press and hold the **Fn + C** keys simultaneously for 3 seconds to enter Bluetooth pairing mode. The Bluetooth indicator light will flash.
4. On your Samsung Galaxy Tab, go to **Settings > Bluetooth** and turn Bluetooth on.
5. Select "wireless keyboard" from the list of available devices to connect.

3. Using the Trackpad

The integrated trackpad provides precise control and supports multi-touch gestures for efficient navigation. If you do not wish to use the trackpad, you can disable it.

- **Enable/Disable Trackpad:** Press **Fn + Space Bar** to lock or unlock the trackpad.




Image: A finger interacts with the responsive trackpad on the keyboard, highlighting its functionality.

4. Adjusting Backlit Keys

The keyboard features 7 colors and 3 levels of brightness for its backlit keys, allowing comfortable typing in various lighting conditions.

- **Change Backlight Color:** Press **Fn +** (bulb button, located next to the volume keys) to cycle through the 7 available colors.
- **Adjust Brightness:** Press the **(bulb button)** only to adjust the backlight brightness up or down through 3 levels.



7-COLOR 3-LEVEL BRIGHTNESS BACKLIT KEYS

 Adjust keys backlighting down or up

 +  Change backlighting colors



Image: A close-up view of the keyboard keys illuminated in various colors, demonstrating the 7-color, 3-level brightness backlight feature.

5. S Pen Storage and Charging

The case includes an open slit designed for your S Pen, allowing for secure storage and quick power boosting while the S Pen is in place.

SECURE AND SMOOTH CASE WITH HOME FOR S PEN



Image: A detailed view of the case's side, illustrating the dedicated slot for the S Pen, which also facilitates charging.

MAINTENANCE

To maintain your keyboard case, follow these guidelines:

- Clean the keyboard and case regularly with a soft, dry, lint-free cloth.
- Avoid using harsh chemicals or abrasive cleaners.
- Keep the device away from liquids and extreme temperatures.

TROUBLESHOOTING

1. Keyboard Not Connecting via Bluetooth

- Ensure the keyboard is fully charged and powered on.
- Confirm the keyboard is in pairing mode (Fn + C pressed for 3 seconds).
- On your tablet's Bluetooth settings, try to "forget" or "delete" any previously connected devices, then attempt to reconnect the keyboard.

- Restart both your tablet and the keyboard, then try pairing again.

2. Cursor Randomly Moves While Typing

This can occur if the trackpad is accidentally touched during typing.

- Press **Fn + Space Bar** to lock the trackpad. Repeat to unlock when needed.

3. Backlight Not Working or Changing

- Ensure the keyboard is powered on and charged.
- Press **Fn +** to change colors.
- Press only to adjust brightness levels.

SPECIFICATIONS

Model Number	SM-TKBD
Connectivity Technology	Bluetooth
Keyboard Layout	US Layout
Charging Port	USB-C
Special Features	Backlit, Trackpad
Keyboard Backlighting	7 Colors, 3 Brightness Levels (RGB)
Battery Capacity	650mAh
Charging Time	2-3 Hours
Working Time (without backlight)	Approx. 300 hours
Material	Acrylonitrile Butadiene Styrene
Item Weight	1.73 pounds

PRODUCT VIDEO

Your browser does not support the video tag.

Video: This video demonstrates the features of the Doohoeek Backlit Keyboard Case, including its quiet scissor-switch keys, responsive trackpad, magnetic attachment, adjustable viewing angles, S Pen storage, and secure protection.

WARRANTY AND SUPPORT

No specific warranty information is provided in this manual. For warranty details or technical support, please refer to the product packaging or contact Doohoeek customer service through their official channels or the retailer where the product was purchased.

You can visit the Doohoeek store on Amazon for more information:[Doohoeek Amazon Store](#)

