

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Avolusion](#) /

› Avolusion HDDGear Pro X 3TB External Gaming Hard Drive User Manual

Avolusion HDDGU3-PROX-3TB-XS

Avolusion HDDGear Pro X 3TB External Gaming Hard Drive User Manual

PRODUCT OVERVIEW

The Avolusion HDDGear Pro X is a 3TB USB 3.0 external gaming hard drive designed to expand the storage capacity of your Xbox console. It is compatible with Xbox Series X, Xbox Series S, Xbox One X, Xbox One S, and Xbox One (Gen 1). This drive allows you to store a vast library of games, videos, and media. For optimal performance, new generation Xbox Series X|S games require installation on the console's internal SSD. However, older Xbox One titles can be played directly from this external drive, freeing up valuable internal SSD space for your latest games.



Image: Avolusion HDDGear Pro X 3TB External Gaming Hard Drive with 'Built-in 3TB' and 'XBOX Series X, S pre-formatted' labels.

WHAT'S IN THE BOX

Upon opening your Avolusion HDDGear Pro X package, you should find the following items:

- Avolusion HDDGear HDDGU3 Pro X 3TB External Gaming Storage
- USB 3.0 cable
- Power adapter
- User manual



Note: XBOX One Game Console NOT included

Image: Retail box, user manual, AC power adapter, and USB cable included with the Avolusion HDDGear Pro X.

SETUP INSTRUCTIONS

Connecting the Hard Drive

Follow these steps to connect your Avolusion HDDGear Pro X to your Xbox console:

1. Connect the power adapter to the hard drive's power input and then to a wall outlet.
2. Connect one end of the USB 3.0 cable to the USB port (Type C) on the hard drive.
3. Connect the other end of the USB 3.0 cable to an available USB port on your Xbox console.
4. Turn on the power switch on the hard drive. The blue LED lights will illuminate, indicating power.



Image: Rear view of the Avolusion HDDGear Pro X, showing the USB Port (Type C), Power Input, and Power Switch.

Formatting the Hard Drive for Xbox

After connecting the drive, your Xbox console will prompt you to format it for game and app storage. Follow the on-screen instructions. If the prompt does not appear automatically, you may need to unplug and reconnect the USB cable.

Your browser does not support the video tag.

Video: This video demonstrates how to connect and format the Avolusion HDDGear Pro X external USB hard drive for your Xbox console, including initial setup steps and navigating the Xbox interface to prepare the drive for use.

OPERATING INSTRUCTIONS

Game Storage and Playback

The Avolusion HDDGear Pro X is optimized for storing and playing Xbox One generation games directly. For Xbox Series X|S optimized games, they must be played from the console's internal SSD. However, you can store Xbox Series X|S games on the external drive and transfer them to the internal SSD when you wish to play them. Transferring games from the external drive is significantly faster than re-downloading them.

XBOX One Game (Store & Play)
Store & Play XBOX One Game
direct from Avolusion USB Gaming HDD



XBOX Series S / X Game (Store Only)
(Factory designed) XBOX Series X / S Game
has to play direct from internal SSD.
To free up internal SSD space, Move & Store XBOX X / S Game
from Internal SSD to External USB Gaming HDD
(It's a lot faster than re-download the game online,
about 3 ~ 5min per game to transfer to USB HDD)

Image: Diagram illustrating that Xbox One games can be stored and played directly from the Avolusion USB Gaming HDD, while Xbox Series X/S games are for storage only on the external drive and must be moved to the internal SSD for play.

Moving Games to the External Drive

To move games from your Xbox console's internal storage to the Avolusion HDDGear Pro X, follow these steps:

1. Navigate to 'Settings' on your Xbox dashboard.
2. Select 'System' then 'Storage devices'.
3. Choose your internal storage, then select 'Move or copy'.
4. Select the games you wish to move and choose the Avolusion HDDGear Pro X as the destination.

Your browser does not support the video tag.

Video: This video guides you through the process of moving Xbox games from your console's internal storage to the Avolusion USB external hard drive, demonstrating the menu navigation and selection process.

Moving Games from External Drive to Console

To move games from your Avolusion HDDGear Pro X back to your Xbox console's internal storage for playing Xbox Series X/S optimized titles, follow these steps:

1. Navigate to 'Settings' on your Xbox dashboard.
2. Select 'System' then 'Storage devices'.
3. Choose the Avolusion HDDGear Pro X, then select 'Move or copy'.
4. Select the games you wish to move and choose the internal storage as the destination.

Your browser does not support the video tag.

Video: This video illustrates how to transfer Xbox games from the Avolusion USB external hard drive back

to the Xbox console's internal storage, detailing the necessary menu selections.

MAINTENANCE

To ensure the longevity and optimal performance of your Avolusion HDDGear Pro X, consider the following maintenance tips:

- **Keep it Clean:** Regularly wipe the exterior with a soft, dry cloth to prevent dust buildup. Avoid using liquid cleaners directly on the device.
- **Proper Placement:** Place the hard drive on a stable, flat surface away from direct sunlight, heat sources, and areas with high humidity. Ensure adequate ventilation around the device.
- **Avoid Physical Shocks:** Hard drives are sensitive to impacts. Avoid dropping or jarring the device, especially when it is powered on.
- **Safe Disconnection:** Always safely eject the hard drive from your Xbox console before unplugging the USB cable or power adapter to prevent data corruption.

TROUBLESHOOTING

If you encounter issues with your Avolusion HDDGear Pro X, refer to the following common troubleshooting steps:

- **Drive Not Detected:**
 - Ensure the power adapter is securely connected to both the drive and a working power outlet.
 - Verify the USB 3.0 cable is firmly connected to both the drive and the Xbox console. Try a different USB port on the console.
 - Restart your Xbox console.
- **Slow Transfer Speeds:**
 - Ensure you are using a USB 3.0 port on your Xbox console. USB 2.0 ports will result in slower speeds.
 - Avoid running multiple demanding applications or games during large file transfers.
- **Games Not Launching from External Drive (Xbox Series X|S):**
 - Xbox Series X|S optimized games must be moved to the console's internal SSD to be played. The external drive is for storage of these titles.
 - Older Xbox One titles should launch directly from the external drive.
- **Drive Disconnects Randomly:**
 - Check all cable connections (power and USB) for looseness.
 - Ensure the drive is placed on a stable surface and not subject to vibrations.
 - Verify the power outlet is functioning correctly.

TECHNICAL SPECIFICATIONS

| Feature | Specification |
|-----------------------------|--|
| Brand | Avolusion |
| Model Number | HDDGU3-PROX-3TB-XS |
| Digital Storage Capacity | 3 TB |
| Hard Drive Type | Mechanical Hard Disk |
| Hard Drive Interface | USB 3.0 |
| Hard Drive Rotational Speed | 7200 RPM |
| Connectivity Technology | USB |
| Compatible Devices | Gaming Console (Xbox Series X, S, ONE X, S, Gen 1) |
| Item Dimensions (LxWxH) | 7.09 x 3.94 x 2.36 inches |
| Item Weight | 2 pounds |
| Color | Black |

WARRANTY AND SUPPORT

Avolusion products are manufactured to high-quality standards. For information regarding warranty coverage, technical support, or service inquiries, please refer to the documentation included with your product or visit the official Avolusion website. Keep your proof of purchase for warranty claims.

For further assistance, you may also contact Avolusion customer support directly through their official channels.
