## Manuals+

Q & A | Deep Search | Upload

## manuals.plus /

- > Bellemave /
- > Bellemave Twin Corner Daybed with Trundle and L-Shaped Bookcase, Gray Instruction Manual

## Bellemave FST00207-TT-AE1

# Bellemave Twin Corner Daybed with Trundle and L-Shaped Bookcase

INSTRUCTION MANUAL - MODEL FST00207-TT-AE1

## **Important Safety Information**

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- Be cautious of sharp edges on the bookcase during assembly and use.
- Ensure proper assembly to prevent instability. All connections must be securely tightened.
- Do not exceed the weight capacity of 70 pounds for the trundle bed. The main bed frame has a higher capacity, but specific limits should be observed.
- Keep small children away from the product during assembly and ensure all small parts are out of reach.
- · Regularly check all bolts and screws to ensure they remain tight.
- Use only mattresses of the appropriate size for both the main bed and the trundle to ensure proper fit and function.

## **Product Overview**

The Bellemave Twin Corner Daybed is a versatile furniture piece designed for compact spaces, offering both sleeping and storage solutions. It features a sturdy wood frame, an L-shaped bookcase headboard, a pull-out trundle bed for additional sleeping capacity, and an integrated charging station.



Figure 1: The Bellemave Twin Corner Daybed in gray, showcasing the main bed, the extended trundle, and the L-shaped bookcase with various items stored.

This daybed is constructed from high-quality pine wood and MDF, ensuring durability and stability. The L-shaped bookcase provides ample space for books, decor, and personal items, while the built-in charging station offers convenient access to power for electronic devices.

# **Specifications**

Feature	Detail
Model Number	FST00207-TT-AE1
Size	Twin
Product Dimensions	83.9"L x 47.9"W x 36.6"H
Color	Gray
Material	Engineered Wood, Pine Wood
Item Weight	70 Pounds

Feature	Detail
Assembly Required	Yes
Included Components	Bookcase, Headboard, Shelves, Slat, Trundle
Compatible Mattress Size	Twin




Figure 2: Detailed dimensions of the daybed, including length, width, height, and internal measurements for the trundle and bookcase shelves.

## **Setup and Assembly**

Assembly of the Bellemave Twin Corner Daybed is required. It is recommended that two adults perform the assembly to ensure safety and ease of construction. All necessary tools and hardware are included in the packaging. Each part is numbered for clear identification.

- Unpack and Identify Parts: Carefully unpack all components and lay them out on a clean, soft surface to prevent scratches. Refer to the included manual to identify each numbered part and hardware.
- 2. **Assemble the Main Bed Frame:** Follow the step-by-step instructions in the provided manual to construct the main bed frame. Ensure all bolts and screws are tightened securely but do not overtighten until all components are aligned.
- 3. **Install Slats:** Place the wooden slats onto the designated supports on the main bed frame. Secure them according to the manual's instructions.




Figure 3: The main bed frame with wooden slats in place, demonstrating the foundation for the mattress.

- 4. **Assemble the Trundle Bed:** Construct the trundle bed frame separately, ensuring the wheels are properly attached for smooth operation.
- 5. **Integrate Trundle:** Once assembled, slide the trundle bed into its designated space beneath the main bed frame.



Figure 4: The daybed with the trundle bed fully retracted, showing its compact configuration.

6. **Attach L-Shaped Bookcase:** Secure the L-shaped bookcase components to the headboard and side of the bed frame as per the manual. Ensure the charging station is correctly positioned and its power cord is accessible.



Figure 5: View of the power cord for the integrated charging station, located on the underside of the bookcase.

7. **Final Tightening:** Once all parts are assembled and aligned, go back and fully tighten all bolts and screws. Do not overtighten.

**Note:** The pre-drilled holes are designed to simplify the installation process. If you encounter any difficulties, refer to the detailed manual or contact customer support.

## **Operating Instructions**

This daybed offers multiple functionalities for daily use.

## **Using the Trundle Bed**

The trundle bed is designed to provide an additional sleeping surface. To use it, simply grasp the front panel of the trundle and gently pull it out from under the main bed. The trundle is equipped with wheels for smooth movement. To retract, push it back into place until it is fully stored under the main bed.

## **Utilizing the L-Shaped Bookcase**

The L-shaped bookcase offers various compartments for storage and display. Organize books, decorative items, or personal essentials within these shelves. Ensure items are placed securely to prevent them from falling.




Figure 6: A close-up of the L-shaped bookcase, highlighting the various storage compartments.

# **Operating the Charging Station**

The integrated charging station includes USB ports and power outlets. To activate, ensure the bed's power cord (Figure 5) is plugged into a wall outlet. You can then connect your electronic devices to the USB ports or power outlets for charging or use.



Figure 7: The integrated charging station, showing the USB ports and standard power outlets for convenient device charging.

## **Care and Maintenance**

Proper care will extend the life and appearance of your Bellemave daybed.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Dusting:** Regularly dust the bed frame and bookcase shelves with a dry, soft cloth.
- Hardware Check: Periodically check all screws, bolts, and connections to ensure they are tight.

  Retighten as necessary to maintain stability.
- Avoid Moisture: Protect the wood from excessive moisture and direct sunlight, which can cause warping or fading.
- **Trundle Wheels:** Keep the trundle wheels free of debris to ensure smooth operation.

## **Troubleshooting**

If you encounter issues with your daybed, refer to the following common problems and solutions:

· Trundle does not slide smoothly:

- Ensure the mattress on the trundle is the correct size (Twin) and not too thick, which might prevent it from fitting under the main bed.
- Check for any obstructions or debris under the main bed or around the trundle wheels.
- Verify that the trundle wheels are securely attached and functioning correctly.

## • Bed feels unstable or wobbly:

- Recheck all assembly connections. Ensure all bolts and screws are fully tightened.
- Confirm that the bed is placed on a flat, level surface.

#### · Missing or damaged hardware:

- · Carefully re-examine all packaging for any overlooked hardware.
- Contact Bellemave customer support for replacement parts. Provide your model number and a description of the missing items.

## · Charging station not working:

- Ensure the bed's power cord is securely plugged into a functional wall outlet.
- Check if the wall outlet itself is receiving power by testing it with another device.
- Verify that the charging station unit is properly connected within the bed frame.

## **Warranty and Support**

Bellemave is committed to providing quality products. For any questions, concerns, or assistance with your product, please refer to the following information:

- **Returns:** This product is eligible for 90-day easy returns. Please refer to your purchase platform's return policy for detailed instructions.
- **Customer Support:** For technical assistance, missing parts, or warranty inquiries, please contact Bellemave customer support. You can often find contact information on the original packaging or through the retailer where the product was purchased.
- Online Resources: Visit the official Bellemave Store on Amazon for additional product information and support.


© 2025 Bellemave. All rights reserved.

## Related Documents - FST00207-TT-AE1




## Bellemave Bunk Bed Assembly Instructions - FU291CPCAN

Comprehensive assembly guide for the Bellemave FU291CPCAN bunk bed. Includes detailed steps for configuring as three single beds or a stacked bunk bed, with part lists, hardware, and safety information.



## Twin House Bed Assembly Instructions - SWB001/SWB002

Detailed assembly instructions for the Bellemave Twin House Bed (models SWB001/SWB002), including a part list, hardware list, and step-by-step guidance for construction.



#### Assembly Instructions for Bellemave Queen Size Bed Frame

Detailed assembly instructions for the Bellemave Queen Size Bed Frame (Models W1580113784, W1580113785, W1580113786), including part lists, hardware details, and step-by-step guidance for assembly.



#### Assembly Instructions for Twin House Floor Bed with Fence

Detailed assembly instructions for the Bellemave Twin House Floor Bed with Fence, including a parts list, hardware list, and step-by-step guidance.



## Assembly Instructions for Bellemave Twin Loft Bed with Stair (Model YX5525)

Detailed assembly instructions for the Bellemave Twin Loft Bed with Stair, model YX5525. Includes a comprehensive part list, hardware list, and step-by-step guidance with textual descriptions of diagrams.