YESHOMY YH-TS101KL

YESHOMY TV Stand Instruction Manual

Model: YH-TS101KL

1. Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your YESHOMY TV Stand. Designed for televisions up to 65 inches, this console table features practical sliding barn doors and ample storage, making it a functional and stylish addition to your living space.

2. Safety Information

Always refer to the manual of installation and usage included in your product packaging for comprehensive safety warnings and guidelines. Ensure all components are securely fastened before placing any items on the stand, especially heavy electronics like televisions. Do not exceed the recommended weight capacity for the top surface or shelves.

3. Product Features

- **TV Stand Size:** Accommodates televisions up to 65 inches, with dimensions of 27.6 inches (H) x 15.5 inches (D) x 58 inches (L).
- **Convenient Sliding Doors:** Two barn-style doors slide smoothly on metal rails, allowing you to conceal storage cabinets or the central shelf as needed.
- **Circular Drilling Design:** Features pre-drilled holes at the back for easy and neat routing of power supplies and cables for electronic equipment.
- **Large Storage Space:** Provides generous storage for electronic devices, media, and other household items, helping to keep your living room organized.
- **Adjustable Shelf:** The central shelf can be adjusted to different heights to accommodate various items, offering flexible storage solutions.
- **Durable Material:** Constructed from sturdy wood with a wood grain finish, designed for long-lasting use.

4. Setup and Assembly

Your YESHOMY TV Stand comes with a comprehensive manual of installation and usage, along with all necessary tools and parts. Follow the step-by-step instructions provided in the included manual carefully. While assembly may take some time, the

clear directions ensure a straightforward process. It is recommended to have two people for assembly to ensure stability and ease of construction.

5. Operating Instructions

- **Sliding Barn Doors:** To open or close the storage compartments, gently slide the barn doors along the top metal rail. The doors can be positioned to cover either the side cabinets or the central shelves, depending on your storage and display preferences.
- **Adjustable Shelves:** The internal shelves feature adjustable pegs. To change the shelf height, remove any items, lift the shelf, reposition the pegs to the desired height, and then place the shelf back securely.
- **Cable Management:** Utilize the circular drilling design at the back of the central compartments to neatly route cables and wires from your electronic devices, preventing clutter and ensuring proper ventilation.

6. Maintenance and Care

To maintain the appearance and longevity of your TV stand, follow these care instructions:

- **Cleaning:** For general cleaning, wipe the surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners. The manufacturer recommends "Hand Wash" for product care, implying gentle cleaning methods.
- **Dusting:** Regularly dust the surfaces with a dry, soft cloth to prevent buildup.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the wood finish.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the wood.

7. Troubleshooting

If you encounter any issues with your TV stand, consider the following common solutions:

- **Loose Components:** If the stand feels wobbly, check all screws and fasteners to ensure they are tightened securely.
- **Sticky Sliding Doors:** If the barn doors are difficult to slide, ensure the metal rails are clean and free of debris. A small amount of silicone lubricant can be applied to the rails if needed (avoid oil-based lubricants on wood).
- **Uneven Surface:** If the stand is uneven, check the floor for irregularities. Small furniture pads or shims can be placed under the base to level it.

For persistent issues or concerns not addressed here, please contact YESHOMY customer support.

8. Specifications

Specification	Detail
Brand	YESHOMY
Model Number	YH-TS101KL
Color	Barnwood
Material	Wood
Product Dimensions (L x W x H)	58 x 15.5 x 27.6 inches
Item Weight	80.8 pounds

Max TV Size Supported	Up to 65 inches
Special Feature	Adjustable Shelf
UPC	768494992620

9. Warranty and Support

Your YESHOMY TV Stand is eligible for 30-day easy returns. For any product-related inquiries, assistance with assembly, or troubleshooting, please contact customer support. Details for customer support are typically found on the product packaging or the retailer's website.

10. Visual Guide



The YESHOMY TV Stand, showcasing its barnwood finish and ample surface area for a large television.



Another view of the TV stand, highlighting its farmhouse aesthetic within a living room setting.



The TV stand with its sliding barn doors positioned to reveal the central storage compartments, ideal for media devices or decorative items.



A visual representation of the TV stand's dimensions and its compatibility with various TV sizes, up to 65 inches.



BARN DOOR DESIGN

Storage much more things through sliding it easily and conveniently.




Detailed view of the barn door design and the smooth

sliding mechanism on the metal rail.

DETAILS DESIGN





ADJUSTABLE SHELF



ROUND CABLE HOLE



STURDY WOOD BOARD

Illustrates key design details including the adjustable shelf, the convenient round cable hole for wire management, and the sturdy wood material.

P2-COMPLIANT MATERIAL



Highlights the P2-compliant material, emphasizing its waterproof, scratch-resistant, and durable properties.



The TV stand styled with various decorative items, showcasing its versatility as a console table.



A comprehensive diagram illustrating all key dimensions of the TV stand, including shelf heights and overall length, width, and height.

Official Product Videos

Your browser does not support the video tag.

This video provides an overview of the YESHOMY Modern TV Stand, showcasing its design and features in a home environment.

© 2025 YESHOMY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question