OLEVS GX-G9910

OLEVS Men Automatic Watch User Manual

Model: GX-G9910

Introduction

This manual provides comprehensive instructions for the OLEVS Men Automatic Watch, Model GX-G9910. Please read this manual thoroughly before using your watch to ensure proper operation and longevity. This watch features a self-winding mechanical movement, multi-calendar display, and 3ATM water resistance.

Product Overview

The OLEVS Men Automatic Watch is a sophisticated timepiece designed for durability and style. It features a classic skeleton design with sparkling diamonds and Roman numerals, enhancing its luxurious appeal. The watch is powered by a self-winding mechanical movement, eliminating the need for batteries.



Front view of the OLEVS Men Automatic Watch, showcasing its intricate dial and the included band adjustment tool.



The OLEVS Men Automatic Watch in black and black, worn on a wrist, highlighting its elegant design.




The OLEVS Men Automatic Watch in black and black, complementing formal attire.



A close-up view of the OLEVS Men Automatic Watch in black and black, resting on a watch cushion.



Detailed view of the watch dial, highlighting the skeleton movement, date window, and intricate design elements.



Infographic detailing the product parameters, including case diameter, thickness, chain width, chain length, movement type, water resistance, and watch weight.

Setup

Initial Winding and Time Setting

As an automatic mechanical watch, it does not require a battery. For the first use, or if the watch has stopped due to inactivity, it needs to be manually wound:

1. Ensure the crown is fully pushed in.

2. Turn the crown clockwise approximately 30-40 times until you feel resistance. This will initiate the movement and build up the power reserve.
3. To set the time, pull the crown out to the outermost position. Turn the crown to adjust the hour and minute hands.
4. Once the time is set, push the crown back in to secure it.

The watch will continue to wind itself through the natural motion of your wrist while worn. If worn for at least 8 hours a day, manual winding should not be frequently necessary. If not worn for extended periods, manually wind it every few days (e.g., every 7-14 days) to maintain accuracy.

Setting Date, Day, and Month

The watch features multi-calendar windows for date, day of the week, and month. Refer to the image below for button locations:



Diagram illustrating the functions of the watch's buttons for adjusting date, week, and month.

1. **Adjust Week:** Use the hidden button (1) to advance the day of the week.
2. **Adjust Date:** Use button (2) to advance the date.
3. **Adjust Time:** Pull out the crown (3) to the outermost position to set the time.
4. **Adjust Month:** Use button (4) to advance the month.

Note: Avoid adjusting the date or day between 9 PM and 3 AM, as this can damage the movement.

Strap Adjustment

The stainless steel strap can be resized to fit your wrist. A strap adjustment tool is included with your watch. If the strap is too loose or too tight, you can remove or add links as needed. For detailed instructions on using the strap adjustment tool, please refer to the video demonstration below or consult a professional jeweler.

Your browser does not support the video tag.


Video demonstrating how to resize the watch band using the provided tools. This video shows the process of removing links to achieve a comfortable fit.

Operating Instructions

Automatic Movement

The OLEVS GX-G9910 is an automatic watch, meaning it is powered by the motion of your body. When worn, the rotor inside the watch moves, winding the mainspring and storing energy. This energy powers the watch, allowing it to keep accurate time without a battery.

- **Power Reserve:** The watch has a power reserve of over 45 hours when fully wound.
- **Luminous Function:** The hands and markers feature a luminous coating, allowing you to read the time in low-light conditions.



The watch displaying its luminous hands and markers in a dark environment.

Maintenance

Water Resistance

This watch is 3ATM water-resistant, which means it can withstand splashes, rain, and brief immersion in water. It is**not** suitable for swimming, diving, or showering. Avoid exposing the watch to hot water or steam, as this can compromise the seals.

Cleaning and Care

- Wipe the watch case and strap regularly with a soft, dry cloth to remove dust and dirt.
- For the stainless steel strap, a slightly damp cloth can be used, followed by immediate drying.
- Avoid contact with harsh chemicals, solvents, or detergents, as these can damage the watch's finish and seals.
- Store your watch in a cool, dry place away from direct sunlight and extreme temperatures when not in use.

Service and Inspection

For optimal performance and longevity, it is recommended to have your mechanical watch serviced by a qualified watchmaker every 3-5 years. This includes cleaning, lubrication, and inspection of the movement and seals.

Troubleshooting

Problem	Possible Cause	Solution
Watch has stopped or is losing time.	Insufficient power reserve.	Manually wind the watch by turning the crown clockwise 30-40 times. Wear the watch regularly (8+ hours/day) to ensure continuous winding.
Date/Day/Month not changing correctly.	Adjusted during restricted hours (9 PM - 3 AM) or incorrect setting.	Avoid adjusting calendar functions between 9 PM and 3 AM. If already set incorrectly, advance the time past 3 AM, then reset the calendar functions.
Condensation inside the watch.	Exposure to extreme temperature changes or water ingress.	Immediately take the watch to a qualified watchmaker for inspection and repair to prevent internal damage. Avoid further water exposure.
Strap feels loose or too tight.	Incorrect strap size.	Use the provided strap adjustment tool to remove or add links. Refer to the strap adjustment section for guidance.

Specifications

Feature	Detail
Model Number	GX-G9910
Movement Type	Automatic Mechanical (21 Rubies)
Case Diameter	41mm (1.61 inches)
Case Thickness	13mm
Strap Material	Stainless Steel
Strap Width	20mm
Water Resistance	3ATM (30 meters / 98 feet) - Splash/Rain Resistant
Power Reserve	Over 45 hours
Clasp Type	Push Button Hidden Clasp
Special Features	Skeleton Design, Multi-Calendar (Date, Day, Month), Luminous Hands/Markers

Warranty and Support

OLEVS provides a **2-year product quality guarantee** for this watch. If you encounter any issues or have questions regarding your OLEVS watch, please contact OLEVS customer support through the platform where you purchased the product. Please retain your proof of purchase for warranty claims.
For additional support or to explore other OLEVS products, you may visit the official OLEVS store page OLEVS Store.

© 2023 OLEVS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question