

[Manuals.plus](#) /

› [MAIDeSiTe](#) /

› MAIDeSiTe Electric Chair Lift User Manual

MAIDeSiTe JC35M3

MAIDeSiTe Electric Chair Lift User Manual

Model: JC35M3 | Brand: MAIDeSiTe

1. INTRODUCTION AND PRODUCT OVERVIEW

The MAIDeSiTe Electric Chair Lift is designed to provide effortless standing assistance, promoting independence for individuals with limited mobility. This device helps users transition safely from a seated position on the floor or low surfaces to a standing position, reducing strain on both the user and caregivers.



Figure 1.1: The MAIDeSITe Electric Chair Lift, showcasing its compact and functional design.

Electric Chair Lift

 **Maidesite**



**User-
friendly**



**300LBS
Capacity**




**Foldable
Storage**



**Comfortable
Design**



Figure 1.2: Overview of the Electric Chair Lift's key features: user-friendly operation, 300 lbs capacity, foldable design for storage, and comfortable use.





Before



After

Figure 1.4: Visual comparison highlighting the chair lift's role in preventing falls and assisting recovery from a seated position.


Safe and Smooth Lifting

Effortless movement between chair lift and other devices

Where to use



Sofa




Bed




Car

Who needs to use



Elderly



Postoperative



Caregivers

Figure 1.5: The chair lift provides safe and smooth lifting, adaptable for use with sofas, beds, or cars, and beneficial for the elderly, postoperative patients, and caregivers.

2. SETUP GUIDE

Before first use, ensure all components are present and undamaged. The chair lift comes pre-assembled for ease of setup.

2.1 What's Included




Figure 2.1: Included components: (1) Lift Chair, (2) Remote Control, (3) Charger, (4) Suction Cups, (5) User Manual.

2.2 Initial Placement and Stability

Place the chair lift on a flat, stable surface. The unit features stable suction support for various household surfaces.

Stable Suction Support

Suitable for common household surfaces



Bathtub



Carpet



Floor

Figure 2.2: The stable suction cups provide secure placement on surfaces such as bathtubs, carpets, and floors.

2.3 Charging the Remote Control

Connect the charger to the remote control. The indicator light will show red while charging and green when fully charged. The controller can remain continuously connected to the charger; it will automatically power off when fully charged.

3. OPERATING INSTRUCTIONS

The MAIDeSiTe Electric Chair Lift is operated using a user-friendly cordless remote control with large, intuitive buttons.

3.1 Basic Operation

1. **Positioning:** Position the chair lift next to the device or surface you wish to transfer from (e.g., sofa, bed, floor).
2. **Adjusting Height:** Use the 'Up' and 'Down' buttons on the remote control to adjust the chair lift's height to match your desired transfer level.
3. **Transfer:** Once at the appropriate height, safely transfer from the chair lift to your destination.



Position the Chair Lift

Position the chair lift next to the device currently used.



Adjust the Chair Lift's Height

Adjust the height of the chair lift to match the sofa.



Transfer

Safely transfer from the chair lift to sofa.

Figure 3.1: Step-by-step guide for using the chair lift: Position, Adjust Height, and Transfer.

3.2 Remote Control Functions

The remote control features dedicated buttons for precise control:

- **Up Button:** Raises the chair lift.
- **Down Button:** Lowers the chair lift.
- **Emergency Stop Button:** Immediately halts all movement for safety.

Powerful Waterproof Motor



Figure 3.2: The remote control provides simple and direct commands for lift operation, powered by a robust motor.

4. MAINTENANCE

Proper maintenance ensures the longevity and safe operation of your MAIDeSiTe Electric Chair Lift.

4.1 Cleaning Instructions

Wipe clean the surfaces of the chair lift with a damp cloth. Avoid using abrasive cleaners or harsh chemicals that could damage the materials.

4.2 Battery Care

Ensure the remote control's battery is regularly charged. While it can remain connected to the charger, avoid prolonged periods of complete discharge to maintain battery health.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with your chair lift.

5.1 Common Issues and Solutions

Problem	Possible Cause	Solution
Chair lift does not move.	Remote control battery is low or dead.	Charge the remote control. Observe the indicator light.
Chair lift stops unexpectedly.	Emergency stop button activated.	Release the emergency stop button.
Unstable during use.	Not placed on a flat surface; suction cups not engaged.	Ensure the chair lift is on a flat, stable surface and suction cups are properly engaged.
Exceeding weight limit.	User weight exceeds 300 lbs.	Do not exceed the maximum weight limit of 300 lbs.

If the issue persists after attempting these solutions, please contact customer support.

6. PRODUCT SPECIFICATIONS

Detailed specifications for the MAIDeSITe Electric Chair Lift (Model JC35M3).

Details



Figure 6.1: Key dimensions and weight capacity of the MAIDeSiTe Electric Chair Lift.

Feature	Detail
Brand	MAIDeSiTe
Model Name	Charles (JC35M3)
Color	Blue
Product Dimensions	30.7"D x 18.9"W x 12.2"H
Maximum Weight Recommendation	300 Pounds

Feature	Detail
Special Feature	Foldable
Product Care Instructions	Wipe Clean
Included Components	Charger, Controller
Item Weight	30 pounds
Batteries	1 Lithium Metal battery required (included)
Seat Height	20 Inches
Indoor/Outdoor Usage	Indoor

7. WARRANTY AND SUPPORT

MAIDeSITe is committed to providing reliable products and excellent customer service.

7.1 Product Warranty

The MAIDeSITe Electric Chair Lift comes with a **1-year warranty** covering the motor, electronics, and frame. This warranty ensures peace of mind regarding the product's durability and performance.

7.2 Customer Support

For any setup assistance, questions, or concerns, a **24/7 US-based care specialist hotline** is available. Please refer to the contact information provided in your product packaging or on the official MAIDeSITe website for support details.

If you are not fully satisfied, the product is eligible for hassle-free 30-day returns.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question