

## VINABTY KK-Y098A

# VINABTY KK-Y098A Replacement Remote Control User Manual

For Konka LCD LED TV Models KK-Y098B, KK-Y098D, KK-Y098E, KK-Y098G, KK-LED32

## INTRODUCTION

This user manual provides detailed instructions for the VINABTY KK-Y098A replacement remote control. This remote is designed to function as a direct replacement for various Konka LCD LED TV models, offering seamless operation without the need for complex programming. Please read this manual thoroughly to understand the features and ensure proper use of your new remote control.

## 1. SETUP

### 1.1 Battery Installation

The VINABTY KK-Y098A remote control requires two AAA batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Figure 1: Back view of the remote control with the battery compartment.

## 1.2 Initial Use

This replacement remote control is designed for immediate use with compatible Konka LCD LED TVs. No programming or setup is required. Once the batteries are correctly installed, the remote is ready to operate your television.

## 2. OPERATING INSTRUCTIONS

The VINABTY KK-Y098A remote control features a standard layout for easy navigation and control of your Konka TV. Below is a general overview of the buttons and their functions:





Figure 2: Front view of the remote control with key functions.

- **POWER (●)**: Turns the TV on or off.
- **INPUT**: Selects the input source (e.g., HDMI, AV, TV).
- **S.MODE / P.MODE**: Sound Mode / Picture Mode selection.
- **FREEZE / SLEEP**: Freezes the current image / Sets a sleep timer.
- **Number Buttons (0-9)**: Directly selects channels.
- **-/-- / INFO**: Toggles between two-digit and three-digit channel numbers / Displays on-screen information.
- **VOL (+/-)**: Adjusts the volume level.
- **PROG (▲/▼)**: Changes TV channels up or down.
- **MUTE (✖)**: Mutes or unmutes the TV sound.
- **MENU / EXIT**: Accesses the TV's main menu / Exits the current menu or function.
- **Navigation Buttons (▲/▼/◀/▶)**: Navigates through menu options.
- **ENTER**: Confirms a selection in the menu.
- **TTX / NICAM**: Teletext function / NICAM stereo sound selection.
- **Playback Controls (◀◀, ▶▶, ■, ▶)**: Used for media playback (e.g., fast forward, rewind, stop, play).
- **Colored Buttons (INDEX, HOLD, REVEAL, SUBPAGE, SUBTITLE, CANCEL, MIX, ZOOM)**  
Provides access to specific functions, often related to teletext or advanced TV features. Refer to your Konka TV's original manual for specific uses.

### 3. TROUBLESHOOTING

If you encounter issues with your VINABTY KK-Y098A remote control, please refer to the following common troubleshooting steps:

- **Remote Not Responding:**
  - Ensure the batteries are correctly installed with the proper polarity (+/-).
  - Replace old or depleted batteries with fresh AAA batteries.
  - Check for any obstructions between the remote control and the TV's infrared sensor.
  - Ensure you are within the effective range and pointing the remote directly at the TV.
- **Limited Functionality:**
  - Verify that your Konka TV model is listed as compatible with the KK-Y098A remote (e.g., KK-Y098B, KK-Y098D, KK-Y098E, KK-Y098G, KK-LED32).
  - Some advanced features may require specific TV settings or may not be supported by all

Konka TV models. Consult your TV's original manual for details.

- **Buttons Not Working:**

- Clean the remote control buttons and surface with a soft, dry cloth to remove any dirt or residue that might be interfering with button presses.

## 4. SPECIFICATIONS

Feature	Detail
Model	KK-Y098A
Brand	VINABTY
Compatible TV Models	Konka LCD LED TV (KK-Y098B, KK-Y098D, KK-Y098E, KK-Y098G, KK-LED32)
Battery Type	2 x AAA (not included)
Dimensions	7.9 x 2 x 0.7 inches
Item Weight	2.39 ounces
Manufacturer	Xinhao

## 5. WARRANTY AND SUPPORT

Specific warranty information for the VINABTY KK-Y098A replacement remote control is not provided in this manual. For warranty details or technical support, please refer to the product packaging or contact the retailer where the product was purchased.