

FONESTAR MSHT-17

FONESTAR MSHT-17 VHF Wireless Lapel Microphone User Manual

Model: MSHT-17

[Introduction](#) | [Safety](#) | [Contents](#) | [Overview](#) | [Setup](#) | [Operation](#) | [Maintenance](#) | [Troubleshooting](#) | [Specifications](#) | [Warranty & Support](#)

1. INTRODUCTION

Thank you for choosing the FONESTAR MSHT-17 VHF Wireless Lapel Microphone. This manual provides essential information for the correct installation, operation, and maintenance of your wireless microphone system. Please read this manual thoroughly before using the product to ensure optimal performance and safety.

2. SAFETY INFORMATION

Please observe the following safety precautions to prevent damage to the device and ensure user safety:

- Do not expose the device to rain, moisture, or extreme temperatures.
- Avoid dropping or subjecting the device to strong impacts.
- Do not attempt to open or repair the device yourself. Refer all servicing to qualified personnel.
- Keep the device away from sources of heat and direct sunlight.
- Use only the power supply specified for this device.

3. PACKAGE CONTENTS

Carefully unpack the box and ensure all items are present and in good condition. The package should contain:

- FONESTAR MSHT-17 VHF Wireless Lapel Microphone (Transmitter and Receiver)
- Computer recording and processing accessories
- User Manual

4. PRODUCT OVERVIEW

The FONESTAR MSHT-17 is a compact VHF wireless lapel microphone system designed for various applications including singing, karaoke, streaming, videoconferencing, and gaming. It offers reliable wireless connectivity for clear audio transmission.



Image showing the FONESTAR MSHT-17 VHF Wireless Lapel Microphone, typically including the lapel microphone, transmitter, and receiver.

5. SETUP INSTRUCTIONS

1. **Power Supply:** Connect the receiver unit to a suitable power source using the provided electric cable. Ensure the power indicator light illuminates.
2. **Connect to Audio System:** Use an XLR cable to connect the receiver's output to your mixer, amplifier, computer, or other compatible audio input device.
3. **Transmitter Power:** Insert the required batteries (not specified, assume standard AA/AAA) into the lapel microphone transmitter. Turn on the transmitter.
4. **Pairing (if applicable):** The system should automatically pair. If not, refer to specific pairing instructions in the full manual (if provided separately). Ensure the receiver's signal indicator shows a stable connection.
5. **Positioning:** Clip the lapel microphone to your clothing, approximately 15-30 cm (6-12 inches) from your mouth, for optimal sound capture.

6. OPERATING INSTRUCTIONS

1. **Power On:** Turn on the receiver first, then the transmitter.
2. **Volume Adjustment:** Adjust the volume on your connected audio system (mixer, amplifier) to a suitable level. Start with a low volume and gradually increase it to avoid feedback or distortion.
3. **Testing:** Speak into the microphone to test the audio output. Monitor the sound quality and adjust settings as

needed.

4. **Power Off:** When finished, turn off the transmitter first, then the receiver. This helps prevent pops or clicks through your audio system.

Helpful Videos

Video demonstrating a general overview or setup process for a wireless microphone system.

Video illustrating connection steps for a wireless microphone to an audio device.

Video showcasing the microphone in use for a performance or recording scenario.

Video providing tips for optimizing sound quality with the wireless microphone.

Short video clip demonstrating a specific feature or quick setup step.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the microphone and receiver. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the microphone system in a dry, cool place, away from direct sunlight and extreme temperatures.
- **Battery Replacement:** Replace batteries in the transmitter when the low battery indicator appears or when performance degrades.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound output	Microphone or receiver not powered on; incorrect cable connection; low transmitter battery.	Ensure all units are powered on. Check all cable connections. Replace transmitter batteries.
Poor sound quality / Static	Interference from other wireless devices; transmitter too far from receiver; low transmitter battery.	Move away from other wireless devices. Reduce distance between transmitter and receiver. Replace transmitter batteries.
Feedback (howling sound)	Microphone too close to speakers; volume too high.	Increase distance between microphone and speakers. Reduce volume on your audio system.

9. SPECIFICATIONS

Brand	FONESTAR
Model Name	VHF Wireless Lapel Microphone
Product Model Number	MSHT-17
Connectivity Technology	XLR
Connector Type	XLR
Special Feature	Wireless

Compatible Devices	Personal Computer, Video Game Console
Recommended Uses	Singing, Karaoke, Streaming, Videoconferencing, Gaming
Color	MULTICOLOR
Microphone Form Factor	Lapel
Power Supply	Electric Cable
Material	Metal, Plastic
Number of Channels	1
Package Dimensions	10 x 6.6 x 2.4 cm
Product Weight	100 g

10. WARRANTY AND SUPPORT

FONESTAR products are manufactured with high-quality materials and undergo strict quality control. For warranty information, please refer to the warranty card included with your purchase or contact your local dealer. For technical support or service inquiries, please contact FONESTAR customer service through their official website or the contact information provided with your product.

© 2023 FONESTAR. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09JGDC4WY>

More documents and user manuals: <https://manuals.plus/>