

[manuals.plus](#) /› [KitchenAid](#) /› [KitchenAid KQ913 Digital Waterproof Kitchen and Food Scale User Manual](#)

## KitchenAid KQ913

# KitchenAid KQ913 Digital Waterproof Kitchen and Food Scale User Manual

Model: KQ913 | Brand: KitchenAid

## 1. INTRODUCTION

The KitchenAid KQ913 Digital Waterproof Scale is designed for precise measurement of both dry and liquid ingredients, making kitchen tasks simpler and more accurate. Its durable tempered glass top and IPX7 waterproof rating ensure easy cleaning and longevity. Featuring touch-sensor buttons, a bright LED readout, and convenient TARE and HOLD functions, this scale is an essential tool for any kitchen.

### Key Features:

- **IPX7 Waterproof Rating:** Allows for easy cleanup by rinsing under water.
- **High Capacity:** Measures up to 11 lbs (5000g) for dry ingredients and 176 fl oz (5000ml) for liquids.
- **Touch-Sensor Buttons:** Prevents accumulation of kitchen dust and food particles, ensuring easy wiping.
- **Bright LED Readout:** Provides clear and quick viewing of measurements.
- **HOLD Feature:** Locks the last recorded weight on the display, even after the item is removed.
- **TARE Function:** Allows for zeroing out the weight of containers or adding multiple ingredients in the same container.
- **Auto Shut-off:** Conserves battery life.



Image: The KitchenAid KQ913 Digital Waterproof Kitchen and Food Scale, showcasing its sleek white design and LED display.

## 2. WHAT'S IN THE BOX

Your KitchenAid KQ913 Digital Waterproof Kitchen and Food Scale package includes:

- 1 x Digital Kitchen Scale
- 3 x AAA Batteries (pre-installed or included separately)

## 3. SETUP

### Battery Installation

1. Turn the scale upside down to locate the battery compartment on the underside.
2. Using a small Phillips head screwdriver, unscrew the four screws securing the battery compartment cover.

3. Remove the cover.
4. Insert 3 AAA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
5. Replace the battery compartment cover and securely fasten the four screws.



Image: The underside of the KitchenAid KQ913 scale, highlighting the battery compartment secured by four screws.

## 4. OPERATING INSTRUCTIONS

### Power On/Off

- To turn on: Press the **Power ( )** button. The LED display will illuminate and show "0.0" when ready.
- To turn off: Press and hold the **Power ( )** button for a few seconds until the display turns off. The scale also features an auto shut-off function to conserve battery life.

### Changing Units

- With the scale on, press the **Unit** button ( icon) to cycle through available measurement units: grams (g),

milliliters (ml), pounds and ounces (lb:oz), and fluid ounces (fl oz).

## Tare Function

The TARE function allows you to weigh multiple ingredients in the same container or to exclude the weight of a container.

1. Place an empty container on the scale. The display will show its weight.
2. Press the **Tare** button (☒ icon). The display will reset to "0.0".
3. Add your first ingredient. The display will show only the weight of the ingredient.
4. To add another ingredient, press the **Tare** button again to reset the display to "0.0", then add the next ingredient. Repeat as needed.

## Hold Function

The HOLD feature allows you to lock the displayed weight, even after the item is removed from the scale.

- Place the item to be weighed on the scale.
- Once the weight stabilizes, press the **Hold** button. The displayed weight will be locked.
- You can now remove the item, and the weight will remain visible on the display. Press the **Hold** button again to clear the display or turn the scale off.



Image: The KitchenAid KQ913 scale in use, accurately weighing food items on its tempered glass surface.

Video: Official demonstration of the KitchenAid Digital Waterproof Scale, showing its features including power on, unit conversion, and tare function.

## 5. MAINTENANCE AND CLEANING

Thanks to its IPX7 waterproof rating, cleaning your KitchenAid KQ913 scale is simple.

- For general cleaning, wipe the surface with a damp cloth and mild detergent.
- For thorough cleaning, the scale can be rinsed under running water. Ensure the battery compartment is securely closed before rinsing.
- Do not immerse the scale in water for extended periods.
- Avoid using abrasive cleaners or scouring pads, as these can damage the glass surface.
- Dry the scale completely after cleaning before storage.



Image: A hand cleaning the KitchenAid KQ913 scale with a sponge, demonstrating its easy-to-clean waterproof design.

## 6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Scale does not turn on	Dead or incorrectly installed batteries.	Check battery polarity. Replace with new AAA batteries.
Inaccurate readings	Scale not on a flat, stable surface; item exceeding max capacity; scale needs recalibration.	Place scale on a hard, level surface. Ensure weight is within 11 lbs / 5000g. Turn off and on again to reset.
Display shows "Err" or random numbers	Overload; internal error.	Remove item immediately if overloaded. Turn off and on again. If issue persists, contact customer support.

Problem	Possible Cause	Solution
Auto shut-off too quickly/slowly	Normal operation (approx. 3 minutes inactivity).	This feature is fixed to conserve battery life and cannot be adjusted.

## 7. SPECIFICATIONS

Feature	Detail
Product Dimensions	7.09 x 9.06 x 0.98 inches
Item Model Number	KQ913
Weight Limit	11 Pounds (5000g)
Measurement Units	g, ml, lb:oz, fl oz
Waterproof Rating	IPX7
Power Source	3 x AAA Batteries
Manufacturer	Lifetime Brands Inc.
Country of Origin	China




Image: The KitchenAid KQ913 scale with its dimensions (7.09" x 9.06" x 0.98") clearly indicated.

## 8. WARRANTY AND SUPPORT

KitchenAid products are warranted to be free from defects in material and workmanship. For one year from the date of purchase, under normal use and care, KitchenAid will replace this product free of charge, if it is found to be defective in material or workmanship. In addition, from year two through the life of this product, any product found to be defective under conditions of normal use and care will be repaired at no charge or replaced with the same item or an item of equal or better value. See packaging for more information.

For further assistance or to explore more KitchenAid products, please visit the [KitchenAid Store](#).

© 2025 KitchenAid. All rights reserved. Used under license.

### Related Documents - KQ913

 <b>KitchenAid</b> Stand Mixer Attachment SKSMMGA	<p><a href="#">KitchenAid 5KSMMGA Stand Mixer Attachment: Use, Care, and Guarantee Guide</a></p> <p>Comprehensive guide for the KitchenAid 5KSMMGA Stand Mixer Attachment, covering parts, assembly, usage, safety, care, cleaning, and warranty information. Learn how to use your food grinder and sausage stuffer attachments effectively.</p>
 <b>KitchenAid</b> Food Processor 5KFP0921E 5KFP0921B	<p><a href="#">KitchenAid Food Processor 5KFP0921E/5KFP0921B Use and Care Manual</a></p> <p>User manual for KitchenAid Food Processor models 5KFP0921E and 5KFP0921B. Covers safety, parts, assembly, operation, cleaning, troubleshooting, and warranty. Find instructions for preparing various foods with this versatile kitchen appliance.</p>
 <b>KitchenAid</b> Food Processor 5KFP0719	<p><a href="#">KitchenAid 5KFP0719 Food Processor: User Manual, Safety, and Operation Guide</a></p> <p>Find detailed instructions for your KitchenAid 5KFP0719 Food Processor, including safety precautions, assembly, usage, cleaning, troubleshooting, and warranty information.</p>
 <b>KitchenAid</b> KFC3516	<p><a href="#">KitchenAid KFC3516 Mini Food Processor User Manual and Safety Guide</a></p> <p>Comprehensive user manual for the KitchenAid KFC3516 Mini Food Processor, covering parts, features, safety instructions, assembly, operation, care, cleaning, troubleshooting, and warranty information.</p>

**KitchenAid**13 CUP FOOD PROCESSORS  
SKFP1318\*, SKFP1319\*  
OWNER'S MANUAL

DE	Einleitung & Hinweise	3
DE	Reparaturanleitung	28
FR	Le manuel d'utilisation	28
IT	Manuale di istruzione	28
NL	Geführer anbringen	40
ES	El manual del procesador	40
PT	O manual do processador	40
DE	Wichtige Sicherheitshinweise	71
ES	Importante información de seguridad	71
IT	Informazioni sulla sicurezza	71
NL	Belangrijke veiligheidsvoorschriften	71
DA	Brugervejledning	122
DE	Wichtiges Sicherheitsinformation	122
FR	Instructions de sécurité	122
PL	Informacje o bezpieczeństwie	122
ES	Información de seguridad	122
IT	Informazioni sulla sicurezza	122
NL	Belangrijke veiligheidsvoorschriften	122
DE	Einleitung	1

W10177951A

[Manuale del Proprietario per Food Processor KitchenAid 13 tazze \(5KFP1318\\*, 5KFP1319\\*\)](#)

Guida completa per l'uso, la sicurezza, l'assemblaggio e la manutenzione dei food processor KitchenAid da 13 tazze, modelli 5KFP1318\* e 5KFP1319\*. Scopri come utilizzare gli accessori e mantenere al meglio il tuo elettrodomestico.

**KITCHENAID** 730-0953A  
Owner's ManualShop genuine replacement parts for KITCHENAID  
730-0953A

First Year KITCHENAID Grill Parts - Select From 200 Models

---- Manual continues below ----

[KitchenAid 730-0953A Freestanding Outdoor Grill Owner's Manual & Installation Guide](#)

Comprehensive owner's manual and installation guide for the KitchenAid 730-0953A freestanding outdoor grill, covering safety, assembly, usage, care, and troubleshooting.