LuvLink 9359247000078

LuvLink Digital Photo Frame Instruction Manual

Model: 9359247000078

Brand: LuvLink

Introduction

This manual provides detailed instructions for setting up, operating, and maintaining your LuvLink Digital Photo Frame. This device allows you to share and display photos and short videos with loved ones from anywhere using the Frameo app.



Image: The LuvLink Digital Photo Frame in white, showcasing a heartwarming family moment.

Package Contents

Please ensure all items are present in the package:

- LuvLink Digital Photo Frame (10-inch)
- Power Adapter
- Detachable Stand
- User Manual (this document)

Setup Guide

1. Physical Setup

1. **Attach the Stand:** Insert the detachable stand into the slot on the back of the frame. The frame can be positioned in either landscape or portrait orientation.
2. **Power Connection:** Connect the power adapter to the DC Power port on the back of the frame and plug it into a wall outlet. The frame will automatically power on.




Image: Rear view of the digital photo frame, highlighting the Micro USB, Micro SD, DC Power ports, and the stand attachment point.

2. Initial Configuration

3. **Language Selection:** Follow the on-screen prompts to select your preferred language.
4. **Wi-Fi Connection:** Select your Wi-Fi network from the list and enter the password. Ensure a stable internet connection for optimal performance.

3. Frameo App Setup

5. **Download the App:** Download the "Frameo" app from the App Store (iOS) or Google Play Store (Android) on your smartphone or tablet.



Image: A smartphone screen showing the Frameo app available for download on Android and iOS platforms.

6. **Create Account:** Open the Frameo app and create a new user profile.



Image: A smartphone screen displaying the Frameo app's profile setup interface.

7. **Connect to Frame:** On your LuvLink Digital Photo Frame, navigate to the "Add Friend" section to obtain a unique 6-digit code. Enter this code into the Frameo app on your device to link your frame.



Image: A smartphone screen showing the Frameo app with a prompt to enter the unique frame code.

Operating Instructions

1. Sending Photos and Videos

Once your frame is connected to the Frameo app, you can easily send photos and short videos:

1. Open the Frameo app on your smartphone.
2. Select the photos or videos you wish to send from your gallery.
3. Choose the recipient frame(s) and add an optional caption.
4. Tap "Send" to instantly transfer the media to the connected frame(s).



Image: A three-panel image illustrating the process of sending photos via the Frameo app: selecting photos, choosing recipients, and adding a caption.

2. Viewing Photos and Videos

The frame will automatically display received photos and videos in a slideshow. You can interact with the display:

- **Swipe:** Swipe left or right on the touchscreen to manually navigate through photos.
- **Gallery View:** Tap the screen to reveal options, then select "Gallery" to view all stored photos in a grid format.
- **React:** Double-tap a photo to send a reaction (e.g., a heart emoji) back to the sender.



Image: The digital photo frame displaying a family photo, with a smartphone showing the Frameo app's gallery interface.

3. Display Settings

Customize your viewing experience:

- **Auto-Rotate:** The frame automatically adjusts photo orientation based on its physical position (landscape or portrait).




Image: Two digital photo frames illustrating the auto-rotate function, showing the same image adjusted for both portrait and landscape orientations.

- **Fill Frame:** Access settings to choose how images are displayed (e.g., fill the screen, show original aspect ratio).
- **Brightness:** Adjust screen brightness through the settings menu.
- **Sleep Mode:** Configure sleep schedules to automatically turn off the display during specific hours.

4. Media Integration

In addition to the Frameo app, you can use local storage:

- **Micro SD Card:** Insert a Micro SD card into the designated slot to display photos and videos stored on it.
- **Micro USB:** Connect a USB drive via the Micro USB port to access media files.

5. Official Product Video

Your browser does not support the video tag.

Video: An official product video demonstrating the LuvLink Digital Photo Frame's features, including how to send photos from a smartphone and display them on the frame.

Maintenance

To ensure the longevity and optimal performance of your LuvLink Digital Photo Frame:

- **Cleaning:** Gently wipe the screen with a soft, dry, lint-free cloth. Avoid using harsh chemicals or abrasive materials.
- **Software Updates:** The frame may receive periodic software updates. Ensure your frame is connected to Wi-Fi to receive and install these updates, which can improve performance and add new features.
- **Placement:** Place the frame on a stable surface away from direct sunlight, excessive heat, or moisture.

Troubleshooting

If you encounter issues with your LuvLink Digital Photo Frame, refer to the following common solutions:

Problem	Solution
Frame does not power on	Ensure the power adapter is securely connected to both the frame and a working power outlet. Try a different outlet.
Cannot connect to Wi-Fi	Verify your Wi-Fi password. Ensure the frame is within range of your router. Restart your router and the frame.
Photos are not appearing on the frame	Check if the frame is connected to Wi-Fi. Confirm that photos were successfully sent via the Frameo app. Ensure the frame is linked to your Frameo account.
Screen is unresponsive	Restart the frame by unplugging and re-plugging the power adapter. If the issue persists, perform a factory reset (refer to the frame's settings menu).
Images appear stretched or cropped	Adjust the "Fill Frame" setting in the frame's display options to your preference.

Specifications

- **Screen Size:** 10.1 Inches
- **Resolution:** 1280 x 800
- **Internal Storage:** 16 GB
- **Connectivity:** Wi-Fi
- **Control Method:** Touchscreen
- **Aspect Ratio:** 16:9
- **Supported Image Formats:** JPG, JPEG, BPM, PNG
- **Supported Video Formats:** MP4
- **Power Source:** AC
- **Frame Material:** Plastic



Image: The digital photo frame with an overlay of icons and text detailing its main features and specifications.

Warranty and Support

Your LuvLink Digital Photo Frame comes with a**12-month warranty** from the date of purchase. LuvLink also provides lifetime support for this product.

For technical assistance, troubleshooting, or warranty claims, please contact LuvLink customer support through the official website or the contact information provided in your purchase documentation.

© 2024 LuvLink. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question