



Manuals.plus /

› Transwon /

› Transwon Kids Case Cover for 8-inch Cloud Mobile Sunshine T1 Elite/Sunshine T1/Xmobile X8Max/X8Pro/X8 Tablet - Instruction Manual

Transwon Kids Case Cover for 8 Inch Cloud Mobile Sunshine T1 Elite Tablet/Sunshine T1 Tablet/Xmobile X8Max/ X8Pro/ X8 Tablet

Transwon Kids Case Cover for 8-inch Cloud Mobile Sunshine T1 Elite/Sunshine T1/Xmobile X8Max/X8Pro/X8 Tablet - Instruction Manual

Comprehensive guide for the installation, features, and maintenance of your Transwon Kids Case Cover.

1. INTRODUCTION

Thank you for choosing the Transwon Kids Case Cover. This manual provides essential information for the proper use and care of your new tablet case. Designed for durability and functionality, this case offers robust protection and enhanced usability for compatible 8-inch tablets.

1.1. Compatibility

This case is specifically designed for the following 8-inch tablet models:

- Cloud Mobile Sunshine T1 Elite Tablet
- Cloud Mobile Sunshine T1 Tablet
- Xmobile X8Max Tablet
- Xmobile X8Pro Tablet
- Xmobile X8 Tablet

Please ensure your tablet model matches one of the listed devices for optimal fit and protection. This case is not compatible with other tablet models.

2. KEY FEATURES

The Transwon Kids Case Cover is engineered with several features to enhance your tablet experience and provide superior protection:

- **Precise Cut-outs:** Full access to all controls, ports, and features without removing the case.

- **Built-in Stand Function:** Provides multiple viewing angles for watching videos, texting, gaming, or learning.
- **Impact-Resistant Material:** Constructed from rubber-like silicone material with raised corners for drop protection and impact-resistance.
- **Foldable Kickstand:** Easy to open and close, offering versatile positioning.



This image displays the Transwon Kids Case Cover in blue, featuring a tablet securely fitted within. The case is designed with reinforced corners for protection and includes a built-in kickstand, shown in an extended position, allowing for hands-free viewing.

3. SETUP AND INSTALLATION

Follow these steps to properly install your tablet into the Transwon Kids Case Cover:

1. **Prepare the Case:** Gently remove any packaging inserts or foam from inside the case.
2. **Align the Tablet:** Carefully align your 8-inch tablet with the case, ensuring the camera, ports, and buttons match the corresponding cut-outs on the case.
3. **Insert the Tablet:** Start by inserting one side of the tablet into the case, then gently press the other sides until the tablet is fully seated and secured within the silicone frame. Ensure all corners are properly covered by the case's protective edges.
4. **Check Fit:** Verify that the tablet is snug and all cut-outs are accessible. The case should not obstruct any functionality.

3.1. Visual Installation Guide

Your browser does not support the video tag.


This video demonstrates the installation process of a tablet into a similar protective case, showing how to correctly align and secure the device. It also highlights the case's features, such as the integrated stand and secure closure mechanism.

4. OPERATING INSTRUCTIONS

4.1. Using the Built-in Kickstand

The case features a foldable kickstand for convenient hands-free viewing. To use the kickstand, gently pull it out from the back of the case until it locks into position. Adjust the tablet's angle by positioning the kickstand in one of the available grooves. Ensure the kickstand is fully extended and stable before releasing the tablet.

HOW TO USE THE KICKSTAND?



This diagram provides visual guidance on how to properly utilize the integrated kickstand. It shows the correct angle for stable tablet support and an incorrect, unstable angle to avoid.

4.2. Accessing Ports and Buttons

The precise cut-outs ensure that all tablet ports (charging, headphone jack) and buttons (power, volume) remain fully accessible and functional while the case is installed. No need to remove the case for charging or using accessories.

5. CARE AND MAINTENANCE

To keep your Transwon Kids Case Cover in optimal condition:

- **Cleaning:** The premium silicone rubber material allows for easy cleaning. If the product gets dirty during use, it can be washed directly with water. Allow it to air dry completely before re-installing your tablet.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners or harsh chemicals, as these may damage the material.
- **Storage:** When not in use, store the case in a cool, dry place away from direct sunlight.

6. TROUBLESHOOTING

If you encounter any issues with your Transwon Kids Case Cover, please consider the following:

- **Case Not Fitting:** Double-check that your tablet model is listed under the compatible devices in Section 1.1. Ensure the tablet is inserted correctly and all corners are properly aligned.
- **Kickstand Issues:** Ensure the kickstand is fully extended and locked into place for stability. If it feels loose, inspect for any obstructions.
- **Access to Ports/Buttons:** Confirm that the tablet is correctly seated within the case, as misalignment can sometimes obstruct access.

For further assistance, please refer to the Warranty and Support section.

7. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Transwon
Compatible Devices	Cloud Mobile Sunshine T1 Elite Tablet, Sunshine T1 Tablet, Xmobile X8Max, X8Pro, X8 Tablet (8-inch models)
Material	Impact-resistant rubber-like silicone
Form Factor	Case
Special Features	Heavy Duty Protection, Built-in Foldable Kickstand
Item Weight	5.6 ounces
Package Dimensions	10.08 x 7.48 x 0.87 inches

8. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Transwon Kids Case Cover, please contact Transwon customer service. While specific warranty details are not provided in this manual, Transwon is committed to customer satisfaction.

You can visit the official Transwon store for more information and contact options: [Transwon Store on Amazon](#).

