Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- mompush /
- Mompush Lithe Double Stroller (Model MP310) Instruction Manual

mompush MP310

Mompush Lithe Double Stroller (Model MP310) Instruction Manual

Comprehensive guide for the safe and effective use of your Mompush Lithe Double Stroller.

1. Introduction

Thank you for choosing the Mompush Lithe Double Stroller. This lightweight, side-by-side stroller is designed for convenience and comfort, accommodating two children from newborn to toddler age. It features spacious seats with independent recline, UPF50+ canopies, and an easy-fold mechanism. Please read this manual carefully to ensure proper assembly, safe operation, and optimal maintenance of your stroller.



Image 1.1: The Mompush Lithe Double Stroller in black, showcasing its side-by-side design and sleek appearance.

2. SAFETY INFORMATION

Your child's safety is paramount. Always adhere to the following safety guidelines:

- Never leave children unattended in the stroller.
- Always use the **5-point safety harness** for each child. Ensure it is properly adjusted and secured.
- Engage the **one-step foot brake** whenever the stroller is stationary.
- Do not exceed the maximum weight recommendation of 40 lbs (18.1 kg) per seat (80 lbs total).
- Ensure the stroller is fully open and locked before placing children inside.
- Keep children clear of moving parts when folding or unfolding the stroller.
- Do not hang bags or items on the handlebar as this can cause the stroller to tip.
- This stroller is suitable for children from 6 to 36 months.

The Mompush Lithe Double Stroller meets **JPMA** and **OEKO-TEX Standard** certifications, ensuring product safety and quality.

3. PACKAGE CONTENTS

Verify that all components are present upon unpacking:

- Stroller Frame with attached seats and canopies
- Wheels (front and rear)
- Cup Holder
- · Rain Cover
- · Instruction Manual

4. SETUP AND ASSEMBLY

4.1 Unfolding the Stroller

- 1. Place the folded stroller on a flat surface.
- 2. Release the folding latch (if present).
- 3. Lift the handlebar firmly until the frame clicks into its fully open and locked position. Ensure both sides are securely locked.

4.2 Attaching the Wheels

- 1. Insert the front wheels into their respective sockets until they click securely.
- 2. Attach the rear wheels by pushing them onto the axle until they lock into place.

4.3 Attaching the Cup Holder

Slide the cup holder onto the designated attachment point on the handlebar until it is firmly secured.

mompush Lithe X2



Image 4.1: Overview of the Mompush Lithe X2 stroller with key features such as the full-grain leather handlebar, UPF 50+ canopy, adjustable recline, adjustable footrest, forever-air rubber tires, all-wheel suspension, and included rain cover highlighted.

5. OPERATING INSTRUCTIONS

5.1 Folding the Stroller

The Lithe Double Stroller features a compact, one-step fold:

- 1. Ensure both seats are in an upright position and canopies are retracted.
- 2. Locate the folding mechanism (refer to the specific location on your stroller frame, usually near the handlebar).
- 3. Activate the folding mechanism and push the handlebar downwards until the stroller collapses into its compact form.
- 4. Secure the folding latch to keep the stroller in its folded position.



Image 5.1: The Mompush Lithe Double Stroller folded compactly and stored in a car trunk, demonstrating its travel-friendly size.

5.2 Adjusting the Seat Recline

Each seat offers independent, multi-position recline up to 145 degrees:

- 1. Locate the recline adjustment lever or strap behind each seat.
- 2. To recline, squeeze the lever or loosen the strap and gently push the seat back.
- 3. To bring the seat upright, pull the lever or tighten the strap while pushing the seat forward.



Image 5.2: A side view of the Mompush Lithe Double Stroller seats illustrating the customizable recline positions, ranging from upright to a more relaxed 145-degree angle, with an adjustable footrest.

5.3 Adjusting the Footrest

The footrests are adjustable to provide comfort for growing children. Locate the adjustment buttons or levers on the sides of each footrest and adjust to the desired position.

5.4 Operating the UPF50+ Canopies

Each seat has an expandable UPF50+ canopy with a peek-a-boo window:

- To extend the canopy, pull it forward.
- To retract, push it back.
- Use the peek-a-boo window to check on your child without disturbing them.



Image 5.3: A close-up view of the Mompush Lithe Double Stroller's two large, expandable UPF 50+ canopies, each featuring a peeka-boo window for easy child monitoring.

5.5 Engaging the Brake System

The stroller is equipped with a responsive one-step foot brake. Press down firmly on the brake pedal, typically located near the rear wheels, until it locks. Ensure the stroller does not move before releasing your grip. To release, lift the pedal.

5.6 Utilizing Storage Baskets

The stroller includes two large storage baskets, each capable of holding up to 10 lbs (4.5 kg), for a total of 20 lbs (9 kg) capacity. Distribute weight evenly and do not overload the baskets.



Image 5.4: The rear view of the Mompush Lithe Double Stroller, highlighting its two spacious storage baskets, each designed to hold up to 10 lbs of items.

5.7 Using the Rain Cover

The included rain cover can be easily fitted over the stroller to protect your children from adverse weather conditions. Ensure it is securely attached and does not obstruct ventilation.



6. MAINTENANCE

6.1 Cleaning the Fabric

The stroller fabric is 100% polyester. Spot clean with a damp cloth and mild soap. Do not use harsh detergents or bleach. Allow to air dry completely before folding or storing.

6.2 Cleaning the Frame and Wheels

Wipe the aluminum frame with a soft, damp cloth. Clean the wheels regularly to remove dirt and debris. Lubricate moving parts periodically with a silicone-based lubricant to ensure smooth operation.

6.3 Storage

Store the stroller in a dry, cool place away from direct sunlight to prevent fabric fading and material degradation.

7. TROUBLESHOOTING

If you encounter issues with your Mompush Lithe Double Stroller, refer to the following common problems and solutions:

- Difficulty Folding/Unfolding: Ensure all seats are upright and the folding mechanism is fully engaged/disengaged. Check for any obstructions.
- Wheels Not Turning Smoothly: Clean wheels of any debris (hair, dirt). Lubricate axles if necessary.
- Brake Not Engaging: Check for obstructions around the brake mechanism. Ensure the pedal is fully depressed.
- Harness Issues: Ensure straps are not twisted and buckles are clean.

For further assistance, please contact Mompush customer support.

8. Specifications

Feature	Detail
Brand	mompush
Model Number	MP310
Color	Black
Frame Material	Aluminum
Fabric Type	100% Polyester
Age Range (Description)	6-36 months
Seating Capacity	2

Feature	Detail
Harness Type	5 Point
Maximum Weight Recommendation	40 lbs (18.1 kg) per seat
Item Weight	25.4 Pounds (11.5 kg)
Item Dimensions (L x W x H)	31"L x 30"W x 40.2"H (78.7cm L x 76.2cm W x 102.1cm H)
Folded Size (L x W x H)	32.3" L X 25.2" W X 9.6" H (82cm L x 64cm W x 24.4cm H)
Front Wheel Diameter	4.9 Inches (12.4 cm)
Back Wheel Diameter	5.5 Inches (14 cm)
Number of Cup Holders	1
Specification Met	JPMA, OEKO-TEX Standard

mompush[®]

Lithe X2 | Ultralight Stroller



Image 8.1: The Mompush Lithe Double Stroller with its key dimensions (height, depth, width) clearly labeled for reference.

9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or visit the official Mompush website. For any questions, concerns, or support needs regarding your Mompush Lithe Double Stroller, please contact Mompush customer service directly.

Manufacturer: MOMPUSH

You can find more information and contact details on the Mompush Brand Store.

© 2025 Mompush. All rights reserved.

Related Documents - MP310



Mompush Lithe V2 Stroller User Manual and Safety Information

Comprehensive guide for the Mompush Lithe V2 stroller, covering safety warnings, assembly instructions, cleaning, and warranty information. Learn how to use and maintain your stroller for optimal performance and child safety.



Mompush S3101-ND Compact Fold Double Stroller User Manual

Comprehensive guide for the Mompush S3101-ND Compact Fold Double Stroller, covering assembly, safety, operation, maintenance, and warranty information.



Mompush T3500 Lightweight Stroller User Manual and Safety Guide

Comprehensive user manual and safety guide for the Mompush T3500 lightweight stroller, covering assembly, operation, safety precautions, maintenance, and warranty information.



Mompush Nova Stroller User Manual and Safety Guide


Comprehensive user manual and safety guide for the Mompush Nova stroller, covering assembly, usage, cleaning, and warranty information. Ensure safe and optimal use of your stroller.





Mompush T629 Stroller: User Manual, Assembly, and Safety Guide

Official user manual for the Mompush T629 stroller. Find detailed instructions on assembly, bassinet mode, stroller mode, harness adjustment, safety warnings, folding, and care. Ensure safe and proper use of your Mompush T629 stroller.



Mompush Meteor Stroller User Manual and Safety Guide

Comprehensive user manual and safety guide for the Mompush Meteor stroller, covering assembly, usage, cleaning, and warranty information.