

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Yaheetech](#) /

› [Yaheetech 139 cm Pink Plush Multi-Level Cat Tree Instruction Manual](#)

Yaheetech 591852D

Yaheetech 139 cm Pink Plush Multi-Level Cat Tree Instruction Manual

INTRODUCTION

This manual provides instructions for the assembly, operation, and maintenance of your Yaheetech 139 cm Pink Plush Multi-Level Cat Tree. Please read these instructions carefully before assembly and use to ensure safe and proper operation. This cat tree offers multiple levels for climbing, scratching, playing, and resting, designed to enrich your cat's environment.

SAFETY INFORMATION

- Do not allow the cat tree to get wet. Exposure to moisture can damage the materials and compromise stability.
- Keep the cat tree away from open flames, heaters, and other heat sources to prevent fire hazards.
- Ensure the anti-tipping strap is securely fastened to a wall to prevent the cat tree from falling over, especially during vigorous play or if multiple cats are using it.
- Regularly check all connections and components for tightness and wear. Tighten any loose screws immediately.
- This cat tree is designed for kittens and small to medium-sized cats. While robust, it may not be suitable for very large or heavy cat breeds.
- Place the cat tree on a flat, stable surface to maximize stability.



Figure 1: Illustration of the anti-tipping strap installation for enhanced stability.

PACKAGE CONTENTS

The package includes all necessary components for the cat tree and an instruction manual. Please verify all parts are present and undamaged before beginning assembly. If any parts are missing or damaged, please contact customer support.

ASSEMBLY INSTRUCTIONS

Assembly of the Yaheetech Cat Tree is designed to be straightforward. Follow the step-by-step instructions provided in the included manual and use the tools supplied. Ensure all screws are tightened securely to maintain structural integrity, but avoid overtightening to prevent damage to the components. The anti-tipping strap should be installed as one of the final assembly steps to secure the tree to a wall.



Figure 2: The Yaheetech 139 cm Pink Plush Multi-Level Cat Tree after complete assembly.

OPERATING INSTRUCTIONS (USAGE)

The Yaheetech Multi-Level Cat Tree offers various features to keep your cat entertained, active, and comfortable:

- **Scratching Posts:** Several posts are wrapped with durable sisal rope, providing an ideal surface for your cat to sharpen their claws and promoting healthy scratching habits away from your furniture.
- **Multi-Level Platforms:** Cats can climb, jump, and observe their surroundings from different heights, satisfying their natural instincts for exploration and perching.
- **Cozy Caves:** Two enclosed cat caves offer secure and private spaces for resting, napping, and hiding, providing a sense of security for your feline companion.
- **Hanging Toys:** Two plush balls are attached to the cat tree, encouraging playful interaction and exercise. These toys are replaceable, allowing you to attach your cat's favorite toys if desired.



Figure 3: Close-up of the cat tree's various features, including caves, platforms, and ramp.



Auswechselbare und abnehmbare hängende Bälle

Figure 4: A cat engaging with one of the hanging plush ball toys.

MAINTENANCE

- **Cleaning:** Use a soft brush or a vacuum cleaner with a brush attachment to remove loose fur, dust, and debris from the plush surfaces and sisal posts. For soiled areas, spot clean with a damp cloth and a small amount of mild, pet-safe detergent. Ensure the area is thoroughly air-dried before your cat uses it again. Do not immerse in water.
- **Inspection:** Periodically inspect the entire cat tree for stability. Check all screws and connections for tightness and re-tighten as necessary. Examine the sisal ropes for significant wear and tear; heavily worn scratching posts may need replacement to maintain their effectiveness.

TROUBLESHOOTING

- **Instability:** If the cat tree feels wobbly, first ensure it is placed on a completely flat and stable floor surface. Re-check all assembly screws for tightness. Confirm that the anti-tipping strap is securely installed and anchored to a wall stud or appropriate wall anchor.
- **Cat not using the tree:** Cats can be particular. Encourage your cat to use the tree by placing treats, catnip, or their favorite toys on different levels. You can also place a familiar blanket or bed on one of the perches or in a cave. Allow your cat time to explore and adjust to the new furniture.

- **Damaged components:** If any part of the cat tree becomes damaged, discontinue use immediately to prevent injury to your pet. Contact customer support for replacement parts or further assistance.

SPECIFICATIONS

Brand	Yaheetech
Model Number	591852D
Color	Pink
Material	Particle board, Plastic, Plush, Sisal
Overall Dimensions (L x W x H)	49 x 49 x 138.5 cm
Large Cat Cave Dimensions (L x W x H)	Approx. 49 x 24.5 x 24 cm
Small Cat Cave Dimensions (L x W x H)	Approx. 28.5 x 28.5 x 24 cm
Maximum Load Capacity	Approx. 20 kg
Net Weight	13.4 kg
Recommended Use	Indoor use for climbing, scratching, and resting




Figure 5: Detailed dimensions of the cat tree.

WARRANTY AND SUPPORT

For warranty information or customer support regarding your Yaheetech Cat Tree, please refer to the seller's contact information or the original purchase documentation. This manual does not contain specific warranty details. Please retain your proof of purchase for any warranty claims.