

[Manuals.plus](#) /

› [PHI VILLA](#) /

› PHI VILLA Outdoor Patio Folding Chairs (6-Piece, Grey) Instruction Manual

PHI VILLA B09JNS5S7B

PHI VILLA Outdoor Patio Folding Chairs (6-Piece, Grey) Instruction Manual

Model: B09JNS5S7B

1. INTRODUCTION

Thank you for choosing PHI VILLA Outdoor Patio Folding Chairs. This set of six grey chairs is designed for comfort, durability, and convenience in various outdoor settings. Featuring an adjustable backrest and a lightweight, foldable design, these chairs are perfect for patios, gardens, lawns, and yards. Please read this manual thoroughly before use to ensure proper handling and maintenance.




Image: A set of six grey PHI VILLA outdoor patio folding chairs arranged around a dining table on a paved patio next to a swimming pool.

2. SETUP

2.1 Unfolding the Chairs

These PHI VILLA patio chairs require no assembly. They arrive pre-assembled and are designed for immediate use. To unfold each chair:

1. Gently pull the backrest upwards until it locks into an upright position.
2. Ensure the seat is fully extended and flat.
3. Verify that all four legs are firmly on the ground and the chair is stable before sitting.





Image: A visual guide demonstrating how to unfold a PHI VILLA patio chair from its compact folded state to its ready-to-use position, emphasizing its space-saving and portable design.

2.2 Folding for Storage

To fold the chairs for convenient storage or transport:

1. Lift the backrest slightly to disengage the locking mechanism.
2. Gently push the backrest forward towards the seat until the chair folds flat.
3. The compact design allows for easy storage in small spaces or transportation in a vehicle.

Video: A demonstration of the PHI VILLA patio folding chair, showcasing its portability and the ease with which it can be folded and unfolded. The video also highlights the adjustable backrest feature.

3. OPERATING THE ADJUSTABLE BACKREST

Each PHI VILLA folding chair features a 7-position adjustable backrest, allowing you to customize your seating angle for dining, lounging, or relaxing.

1. While seated, gently lift the armrests upwards. This action disengages the backrest locking mechanism.
2. Lean back or push forward to adjust the backrest to your desired angle.

3. Once the desired position is reached, release the armrests. The backrest will lock into one of the seven available notches.



Strong & Sturdy



Portable Folding



Comfortable



No installation, space-saving, and portable for camping!



Image: A visual representation of the PHI VILLA chair's adjustable backrest, showing the range of 7 positions from approximately 100 to 135 degrees, with instructions to lift armrests to adjust.

Video: A user demonstrating the adjustable backrest feature of the PHI VILLA outdoor patio folding chairs, showing how to easily change the recline angle by lifting the armrests.

4. MAINTENANCE

4.1 Cleaning Instructions

To maintain the appearance and longevity of your PHI VILLA chairs, follow these simple cleaning guidelines:

- **Frame:** Wipe the aluminum and iron frame with a soft cloth dampened with mild soap and water. Rinse thoroughly and dry completely to prevent water spots and rust.

- **Fabric (Textilene):** The breathable Textilene fabric is easy to clean. Use a soft brush or sponge with mild soap and water to remove dirt and stains. Rinse well and allow to air dry. Avoid harsh chemicals or abrasive cleaners.



Image: Detailed view of the Textilene fabric used in PHI VILLA chairs, emphasizing its durability and weather-resistant features.

High-Quality Texlin Fabric, Refreshing & Breathable



Waterproof



Anti-UV



Anti-Fade



High strength
& flexibility



Easy to clean



Image: A close-up shot of the chair's armrest and frame, showcasing the powder e-coating for enhanced durability and resistance to outdoor elements.

4.2 Storage

When not in use, especially during harsh weather conditions or off-season, it is recommended to fold the chairs and store them in a dry, protected area to prolong their lifespan.

5. TROUBLESHOOTING

If you encounter any issues with your PHI VILLA chairs, please refer to the following common solutions:

- **Chair feels unstable:** Ensure the chair is fully unfolded and the backrest is securely locked into one of the 7 positions. Check that all legs are on a flat, even surface.
- **Backrest not adjusting smoothly:** Inspect the armrest lifting mechanism for any obstructions. Ensure the fabric is not caught in the moving parts. Clean any debris from the adjustment points.
- **Difficulty folding:** Make sure the backrest is slightly lifted to disengage the lock before attempting to fold. Do not

force the mechanism.

For persistent issues, please contact PHI VILLA customer support.

6. SPECIFICATIONS

Feature	Detail
Brand	PHI VILLA
Model Number	B09JNS5S7B
Color	Grey
Material	Aluminum, Iron, Textilene Fabric
Product Dimensions (L x W x H)	25.5"D x 20.5"W x 42"H
Seat Height	18 Inches
Seat Depth	17 inches
Maximum Weight Recommendation	250 Pounds
Adjustable Backrest Positions	7
Assembly Required	No
Indoor/Outdoor Usage	Outdoor
Product Care Instructions	Wipe Clean

Powder E-coating Finish & Smooth Armrest



Rust resistant, Stable, Durable



Rust-proof



Heavy duty



Long-lasting



Image: A diagram providing precise measurements for the PHI VILLA folding chair, illustrating its overall dimensions and key seating area sizes.

7. SAFETY INFORMATION

- Do not exceed the maximum weight recommendation of 250 pounds per chair.
- Always ensure the chair is fully unfolded and stable on a level surface before use.
- Keep fingers and clothing clear of moving parts when adjusting the backrest or folding the chair.
- Do not stand on the chairs.
- Supervise children when they are near or using the chairs.

8. ADDITIONAL PRODUCT VIDEOS

Video: An overview of a PHI VILLA Outdoor Dining Set, showcasing the chairs in a garden setting. This video provides a general visual of the product in use.

9. WARRANTY AND SUPPORT

PHI VILLA is committed to providing high-quality products. For any questions, concerns, or warranty inquiries, please refer to the contact information provided with your purchase or visit the official PHI VILLA website. For more PHI VILLA products and information, visit the [PHI VILLA Store on Amazon](#).

© 2026 PHI VILLA. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question