

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [FULLJA](#) /

› [FULLJA 19-inch Dual-WiFi Digital Photo Frame 19-NEW1 Instruction Manual](#)

FULLJA 19-NEW1

FULLJA 19-inch Dual-WiFi Digital Photo Frame Instruction Manual

Model: 19-NEW1 | Brand: FULLJA

1. INTRODUCTION

The FULLJA 19-inch Dual-WiFi Digital Photo Frame (Model 19-NEW1) is designed to display your cherished photos and videos with ease. Featuring a high-resolution 1440x900 wide-viewing angle touch screen, 32GB of built-in memory, and Wi-Fi connectivity, this frame allows for instant sharing of media with family and friends from anywhere. Its versatile design supports both tabletop and wall-mounted orientations, making it a perfect addition to any space.

2. PACKAGE CONTENTS

Please check the box for the following items:

- 1x 19" Wi-Fi Digital Photo Frame
- 1x User Manual
- 1x Quick Started Guide
- 1x Remote Control
- 1x Micro USB Cable
- 1x Power Cord (59 inch)
- 1x Bracket

3. KEY FEATURES

- **19-inch HD Display:** 1440x900 resolution with a 16:10 aspect ratio for clear, natural photos from any angle.
- **Dual-WiFi Connectivity:** Enables free and instant sharing of photos and videos via the VPhoto app or email.
- **Large Storage Capacity:** 32GB built-in memory, expandable with USB and TF card (up to 128GB), plus unlimited cloud storage.
- **Motion Sensor:** Automatically turns the screen on/off based on presence.
- **Auto Rotate:** Automatically adjusts photo orientation for correct display.

- **Full Functionality:** Includes video playback, alarm, clock, calendar, split-screen, photo folder, music playback, auto on/off, and text captions.
- **Wall Mountable Design:** Can be hung on a wall or placed on a desk in portrait or landscape orientation.

Wall Mountable Design



Image: Overview of the FULLJA 19-inch Digital Photo Frame highlighting its diverse features including Wi-Fi, VPhoto App, Touch Screen, 32GB Built-in, Alarm, Weather, Clock, Slideshow, Adjustable Brightness, Motion Sensor, and Text Caption.

4. SETUP

4.1 Power Connection

Connect the provided power cord to the frame's power port and then to a power outlet. The frame will automatically power on.

4.2 Initial Wi-Fi Setup

Upon first use, the frame will guide you through the initial setup process, including connecting to your Wi-Fi network. Follow the on-screen instructions to select your network and enter the password.

4.3 VPhoto App Download & Device Binding

To share photos and videos remotely, download the **VPhoto app** on your smartphone (available on App Store and Google Play). Create an account and then bind your device to the app using the unique code displayed on your digital photo frame. You can invite family and friends to share photos with your frame by providing them with the device code.



Image: A smartphone displaying the VPhoto app interface, illustrating the steps to download the app, add devices by code, choose photos/videos to share, and invite loved ones.

5. OPERATING INSTRUCTIONS

5.1 Sending Photos and Videos

Once your frame is connected to the VPhoto app, you can easily send photos and short videos directly from your smartphone. Select the media you wish to share within the app and choose your frame as the recipient. The frame will receive them instantly.

Wireless Sharing & Keep Connected

Share Pictures or Small Videos with People You Care From Anywhere



Image: Multiple digital photo frames showcasing family moments, with a smartphone in the foreground demonstrating wireless photo and video sharing capabilities.

5.2 Slideshow Settings

Customize your slideshow experience through the frame's settings. You can adjust the interval time between photos (e.g., 5 seconds, 10 seconds, 1 minute), select transition effects, and choose the display order. The frame supports various auto-play styles including photo, video, music, or a combination.

5.3 Motion Sensor

The built-in motion sensor can be enabled to automatically turn the screen on when motion is detected and off after a period of inactivity, saving energy.

5.4 Auto Rotate

The frame automatically detects its orientation (portrait or landscape) and adjusts the displayed photos accordingly.

32GB Built-in Storage

Extended TF Card (max. 128GB)/Free Unlimited Cloud Storage



Image: A 19-inch digital photo frame showcasing a family photo, emphasizing its wide viewing angle and high-definition touch screen with 1440x900 resolution and 16:10 aspect ratio.

6. MEDIA MANAGEMENT

6.1 Internal and External Storage

The frame comes with 32GB of internal storage. You can expand this by inserting a USB drive or a TF card (up to 128GB) into the designated slots. Photos and videos can be played directly from external storage.

Easy to Bind Devices

Share Special Moments
Via VPhoto App

1. Download VPhoto App
2. Add Devices by Code
3. Choose Photos/Videos to Share
4. Invite Your Beloved Ones to Share With You



Image: A digital photo frame displaying a family photo, surrounded by a collage of other family pictures, with text highlighting its 32GB built-in storage and options for extended TF card and unlimited cloud storage.

6.2 Cloud Storage

Benefit from unlimited cloud storage for your photos and videos when using the VPhoto app. This ensures your memories are safely backed up and accessible.

7. SPECIFICATIONS

Feature	Detail
Screen Size	19 Inches
Resolution	1440*900 HD Display
Aspect Ratio	16:10
Internal Memory	32GB
External Storage	USB, TF card (up to 128GB)

Connectivity	Dual-WiFi
Compatible Devices	Android, iPhone (via VPhoto app)
Product Dimensions	18.89 x 12.83 x 1.06 inches
Item Weight	4.97 pounds
Color	Black

8. TROUBLESHOOTING

8.1 Frame Not Turning On

- Ensure the power cord is securely connected to both the frame and a working power outlet.
- Check if the power outlet is functional by plugging in another device.

8.2 Wi-Fi Connection Issues

- Verify your Wi-Fi password is correct.
- Ensure the frame is within range of your Wi-Fi router.
- Restart your Wi-Fi router and the digital photo frame.

8.3 Photos Not Displaying Correctly

- Check the photo format; the frame supports common image formats.
- Ensure the photos are not corrupted.
- Adjust display settings in the menu, such as aspect ratio or fill frame options.

9. MAINTENANCE

9.1 Cleaning the Screen

Gently wipe the screen with a soft, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water or a screen-cleaning solution. Avoid harsh chemicals or abrasive materials.

9.2 General Care

Keep the frame away from direct sunlight, excessive heat, and moisture. Avoid dropping the device or exposing it to strong impacts.

10. WARRANTY AND SUPPORT

The FULLJA 19-inch Dual-WiFi Digital Photo Frame comes with a one-year limited warranty. For technical support, warranty claims, or any inquiries, please refer to the contact information provided in the Quick Started Guide included in your package or visit the official FULLJA website. We aim to provide prompt responses within 24 hours.