Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HoTiyan H-10001

HoTiyan Digital Voice Recorder User Manual

Model: H-10001

Introduction

Thank you for choosing the HoTiyan Digital Voice Recorder. This compact and versatile device is designed for high-definition stereo recording, featuring a sensitive microphone and advanced noise reduction technology. It is ideal for capturing lectures, meetings, interviews, and personal notes with exceptional clarity. This manual provides comprehensive instructions to help you get the most out of your new voice recorder.





Figure 1: HoTiyan Digital Voice Recorder (Model H-10001)

Key Features

Voice Activated Recording (VOR)

The voice-controlled recording feature allows the device to automatically start recording when sound is detected above a set decibel level and pause when silence occurs. This intelligent function helps conserve storage space and simplifies the recording process by eliminating silent segments.



Figure 2: Illustration of Voice Activated Recording (VOR)

Simple Three-Button Operation

The recorder is designed for ease of use with dedicated buttons for recording, saving, and playback. This intuitive interface ensures quick and efficient operation, allowing you to capture important audio without delay.



Figure 3: REC, STOP, and PLAY/PAUSE buttons for easy control

A-B Repeat Function

Utilize the A-B repeat function to loop specific sections of your recordings. This feature is particularly beneficial for students reviewing lectures or professionals re-listening to critical meeting discussions, ensuring no detail is missed.



Figure 4: Demonstrating the A-B Repeat Function for focused review

Long Battery Life & Ample Storage

Equipped with a built-in 8GB storage capacity, the recorder can store up to 128 hours of high-quality audio (192 kbps). The rechargeable 3.6V 300mAh lithium battery provides approximately 20 hours of continuous recording or 8 hours of playback with earphones on a full charge.



Figure 5: Extended recording time with a fully charged battery

MP3 Player & Convenient File Transfer

Beyond its recording capabilities, this device functions as an MP3 player, allowing you to enjoy music. Transferring files is straightforward; simply connect the recorder to your computer using the supplied Micro USB cable to manage your MP3/WAV recordings and music.



Figure 6: Using the device as an MP3 player and for file transfer

Official Product Video

[redacted]

Video 1: HoTiyan Digital Voice Recorders - An overview of the product's features and design.

Setup Guide

1. Charging the Device

Before first use, fully charge your HoTiyan Digital Voice Recorder.

1. Locate the Micro USB port on the side of the device.
2. Connect the supplied Micro USB cable to the recorder and the other end to a USB power adapter (not included) or a computer's USB port.
3. The charging indicator on the screen will show charging status. A full charge typically takes a few hours.
4. Once fully charged, disconnect the cable.



Figure 7: Connecting the recorder for charging and file transfer

2. Powering On/Off

- To power on: Slide the **ON/OFF** switch located on the side of the device to the **ON** position. The screen will light up.
- To power off: Slide the **ON/OFF** switch to the **OFF** position. The device will shut down.

Operating Instructions

1. Basic Recording

1. Ensure the device is powered on.
2. Press the **REC** button (red circle) to start recording. The recording indicator will illuminate, and the timer on the screen will begin.
3. To pause recording, press the **PLAY/PAUSE** button. Press it again to resume.
4. To stop and save the recording, press the **STOP** button. The recording will be saved automatically.

Figure 8: Simple three-button operation for recording and playback

2. Playback

1. From the main menu or file list, select the desired recording using the navigation buttons.
2. Press the **PLAY/PAUSE** button to begin playback.
3. Press **PLAY/PAUSE** again to pause, and again to resume.
4. Use the volume buttons (**+/-**) on the side to adjust playback volume.
5. To stop playback, press the **STOP** button.

3. Voice Activated Recording (VOR) Setup

To enable VOR and adjust its sensitivity:

1. Navigate to the settings menu on the device.
2. Find the "VOR" or "Voice Activated" setting.
3. Enable the VOR function and adjust the sensitivity level (e.g., from 1 to 7, where 7 is most sensitive).
4. Exit the settings. The recorder will now automatically start/stop recording based on sound detection.



Figure 9: Voice Activated Recording (VOR) in action, saving space and time

4. A-B Repeat Function

To repeat a specific segment of an audio file:

1. During playback, press the **A/B** button once to set the starting point (A).
2. Press the **A/B** button a second time to set the ending point (B). The section between A and B will now loop.
3. Press the **A/B** button a third time to exit the A-B repeat mode.



Figure 10: A-B Repeat Function for focused listening

5. Password Protection

For enhanced security, you can set a password for your device.

- Access the security settings in the device menu.
- Select "Password Lock" and follow the on-screen prompts to set your desired password.
- Once enabled, the device will require the password to access its functions.
- **Important:** Remember your password. There is no master reset for forgotten passwords.



Figure 11: Secure your recordings with password protection

6. Time Stamps & File Management

Recordings are automatically named with a time stamp (e.g., YYYYMMDD_HHMMSS.WAV), making it easy to locate specific files.

- Connect the device to a computer via USB to access and manage your recorded files.
- Files can be copied, moved, or deleted like any other file on a USB drive.

Maintenance

- Keep the device dry. Moisture can damage internal components.
- Avoid extreme temperatures. Do not expose to direct sunlight or very cold environments.
- Clean the device with a soft, dry cloth. Do not use liquid cleaners or aerosols.
- Handle with care. Avoid dropping or subjecting the device to strong impacts.
- Regularly back up important recordings to a computer to prevent data loss.

Troubleshooting

Device Not Turning On

- Ensure the **ON/OFF** switch is firmly in the **ON** position.
- Connect the device to a power source using the USB cable to check if the battery is depleted. Charge fully if necessary.

Poor Recording Quality

- Check the recording environment for excessive background noise.
- Ensure the microphone is not obstructed.
- Adjust the microphone sensitivity settings if available (refer to VOR settings).
- Ensure the device is close enough to the sound source.

Cannot Transfer Files to Computer

- Ensure the USB cable is securely connected to both the recorder and the computer.
- Try a different USB port on your computer.

- Ensure the device is powered on when connected to the computer.
- If prompted, select "Mass Storage" or "Connect to PC" mode on the recorder's screen.
- Restart your computer and the voice recorder.

Recordings Not Saving

- Ensure you press the **STOP** button after recording to save the file.
- Check the available storage space on the device. If full, transfer files to a computer and delete them from the recorder.

Specifications

Brand	HoTiyan
Model Number	H-10001
Memory Storage Capacity	8 GB
Product Dimensions	3.3 x 1.4 x 0.55 inches
Item Weight	1.6 ounces
Battery	1 Lithium Ion battery required (3.6V 300mAh)
Compatible Devices	Personal Computer
Hardware Interface	USB 2.0 Type B
Microphone Form Factor	Built-In
Recording Format	MP3 Audio, WAV
Headphones Jack	3.5 millimeters

Warranty and Support

Warranty Information

Your HoTiyan Digital Voice Recorder is covered by a standard return policy, allowing for refund or replacement within 30 days of purchase. Please retain your proof of purchase for any warranty claims.

Customer Support

For further assistance, technical support, or inquiries regarding your HoTiyan product, please visit the official HoTiyan store on Amazon or contact their customer service directly.
Visit the HoTiyan Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I reset the HoTiyan H-10001 Digital Voice Recorder?

Based on the HoTiyan H-10001 Digital Voice Recorder manual, there is no dedicated physical reset button or master reset procedure mentioned for the device. Please consider the following based on your specific situation: For...

Read full answer

Open the live page

https://manuals.plus/asin/B09JNTR7J9

More documents and user manuals: **https://manuals.plus/**