

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [CYBORIS](#) /

› [CYBORIS S3 Portable Wireless Speaker User Manual](#)

CYBORIS S3

CYBORIS S3 Portable Wireless Speaker User Manual

Model: S3

INTRODUCTION

Thank you for choosing the CYBORIS S3 Portable Wireless Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. The S3 speaker delivers 15W stereo sound with deep bass, vibrant RGB lighting, and IPX7 waterproofing, making it ideal for various indoor and outdoor activities.

PRODUCT FEATURES

- **Extra Deeper Bass Hi-Fi Sound:** Equipped with a 15W high-sensitivity driver, dual-diaphragm, and DSP bass design for enhanced low frequencies. Supports dual pairing for 360° surround Hi-Fi stereo sound.
- **RGB Colorful Light Show:** Features three lighting modes (seven-color cycle, breathing, rhythm, and single-color light) that synchronize with music.
- **IPX7 Waterproof & Portable:** Designed to withstand rain, dust, snow, and spills. Includes a portable lanyard for easy carrying. Note: The charging port needs to be closed tightly for waterproofing.
- **Bluetooth 5.1 Connectivity:** Offers lossless music transmission and a stable wireless connection up to 60ft. Supports instant pairing and HD hands-free calling.
- **Versatile Playback Options:** Supports Micro SD/TF card, AUX port, and Bluetooth connectivity.
- **Long Playing Time:** Built-in 2400mAh lithium battery provides up to 18 hours of music playback or talk time.

WHAT'S IN THE BOX

- CYBORIS S3 Portable Wireless Speaker
- Charging Cable

- AUX Cable
- Portable Rope

PRODUCT LAYOUT AND CONTROLS

The CYBORIS S3 speaker features intuitive controls located on its body for easy access to various functions. The charging and AUX ports are protected by a waterproof cover.



Image: Side view of the CYBORIS S3 speaker, highlighting the control buttons for power, volume, and mode selection.

IPX7 WATERPROOF

Perfect protection for beach, poolside, shower.
Support immersed 3ft underwater for 30 mins.



Image: Close-up of the CYBORIS S3 speaker's waterproof cover, which protects the charging and AUX ports.

SETUP

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided charging cable to the speaker's charging port and a USB power source. The charging indicator light will show the charging status.

2. Power On/Off

Press and hold the Power button located on the speaker to turn it on or off. A sound prompt will indicate the power status.

3. Bluetooth Pairing

1. Turn on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing LED light.
2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "CYBORIS S3" from the list. Once connected, the LED light will become solid, and a confirmation sound will play.

4. True Wireless Stereo (TWS) Pairing

For an enhanced stereo experience, two S3 speakers can be paired together.

1. Ensure both S3 speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be the primary speaker), double-press the Power button. It will search for the second speaker.
3. Once successfully paired, both speakers will emit a confirmation sound, and their LED lights will synchronize.
4. Connect your device to the primary speaker via Bluetooth as described in step 3.

TWS Two Pairing

Stereo surround sound makes you immersive.

Bluetooth 5.1



Image: Two CYBORIS S3 speakers positioned to illustrate True Wireless Stereo (TWS) pairing, with a smartphone displaying music in the center.

OPERATING INSTRUCTIONS

1. Music Playback

- **Bluetooth Mode:** After successful pairing, play music from your connected device. Use the speaker's volume buttons or your device's volume controls.
- **Micro SD/TF Card Mode:** Insert a Micro SD/TF card with audio files into the designated slot. The speaker will automatically switch to card playback.
- **AUX Mode:** Connect an audio device using the provided AUX cable to the speaker's AUX port. The

speaker will automatically switch to AUX input.

Powerful Sound

15W driver, and DSP bass design.
Explosion of 125dB volume and deeper bass.




Image: An internal diagram of the CYBORIS S3 speaker, illustrating its 15W full-range horn and dual dynamic bass diaphragm for powerful sound delivery.

2. Hands-Free Calling

When connected via Bluetooth, the speaker supports hands-free calling. Press the Play/Pause button to answer or end a call. Press and hold to reject a call.

3. RGB Light Modes

The speaker features dynamic RGB lighting. Press the Light Mode button (if available, or refer to specific button functions) to cycle through different light effects: seven-color cycle, breathing, rhythm (active during playback), and single-color light. The lights enhance the audio experience.

RGB Light Show

Feel the ingenious blend of colorful lights and music.



- Cycle
- Breathe
- Colorful
- Single Color



Image: The CYBORIS S3 speaker showcasing its vibrant RGB light show, with various color modes indicated.

MAINTENANCE

- **Waterproofing:** Ensure the charging port's protective cover is tightly closed when using the speaker near water to maintain its IPX7 waterproof rating.
- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the speaker frequently. Charge it regularly, even if not in use for extended periods.

IPX7 WATERPROOF

Perfect protection for beach, poolside, shower.
Support immersed 3ft underwater for 30 mins.



Image: The CYBORIS S3 speaker partially submerged in water, illustrating its IPX7 waterproof feature, suitable for use in wet environments.

TROUBLESHOOTING

Problem	Possible Solution
Speaker does not power on.	Ensure the battery is charged. Connect to a power source and try again.

Problem	Possible Solution
Cannot pair via Bluetooth.	Ensure the speaker is in pairing mode (flashing LED). Turn off and on both the speaker and your device's Bluetooth. Make sure no other devices are connected to the speaker.
No sound or low volume.	Check volume levels on both the speaker and your connected device. Ensure the speaker is properly connected. If using AUX, check the cable connection.
TWS pairing fails.	Ensure both speakers are S3 models and are not connected to any other Bluetooth devices before attempting TWS pairing. Keep them close together during pairing.
RGB lights are not working.	Ensure the speaker is powered on. Press the Light Mode button to cycle through modes. Rhythm mode only activates during music playback.

SPECIFICATIONS

Specification	Detail
Model Name	S3
Brand	CYBORIS
Speaker Maximum Output Power	15 Watts
Connectivity Protocol	Bluetooth 5.1
Wireless Communication Technology	Bluetooth
Maximum Range	60 Feet
Water Resistance Level	IPX7 (Water Resistant)
Battery Life	18 Hours
Battery Type	2 Lithium Ion batteries (included)
Product Dimensions	3"D x 3"W x 5"H
Item Weight	350 Grams (12.3 ounces)
Material	Plastic or Synthetic Materials
Audio Driver Size	57 Millimeters
Audio Output Mode	Surround, Stereo
UPC	677306910229

OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video: An official product video from CYBORIS-US showcasing the S3 Portable Bluetooth Speaker's features and design.

WARRANTY AND SUPPORT

The CYBORIS S3 Portable Wireless Speaker comes with a standard manufacturer's warranty. For warranty claims, technical support, or any inquiries regarding your product, please contact CYBORIS customer service through the retailer's platform or the official CYBORIS website. Please retain your proof of purchase for warranty validation.