

Manuals.plus /

› Playmobil /

› Playmobil Police Jet Pack with Boat Instruction Manual - Model 70782

Playmobil 70782

Playmobil Police Jet Pack with Boat Instruction Manual

Model: 70782 | Brand: Playmobil

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and care of your Playmobil Police Jet Pack with Boat playset, Model 70782. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Safety Warning: Choking Hazard. Small parts. Not suitable for children under 3 years. Adult supervision is recommended during assembly and play.



Image: The Playmobil Police Jet Pack with Boat playset packaging, showing the police officer with a jet pack pursuing a figure in a boat.

PACKAGE CONTENTS

Verify that all components listed below are present in your package. If any parts are missing or damaged, please contact Playmobil customer support.

- Police Officer figure with Jet Pack
- Thief figure
- Inflatable Boat with outboard motor
- Handcuffs
- Crowbar
- Flashlight
- Stolen contraband accessories
- Other small accessories as depicted



Image: An overhead view displaying all individual components included in the Playmobil Police Jet Pack with Boat set, laid out against a blue background.

ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your Playmobil playset. Refer to the illustrations for visual guidance.

1. **Assemble Figures:** Attach the jet pack to the police officer figure. Ensure all accessories like the helmet and visor are securely placed. Assemble the thief figure with any designated accessories.

2. **Prepare the Boat:** Attach the outboard motor to the rear of the inflatable boat. Ensure it clicks into place firmly.
3. **Accessory Placement:** Place the stolen contraband, crowbar, and flashlight within the boat or with the figures as desired for play. The handcuffs can be clipped to the jet pack for easy access.

OPERATION

The Playmobil Police Jet Pack with Boat set is designed for imaginative play, simulating a police chase on water.

- **Jet Pack Functionality:** The police officer figure can be positioned as if flying with the jet pack, allowing for aerial pursuit scenarios.
- **Boat Movement:** The boat is designed to float. For enhanced water play, the boat can be upgraded with the Playmobil Underwater Motor (Model #7350), sold separately. This motor attaches to the existing outboard motor mount and propels the boat through water.
- **Interactive Play:** Use the included accessories to create various chase and capture scenarios between the police officer and the thief.



Image: The Playmobil police officer with a jet pack flying above the water, pursuing the thief in the inflatable boat.

MAINTENANCE AND CARE

To ensure the longevity of your Playmobil playset, follow these simple care instructions:

- **Cleaning:** Wipe figures and accessories with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Drying:** If used in water, ensure all parts, especially the boat, are thoroughly dried before storage to

prevent mildew or damage.

- **Storage:** Store the playset in a clean, dry place away from direct sunlight and extreme temperatures to prevent discoloration or warping.

IMPORTANT SAFETY INFORMATION

This product contains small parts which may pose a choking hazard. Keep away from children under 3 years of age. Adult supervision is always recommended during play. Do not modify the product in any way, as this may compromise its safety and functionality.

PRODUCT SPECIFICATIONS

Model Number	70782
Brand	Playmobil
Product Dimensions	9.76 x 5.59 x 2.76 inches (LxWxH)
Item Weight	7.3 ounces
Recommended Age	5 - 10 years
Number of Pieces	30

TROUBLESHOOTING

- **Missing Parts:** If any parts are missing upon opening the package, please refer to the 'Package Contents' section and contact Playmobil customer support for assistance.
- **Assembly Difficulties:** Review the 'Assembly Instructions' and accompanying images carefully. Ensure all pieces are oriented correctly and pressed firmly into place. Do not force parts together.
- **Boat Not Floating Correctly:** Ensure the boat is not overloaded with additional items. Check for any cracks or damage that might compromise its buoyancy.

CUSTOMER SUPPORT

For further assistance, replacement parts, or inquiries regarding your Playmobil product, please visit the official Playmobil website or contact their customer service department. Contact information can typically be found on the product packaging or the official Playmobil website.

Online Resources: www.playmobil.com