

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [MoNiBloom](#) /

› [MoNiBloom 5 Tier Book Cabinet with Acrylic Doors Instruction Manual](#)

MoNiBloom 5 Tier Book Cabinet

MoNiBloom 5 Tier Book Cabinet with Acrylic Doors Instruction Manual

Model: 5 Tier Book Cabinet

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your MoNiBloom 5 Tier Book Cabinet with Acrylic Doors. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of your product.

The MoNiBloom 5-layer bamboo storage cabinet features clean lines and a concise style, designed to bring an elegant appearance to your home. The push-in style acrylic doors offer water-proof and dirt-proof protection, creating an enclosed space for household items. The transparent design allows for convenient item retrieval and display of accent pieces.

2. SAFETY INFORMATION

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not overload shelves. Refer to specifications for weight limits per shelf.
- Keep small parts away from children during assembly to avoid choking hazards.
- Do not climb on or lean heavily on the cabinet.
- Place the cabinet on a level surface to prevent tipping.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Side Panels (Left & Right)
- Top Panel

- Bottom Panel
- Shelf Panels (5 pieces)
- Back Panels
- Acrylic Doors (5 pieces)
- Door Knobs/Handles (5 pieces)
- Hardware (screws, dowels, cam locks, etc.)
- Assembly Tool (e.g., Allen wrench)

4. ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. It is recommended to have two people for assembly.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface. Compare each part to the package contents list to ensure everything is present.
2. **Assemble the Base Frame:** Attach the bottom panel to the side panels using the provided hardware (e.g., screws, dowels). Ensure the pre-drilled holes align correctly.
3. **Install Shelf Panels:** Insert the shelf panels into the grooves or attach them to the side panels using the designated hardware. Work from bottom to top, ensuring each shelf is level and secure.
4. **Attach the Top Panel:** Secure the top panel to the side panels and the uppermost shelf using the appropriate hardware.
5. **Install Back Panels:** Carefully align and attach the back panels to the rear of the cabinet using small nails or screws. Ensure the cabinet frame is square before securing the back panels.
6. **Attach Acrylic Doors:** For each tier, slide the acrylic door into its designated track. The doors are designed for a push-in style mechanism.
7. **Install Door Knobs:** Attach the door knobs to each acrylic door using the provided screws.
8. **Final Check:** Once assembled, gently move the cabinet to its desired location. Ensure it is stable and level. Check all connections for tightness.



Figure 1: Exploded view of cabinet components for assembly.



Figure 2: Detail of the push-in invisible style door mechanism.



Figure 3: Product dimensions for planning placement.

5. OPERATING INSTRUCTIONS

The MoNiBloom 5 Tier Book Cabinet features pull-down acrylic doors for easy access and protection of your items.

- **Opening Doors:** Gently pull the knob on the acrylic door downwards to open. The door will slide down and inward, allowing access to the shelf compartment.
- **Closing Doors:** Push the door upwards until it clicks securely into place. Ensure the door is fully closed to protect contents from dust and moisture.
- **Loading Shelves:** Place books, decorative items, or other suitable objects onto the shelves. Distribute weight evenly to maintain stability.



Figure 4: Example of the cabinet in use, displaying books and decor.

6. MAINTENANCE

To keep your MoNiBloom Book Cabinet in optimal condition, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the bamboo surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the varnished finish.
- **Acrylic Doors:** Clean acrylic doors with a soft cloth and a mild, non-abrasive cleaner specifically designed for plastics. Do not use glass cleaner, as it may damage the acrylic.
- **Moisture Protection:** The bamboo is treated with waterproof paint. However, promptly wipe up any spills to prevent water damage.
- **Regular Checks:** Periodically inspect all screws and connections to ensure they remain tight. Re-tighten if necessary.



Water-Resistant
Surface is Treated with Waterproof Paint

Figure 5: Demonstrating water-resistant surface for easy cleaning.

7. TROUBLESHOOTING

If you encounter any issues with your MoNiBloom Book Cabinet, refer to the following common problems and solutions:

- **Cabinet is Wobbly:**

Solution: Ensure the cabinet is placed on a flat, level surface. Check all assembly screws and connections, tightening any that are loose. Verify that the back panels are securely attached and squaring the frame.

- **Acrylic Doors Not Sliding Smoothly:**

Solution: Check the door tracks for any obstructions or debris. Ensure the doors are correctly seated in their tracks. If the issue persists, verify that the cabinet frame is square and not warped, which can affect door alignment.

- **Missing or Damaged Parts:**

Solution: If you find any parts missing or damaged upon unpacking, do not proceed with assembly. Contact MoNiBloom customer support immediately for assistance and replacement parts.

- **Difficulty with Assembly:**

Solution: Review the assembly instructions carefully. Ensure you are using the correct hardware for

each step. If you are still having difficulty, consider seeking assistance from another person or contacting customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	MoNiBloom
Model	5 Tier Book Cabinet
Material	Acrylic, Bamboo
Number of Shelves	5
Product Dimensions	32D x 69.1W x 172H Centimetres (approx. 12.6D x 27.2W x 67.7H inches)
Finish Type	Varnished
Special Feature	Waterproof
Assembly Required	Yes
Care Instructions	Wipe with Damp Cloth

9. PRODUCT OVERVIEW VIDEO

Watch this video for a general overview of the MoNiBloom Book Cabinet and its features.

Your browser does not support the video tag.

Video 1: MoNiBloom Product Overview. This video showcases various MoNiBloom bamboo furniture products, including the book cabinet, highlighting features like damp-proof material, strength, flexibility, and stability.

10. WARRANTY AND SUPPORT

MoNiBloom is committed to providing high-quality products. For any questions, concerns, or warranty claims, please contact MoNiBloom customer support through your retailer or the official MoNiBloom website. Please have your purchase details and product model number ready when contacting support.