

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Deeyaple](#) /

› [Deeyaple 3D LED Digital Alarm Desk Clock User Manual](#)

Deeyaple CK-LED1302

Deeyaple 3D LED Digital Alarm Desk Clock User Manual

Model: CK-LED1302

1. INTRODUCTION

Thank you for purchasing the Deeyaple 3D LED Digital Alarm Desk Clock. This versatile clock combines modern design with essential functionalities, making it a perfect addition to any room. Please read this manual carefully to ensure proper use and maintenance of your new clock.

Key Features:

- Easy-to-read 3D LED display with adjustable brightness.
- Remote control and on-device button settings for convenience.
- Multifunctional display: 12/24 hour mode, date, temperature.
- Alarm clock with snooze function.
- Automatic and manual brightness adjustment.
- Suitable for both wall mounting and tabletop use.

2. PACKAGE CONTENTS

Please check the package for the following items:

- Deeyaple 3D LED Digital Alarm Clock (White)
- Remote Control
- USB Power Cable (approx. 3 meters long)
- Detachable Stand
- Wall Mounting Kits (3 hooks)
- User Manual




Image: The Deeyaple 3D LED Digital Alarm Clock, showing the main unit, remote control, and USB power cable.

3. PRODUCT OVERVIEW

Front Display:

The large 3D LED digits clearly display time, date, and temperature. The brightness can be adjusted to suit your environment.



Image: The 3D LED clock displaying time, positioned on a bedside table in a dimly lit room.

Back Panel and Remote Control:

The clock features control buttons on the back for basic settings and comes with a remote control for convenient operation from a distance.



Image: Rear view of the clock, highlighting the control buttons and keyhole slots for wall mounting.

4. SETUP

4.1 Power Connection:

Connect the provided USB power cable to the clock's power input port and plug the other end into a standard USB power adapter (not included) or a USB port on a computer/power bank. The clock will power on automatically.

4.2 Placement Options:

- **Tabletop Use:** Attach the detachable stand to the bottom of the clock for stable placement on any flat surface.
- **Wall Mounting:** Use the three keyhole slots on the back of the clock with appropriate screws (not included) to mount it securely on a wall. Ensure the wall can support the clock's weight and that the power cable can reach a power source.



Image: The product packaging illustrating both wall-mounted and tabletop display options for the clock.

5. OPERATING INSTRUCTIONS

5.1 Setting Time and Date:

Use the remote control or the buttons on the back of the clock to set the current time and date. Refer to the remote control's labels for specific buttons like "CLOCK" or "TIME".

- Press the "CLOCK" button on the remote to enter time setting mode.
- Use the Up/Down arrows to adjust hours and minutes.
- Press "CLOCK" again to confirm and move to date setting.
- Adjust year, month, and day using the Up/Down arrows.
- Press "CLOCK" to exit setting mode.

5.2 12/24 Hour Format:

Toggle between 12-hour and 24-hour display formats using the dedicated button on the remote control (often labeled "12/24H").

5.3 Alarm and Snooze Function:

The clock includes an alarm function with a snooze option.

- **Setting Alarm:** Press the "ALARM" button on the remote. Use Up/Down arrows to set the alarm time. Press "ALARM" again to confirm.
- **Activating Snooze:** When the alarm sounds, press the "SNOOZE" button on the remote or any button on the back of the clock to activate snooze. The alarm will sound again after a set interval.
- **Disabling Alarm:** To turn off the alarm completely, press the "ALARM" button repeatedly until the alarm icon disappears from the display.



Image: The clock displaying an alarm time and a separate image showing the snooze function activated.

5.4 Brightness Control:

The clock offers multiple brightness levels and an automatic dimming feature.

- **Manual Adjustment:** Use the "BRIGHT" button on the remote to cycle through 3 brightness levels (High, Medium, Low) and an OFF state.
- **Automatic Dimming:** The clock can automatically adjust its brightness based on ambient light conditions. This feature ensures optimal visibility during the day and reduces brightness for comfortable viewing at night.




Image: Illustration of the clock displaying time at three different brightness levels, from brightest to dimmest.

5.5 Temperature and Date Display:

The clock can cycle through time, date, and temperature displays. Use the "TEMP" button on the remote to switch between these modes or activate the loop display.



Time

Loop Display Mode



Date

Temperature



Image: The clock demonstrating its loop display mode, showing transitions between time, date, and temperature readings.

6. MAINTENANCE

- Clean the clock surface with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Keep the clock away from direct sunlight, high temperatures, and high humidity.
- Ensure the USB cable is not kinked or damaged.
- If the clock is unplugged, it has a memory function to retain time settings, powered by the included Lithium Ion batteries.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Clock does not turn on.	No power supply or faulty cable.	Ensure the USB cable is securely connected and the power adapter is working. Try a different USB port or adapter.
Display is too bright/dim.	Brightness setting needs adjustment.	Press the "BRIGHT" button on the remote to cycle through brightness levels. Check if automatic dimming is enabled.
Time/Date is incorrect.	Not set correctly or power interruption.	Follow instructions in Section 5.1 to reset time and date. The clock has memory function, but a prolonged power outage might require re-setting.
Alarm does not sound.	Alarm not set or volume too low.	Ensure the alarm is activated and set to the correct time. Check for any mute settings (though the product description mentions "mute", it's likely for button sounds, not alarm).
Clock flickering or acting erratically.	Power instability or internal issue.	Try unplugging and re-plugging the clock. If the issue persists, contact customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	Deeyaple
Model Number	CK-LED1302
Color	White
Display Type	Digital (3D LED)
Product Dimensions	9.84"W x 3.54"H
Item Weight	8.8 Ounces
Power Source	Corded Electric (USB)
Special Features	Adjustable Brightness, 3D Floating Display, Auto Dimmable, Snooze, Calendar Display, Temperature Display
Mounting Type	Wall Mount, Tabletop
Batteries	2 Lithium Ion batteries (included for memory function)

9. WARRANTY AND SUPPORT

Deeyaple is committed to providing quality products. For any questions, concerns, or technical support regarding your 3D LED Digital Alarm Desk Clock, please contact our customer service team through the retailer's platform where you purchased the product or visit the official Deeyaple store online.

Please retain your purchase receipt for warranty purposes. Specific warranty details may vary by region and retailer.

Deeyaple Official Store: [Visit Deeyaple Store on Amazon](#)

© 2024 Deeyaple. All rights reserved.