

ZIHNIC pn-9

ZIHNIC Active Noise Cancelling Headphones PN-9 User Manual

Model: PN-9

1. INTRODUCTION

Thank you for choosing ZIHNIC Active Noise Cancelling Headphones. This manual provides essential information for setting up, operating, and maintaining your headphones to ensure an optimal audio experience. These headphones are designed to deliver Hi-Res audio with deep bass, featuring active noise cancellation for an immersive listening environment.

2. PACKAGE CONTENTS

Please check the package for the following items:

- ZIHNIC Active Noise Cancelling Headphones (PN-9)
- Type C Charging cable
- 3.5mm Audio Cable
- Premium Carrying Case



Image: ZIHNIC PN-9 Headphones with included Type C charging cable, 3.5mm audio cable, and premium carrying case.

3. PRODUCT OVERVIEW AND CONTROLS

Familiarize yourself with the headphone components and controls.



Image: Close-up view of the headphone earcup, highlighting the Active Noise Cancellation (ANC) button and its indicator light.

Comfort and Design Features

- **90° Angle Rotatable Joints:** Allows for flexible adjustment and flat storage.
- **Soft Protein Leather & Memory Foam Cushions:** Provides comfort for extended wear.
- **Metal Adjustable Headband:** Ensures a secure and customized fit.

CUSTOMIZED & COMFORTABLE WEARING FEATURES



90° angle rotatable joints



Soft protein leather & Memory foam cushions



Metal adjustable headband



Image: Detailed view of the ZIHNIC headphones illustrating the 90-degree rotatable earcups, soft protein leather and memory foam cushions, and the metal adjustable headband for enhanced comfort.



Image: The headphones demonstrating their foldable design for easy portability and storage.

4. SETUP AND PAIRING

Bluetooth Pairing

1. Ensure the headphones are fully charged.
2. Press and hold the Power button for approximately 3-5 seconds until the LED indicator flashes blue and red, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "ZIHNIC PN-9" from the list of devices.
5. Once connected, the LED indicator will show a solid blue light or flash blue slowly.

The headphones support Bluetooth 5.0 for a stable connection up to 33 feet (10 meters).



Image: ZIHNIC headphones wirelessly connected to various Bluetooth-enabled devices, demonstrating multi-device compatibility.

5. OPERATING INSTRUCTIONS

Basic Functions

- **Power On/Off:** Press and hold the Power button.
- **Play/Pause:** Press the Multi-function button once.
- **Volume Up/Down:** Use the Volume + / - buttons.
- **Next/Previous Track:** Press and hold Volume + / - buttons.
- **Answer/End Call:** Press the Multi-function button once.
- **Reject Call:** Press and hold the Multi-function button.

Active Noise Cancellation (ANC)

To activate or deactivate Active Noise Cancellation, press the dedicated ANC button located on the earcup. An indicator light will confirm the ANC status.



ADVANCED ANC TECHNOLOGY

Reduce ambient noises by up to 90% especially from traffic and airplane engines

■ Noise
■ Voice

Image: A woman wearing the ZIHNIC headphones, illustrating the effect of Active Noise Cancellation by showing a reduction in ambient noise.

Wired Mode

Connect the included 3.5mm audio cable to the headphone's audio jack and your device's audio output. This allows you to use the headphones even when the battery is depleted or with non-Bluetooth devices.



Image: The ZIHNIC headphones connected to a laptop using the 3.5mm audio cable, demonstrating wired listening

capability.

6. CHARGING

The headphones are equipped with a 500mAh battery, providing up to 40 hours of playtime. To charge your headphones:

1. Connect the provided Type C charging cable to the charging port on the headphones.
2. Connect the other end of the cable to a USB power source (e.g., wall adapter, computer USB port).
3. The LED indicator will show red during charging and turn blue or off when fully charged.

A full charge takes approximately 1.5 hours. A quick 10-minute charge can provide up to 6 hours of listening time.



Image: ZIHNIC headphones displayed in an airport setting, highlighting their 40-hour playtime and quick charging feature.

7. MAINTENANCE

- Clean the headphones with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Store the headphones in the premium carrying case when not in use to protect them from dust and

damage.

- Avoid exposing the headphones to extreme temperatures, humidity, or direct sunlight.
- Do not attempt to disassemble or modify the headphones, as this will void the warranty.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Headphones do not power on	Low battery	Charge the headphones fully.
Cannot pair with device	Bluetooth not enabled, headphones not in pairing mode, or device too far	Ensure Bluetooth is on, headphones are in pairing mode (flashing blue/red), and within 1 meter of the device.
No sound	Volume too low, incorrect audio source, or loose cable (wired mode)	Increase volume, check device's audio output, ensure 3.5mm cable is securely connected.
ANC not working effectively	ANC not activated, or type of noise	Press the ANC button to activate. ANC is most effective for low-frequency ambient noise.

9. SPECIFICATIONS

Feature	Detail
Model Name	PN-9
Noise Control	Active Noise Cancellation
Connectivity Technology	Wireless (Bluetooth 5.0)
Bluetooth Range	10 Meters (33 feet)
Audio Driver Type	Dynamic Driver (40mm large-aperture)
Frequency Response	20 KHz
Headphones Jack	3.5 mm Jack
Battery Life	40 Hours
Charging Time	1.5 Hours
Earpiece Shape	Over Ear
Material	Leather (earcups)
Item Weight	300 Grams (10.6 ounces)
Special Features	Foldable, Noise Cancellation, Volume Control

10. WARRANTY AND SUPPORT

ZIHNIC headphones come with a **12-month warranty**. For any inquiries, technical support, or warranty claims, please contact our customer service. We offer **24-hour after-sale customer services** and quick response to ensure your satisfaction.

For further assistance, please visit the [ZIHNIC Store on Amazon](#).