

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [LEGO](#) /

> [LEGO Botanical Collection: Flower Bouquet \(10280\) & Bonsai Tree \(10281\) Instruction Manual](#)

LEGO 10280, 10281

LEGO Botanical Collection: Flower Bouquet (10280) & Bonsai Tree (10281) Instruction Manual

Brand: LEGO

INTRODUCTION



Image: The LEGO 10280 Flower Bouquet and LEGO 10281 Bonsai Tree sets, showing both product boxes and their assembled models. This instruction manual provides guidance for the assembly, display, and care of your LEGO Botanical Collection sets: the LEGO 10280 Flower Bouquet and the LEGO 10281 Bonsai Tree. These sets are designed to offer a rewarding and immersive building experience for adults, resulting in beautiful, displayable botanical models. The LEGO 10280 Flower Bouquet allows for the creation of a vibrant, customizable floral arrangement, while the LEGO 10281 Bonsai Tree offers a serene model with interchangeable foliage options. Please read through these instructions carefully to ensure a successful and enjoyable building process.

ASSEMBLY INSTRUCTIONS (SETUP)

Each LEGO set includes a detailed, step-by-step instruction booklet. It is crucial to follow these official LEGO instructions for proper assembly. The following provides general guidance and highlights key features of each model.

LEGO 10280 Flower Bouquet




Image: The LEGO 10280 Flower Bouquet set, showing the product box and the fully assembled bouquet with various colorful flowers.



WERDEN SIE KREATIV UND PERSONALISIEREN SIE IHREN BLUMENSTRAUß

Image: A close-up view of the LEGO Flower Bouquet, highlighting the intricate details of the petals and leaves, which can be customized and positioned.

- **Unpacking:** Carefully open the box and sort the LEGO bricks by color or type to facilitate the building process.
- **Following Instructions:** Refer to the dedicated instruction booklet for the LEGO 10280 set. Each step is illustrated to guide you through the construction.
- **Customization:** The petals and leaves of the flowers are designed to be repositioned. Experiment with different angles and arrangements to achieve your desired look.
- **Stem Length Adjustment:** The stems can be adjusted in length, allowing you to create various bouquet compositions. This flexibility helps in fitting the bouquet into different display containers (not included).

[LEGO 10281 Bonsai Tree](#)




Image: The LEGO 10281 Bonsai Tree set, showing the product box and the fully assembled bonsai tree with green foliage.



Bringen Sie ein Symbol für Harmonie und Balance in Ihr Zuhause

Image: A detailed view of the LEGO Bonsai Tree, showcasing the interchangeable green leaves and the pink cherry blossom elements, including tiny frog pieces.

- **Unpacking:** As with the bouquet, organize your pieces before beginning construction.
- **Following Instructions:** Use the specific instruction booklet for the LEGO 10281 set.
- **Interchangeable Foliage:** The Bonsai Tree comes with two sets of foliage: classic green leaves and pink cherry blossoms. You can switch these out to change the tree's appearance.
- **Hidden Details:** Note the adorable frog elements hidden within the pink cherry blossoms, adding a unique touch to the model.
- **Base Assembly:** Construct the rectangular pot and the wood-slat effect stand as per the instructions to provide a stable and aesthetic base for your Bonsai.

OPERATING AND DISPLAY

Once assembled, both the Flower Bouquet and Bonsai Tree are designed for display. They do not require any operational functions beyond their initial construction and arrangement.

Displaying the Flower Bouquet



**ORDNEN SIE DEN BLUMENSTRAUß
NEU AN, UM IHN IHREM ZIMMER ODER
IHRER STIMMUNG ANZUPASSEN**

Image: The LEGO Flower Bouquet arranged in different vases and settings within a home, demonstrating its versatility in decor.

- The bouquet is provided without a vase, allowing you to choose one that complements your decor.
- Arrange the flowers and adjust stem lengths to create a composition that suits your space or mood.
- The customizable elements allow for frequent rearrangement to refresh your display.

Displaying the Bonsai Tree



Ein lohnendes und entspannendes Gebäude-Erlebnis

Image: A person carefully assembling the LEGO Bonsai Tree, illustrating the hands-on and relaxing nature of the building experience.

- The Bonsai Tree, with its rectangular pot and wood-slat stand, is designed for stable display on any flat surface.
- Choose between the green foliage or pink cherry blossoms to match the season or your personal preference.
- Position the tree in a prominent location to appreciate its intricate design and symbolic representation of harmony.

MAINTENANCE

LEGO models are durable, but proper care ensures their longevity and appearance.

- **Cleaning:** To remove dust, use a soft brush, a can of compressed air, or a damp cloth. Avoid harsh chemicals or abrasive materials, as these can damage the plastic.
- **Handling:** Handle the models gently, especially when moving them, to prevent pieces from detaching.
- **Storage:** If disassembling for storage, keep all pieces in a sealed container to prevent loss.
- **Sunlight Exposure:** Prolonged exposure to direct sunlight can cause plastic colors to fade over time. Consider placing your models in areas with indirect light.

TROUBLESHOOTING

Most issues with LEGO sets can be resolved by carefully reviewing the instruction manual or contacting customer support.

- **Missing Pieces:** If you discover a missing piece during assembly, please refer to the official LEGO customer service website for replacement parts. Do not attempt to force incompatible pieces together.
- **Difficulty Assembling:** Double-check the instruction steps. Ensure you are using the correct pieces and that they are oriented correctly. Sometimes, a small piece can be overlooked.
- **Model Instability:** If your model feels unstable, re-examine the connections in the relevant section of the build. Ensure all bricks are firmly pressed together.

SPECIFICATIONS

| Feature | Detail |
|-----------------------------------|---|
| Brand | LEGO |
| Model Numbers | 10280 (Flower Bouquet), 10281 (Bonsai Tree) |
| Educational Value | Creative thinking |
| Main Material | Plastic (LEGO bricks) |
| Flower Bouquet Colors | Multi-color (inspired by rose, snapdragon, poppy, aster, daisy, etc.) |
| Bonsai Tree Colors | Green (classic foliage), Pink (cherry blossoms) |
| Age Range | Adult (18+) |
| Flower Bouquet Dimensions | Over 18 cm (7 in.) high, 21 cm (8 in.) long, 20 cm (7 in.) wide (approximate, depending on arrangement) |
| Bonsai Tree Dimensions | Over 18 cm (7 in.) high, 21 cm (8 in.) long, 20 cm (7 in.) wide (approximate) |
| Number of Pieces (Flower Bouquet) | 756 |
| Number of Pieces (Bonsai Tree) | 878 |

WARRANTY AND SUPPORT

For detailed warranty information and customer support regarding your LEGO products, please refer to the official LEGO website or the documentation included with your purchase.

- **Official LEGO Website:** www.lego.com/service (for missing parts, building instructions, and general inquiries).
- **Product Registration:** Registering your product may provide additional benefits or support options.

