

Nokia 105 4G (16VEGB21A05)

Nokia 105 4G User Manual

Model: 105 4G (16VEGB21A05)

INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Nokia 105 4G mobile phone. The Nokia 105 4G is designed for clear communication with 4G VoLTE capabilities, offering features like FM radio, classic games, and a built-in flashlight. Its user-friendly interface includes zoomed menus and text-to-speech functionality for ease of use.

SETUP

1. Inserting the SIM Card and Battery

To begin using your Nokia 105 4G, you will need to insert your SIM card(s) and the battery. The phone supports dual SIM cards.

1. Carefully remove the back cover of the phone.
2. If the battery is already in place, remove it by gently lifting it from the notch.
3. Insert your SIM card(s) into the designated slot(s) with the gold contacts facing down. Ensure they click into place.
4. Insert the battery, aligning the contacts.
5. Replace the back cover, pressing firmly until it snaps into place.



Figure 1: Front and side view of the Nokia 105 4G, illustrating its compact design.

2. Charging the Battery

Before first use, fully charge the battery. Use only compatible chargers approved by Nokia.

1. Connect the USB cable to the phone's charging port (Micro USB).
2. Connect the other end of the cable to a power adapter and plug it into a wall outlet.
3. The battery indicator on the screen will show charging progress.

4. Once fully charged, disconnect the charger.

OPERATING YOUR PHONE

Power On/Off

To power on your phone, press and hold the Power key until the Nokia logo appears. To power off, press and hold the Power key, then select 'Power off' from the options.

Basic Navigation

Use the navigation keys and the center select key to move through menus and make selections. The left and right soft keys perform functions indicated on the screen above them.





Figure 2: The phone display showing the 'Call Logs' menu, accessible via navigation keys.

Making Calls

The Nokia 105 4G supports 4G VoLTE for clear call quality.

1. From the home screen, enter the phone number using the keypad.
2. Press the Call key (green phone icon) to initiate the call.
3. To end a call, press the End Call key (red phone icon).

Sending Messages

1. Go to the 'Messages' menu.
2. Select 'Create message' or 'New message'.
3. Enter your message using the keypad.
4. Enter the recipient's phone number or select from contacts.
5. Select 'Send'.

FM Radio

Your phone includes an FM radio. You may need to connect a headset (sold separately) to act as an antenna.

1. Navigate to the 'FM Radio' application.
2. Tune to your desired station using the navigation keys.

Flashlight

To activate the flashlight, typically press and hold the '0' key or access it through the 'Tools' menu.

Games

The phone comes pre-loaded with classic games. Access them through the 'Games' menu.

MAINTENANCE

Cleaning Your Phone

Use a soft, lint-free cloth to clean the phone's screen and body. Avoid using harsh chemicals or abrasive materials.

Battery Care

- Do not expose the battery to extreme temperatures.
- Avoid fully discharging the battery frequently.
- If the phone will not be used for an extended period, store it in a cool, dry place with the battery partially charged.

Storage

Store your phone in a safe place away from dust, moisture, and direct sunlight when not in use.

TROUBLESHOOTING

If you encounter issues with your Nokia 105 4G, try the following steps:

- **Phone not turning on:** Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on.
- **No network signal:** Check that your SIM card is correctly inserted. Move to an area with better network coverage.
- **Call quality issues:** Ensure you are in an area with good signal strength.
- **Battery draining quickly:** Reduce screen brightness, close unused applications, or limit background processes.
- **Phone frozen/unresponsive:** Remove and reinsert the battery, then power on the phone.

If the problem persists, please contact customer support for further assistance.

SPECIFICATIONS

Feature	Specification
Operating System	Android
RAM	1 GB
Package Dimensions	12.8 x 12.2 x 3.4 cm
Item Weight	180 grams
Batteries	1 Lithium Ion battery required (included)
Item Model Number	16VEGB21A05
Wireless Communication Technologies	Cellular
Connectivity Technologies	4G

Feature	Specification
GPS	No
Special Features	Radio Tuner, USB
Other Display Features	Wireless
Device Interface - Primary	Buttons, Numeric Keypad, Microphone
Scanner Resolution	1280 x 720
Other Camera Features	Rear
Audio Jack	3.5 mm
Form Factor	Bar
Color	Blue, Red, [Unknown]
Battery Power Rating	1020 mAh (Unknown rating)
Phone Talk Time	10 hours
What's in the Box	USB Cable
Screen Size	5.8 inches
Refresh Rate	90 Hz
Model Name	Nokia 105 4th Generation
Wireless Carrier	All Carriers
Cellular Technology	4G

WARRANTY AND SUPPORT

Warranty Information

Your Nokia 105 4G comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty period and coverage details.

Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact Nokia customer support. You can find contact details on the official Nokia website or in your product documentation.

For online support, visit: www.nokia.com/phones/support