

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Relaxdays](#) /

› [Relaxdays Industrial TV Cabinet Model 10038548 User Manual](#)

Relaxdays 10038548

Relaxdays Industrial TV Cabinet - Model 10038548

User Manual

INTRODUCTION

Thank you for choosing the Relaxdays Industrial TV Cabinet, Model 10038548. This manual provides essential information for the safe assembly, operation, and maintenance of your new TV cabinet. Please read these instructions carefully before beginning assembly and retain them for future reference.



Front view of the assembled TV cabinet, showcasing its industrial design with dark wood-look shelves and black metal frame.

SAFETY INSTRUCTIONS

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten if necessary.
- Do not overload the shelves or drawers. Refer to the specifications for weight limits.
- Place the TV cabinet on a level and stable surface to prevent tipping. Use the adjustable feet to compensate for uneven floors.
- Keep small parts and packaging materials away from children to avoid choking hazards.
- This product is designed for indoor use only.

PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Metal Frame components
- Wood-look Panels (top shelf, middle shelf, drawer fronts)
- Fabric Drawers (2 units)
- Adjustable Feet (4 units)
- Assembly Hardware (screws, Allen key, etc.)

SETUP AND ASSEMBLY

Assembly is required for this product. Please follow the steps carefully. It is recommended to have two people for assembly, though it can be managed by one person with patience.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a soft, clean surface.
2. **Assemble Frame:** Connect the metal frame components using the provided screws and Allen key. Ensure all connections are firm.
3. **Attach Shelves:** Secure the wood-look panels to the metal frame to form the top and middle shelves.
4. **Insert Drawers:** Assemble the fabric drawers by inserting the bottom panel and then sliding them into their designated slots within the frame. Attach the wood-look drawer fronts to the fabric drawers.
5. **Attach Adjustable Feet:** Screw the adjustable feet into the bottom of the metal frame.
6. **Level the Cabinet:** Once assembled, place the cabinet in its desired location. Adjust the height of each foot by rotating it until the cabinet is stable and level on the floor.



An annotated image illustrating the height (48.5 cm), width (93 cm), and depth (41.5 cm) of the TV cabinet.

21 x 43 x
37 cm



Detailed view of one of the two fabric drawers, highlighting its wood-look front panel and black handle. The internal dimensions of the drawer are shown as 21 x 43 x 37 cm.




Two images showing the adjustable feet of the cabinet. One image shows the foot in its standard position, and the other shows it extended, indicating its height adjustment capability for uneven floors.

OPERATING INSTRUCTIONS

The Relaxdays Industrial TV Cabinet is designed to organize your entertainment area efficiently.

- **Top Shelf:** Use the top surface to place your television. Ensure the TV base fits securely within the dimensions of the cabinet top.
- **Open Shelf:** The open middle shelf is ideal for housing media devices such as receivers, gaming consoles, or soundbars.
- **Drawers:** Utilize the two fabric drawers for discreet storage of DVDs, remote controls, magazines, or other accessories.



The TV cabinet positioned against a brick wall, demonstrating its aesthetic integration into a living space. Decorative items are placed on top and within the open shelf.



An image depicting the TV cabinet in use, with a television placed on its top shelf and people enjoying content, illustrating its primary function.

MAINTENANCE

To ensure the longevity and appearance of your TV cabinet, follow these maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using abrasive cleaners, harsh chemicals, or solvents, as these can damage the finish.
- **Dusting:** Regularly dust the cabinet with a dry, soft cloth.
- **Hardware Check:** Periodically inspect all screws and connections to ensure they remain tight. Re-tighten if any looseness is detected.
- **Drawer Care:** The fabric drawers can be spot cleaned with a mild detergent and damp cloth. Allow to air dry completely.



A detailed shot of the cabinet's construction, showing the black metal frame connected to the dark wood-look panel, emphasizing the industrial design elements.

TROUBLESHOOTING

If you encounter any issues with your TV cabinet, refer to the following common problems and solutions:

- **Cabinet is wobbly:** Ensure the cabinet is on a flat surface. Adjust the individual feet by rotating them until the cabinet is stable. Check that all assembly screws are tightened.
- **Drawers do not slide smoothly:** Verify that the fabric drawers are correctly assembled and inserted into their slots. Ensure no obstructions are present.
- **Missing parts:** If any parts were missing upon unboxing, please contact Relaxdays customer support with your purchase details.

SPECIFICATIONS

Model Number	10038548
Dimensions (H x W x D)	48.5 x 93 x 41.5 cm
Weight	10.76 kg
Material	60% Fiberboard, 30% Iron, 10% Wood
Color	Dark Brown / Black
Style	Industrial
Assembly Required	Yes

WARRANTY AND SUPPORT

For warranty information, spare parts availability, or any other support inquiries, please contact Relaxdays customer service. Refer to your purchase documentation for specific contact details or visit the official Relaxdays website.