

[Manuals.plus](#) /

› [Toozezy](#) /

› Toozezy Automatic Pet Feeder Instruction Manual

Toozezy PP013

Toozezy Automatic Pet Feeder Instruction Manual

Model: PP013

PRODUCT OVERVIEW

The Toozezy Automatic Pet Feeder is designed to provide reliable and scheduled feeding for your cats and small to medium-sized dogs. With its 6-liter capacity, programmable meal times, and clog-free design, it ensures your pet receives consistent nutrition even when you are away. The feeder also includes a voice recording feature to call your pet to meals and dual power supply options for uninterrupted operation.



Image: The Toozey Automatic Pet Feeder, showcasing its design and a full food reservoir.

SETUP AND ASSEMBLY

1. Unboxing and Components

Carefully remove all components from the packaging. Ensure you have the main feeder unit, stainless steel bowl, bowl holder, rotary vane, transparent food bucket, desiccant bag, power adapter, and USB cable.



Image: Diagram illustrating the various components included with the feeder.

2. Power Supply

The feeder supports dual power supply: via USB cable or 3 x D batteries (not included). For optimal performance and backup, it is recommended to use both. The memory function retains settings during power outages.

DUAL POWER SUPPLY

Memory settings when sudden power failure



5V USB
ADAPTER



3×D BATTERIES
(NOT INCLUDED)

Image: Illustration of the dual power supply options: USB adapter and D batteries.

3. Initial Assembly

1. Place the stainless steel bowl into the bowl holder.
2. Lift up the button on the feeder, place the rotary vane, and lock it into position.
3. Install the transparent grain bucket onto the main unit and lock the buttons on both sides.
4. Place the desiccant bag into the designated compartment in the lid to keep food fresh.

5. Close the lid securely.

BUILT IN DRYING BOX

Keep each bite fresh



Desiccant Bag

Image: The built-in drying box with the desiccant bag for food freshness.

OPERATING INSTRUCTIONS

1. Setting Time and Meals

The feeder allows you to set up to 6 meals per day with up to 20 portions (approximately 200g / 7oz) per meal. Refer to the control panel for setting the current time and programming meal schedules.




Image: A cat enjoying a meal from the feeder, with a graphic showing meal timing options.

2. Voice Recording

Record a personalized voice message of up to 10 seconds to call your pet to eat. This message can be played up to 5 times at each meal, making your pet feel comfortable and safe.

VOICE RECORDING

🎤 Up to 10s long voice recording
and 5 times voice calling

🔊 HEY BABY, TIME TO MEAL!



Image: The feeder's voice recording feature in action, calling a cat to its meal.

3. Manual Feeding

You can manually dispense food by pressing the appropriate button on the control panel. This is useful for immediate feeding or testing the dispenser.

4. Food Shortage Reminder

The transparent food storage box allows you to monitor food levels easily. A red indicator light will illuminate when food is

low, prompting you to replenish it in a timely manner.

Video: Official operating instructions for the Automatic Pet Feeder, demonstrating various functions.

MAINTENANCE AND CLEANING

Regular cleaning ensures hygiene and extends the life of your pet feeder. The feed container, turntable, and stainless steel feeding bowl can be easily disassembled for cleaning.

REMOVABLE FOR CLEANING

Easy to clean, worry-free food hygiene



Image: Visual guide to the removable components of the feeder for easy cleaning.

Cleaning Steps:

1. Turn off the power and unplug the feeder.
2. Remove the transparent food bucket by unlocking the side buttons.
3. Lift up and rotate the button to remove the rotary vane.
4. Remove the stainless steel bowl from its holder.

- 5. Wash the stainless steel bowl, bowl holder, rotary vane, and grain bucket with soapy water. These parts can also be cleaned with a damp-dry cloth or by dishwasher.
- 6. Clean the inner and outer surfaces of the main machine unit with a damp-dry cloth. Do not soak the machine in water.
- 7. Ensure the infrared sensor area is clean for proper food detection.
- 8. Allow all parts to dry completely before reassembling.

Video: Detailed cleaning instructions for the Automatic Pet Feeder components.

TROUBLESHOOTING

- **Feeder not dispensing food:** Check if the food bucket is empty. Ensure the rotary vane is correctly installed and not jammed. The feeder has an automatic anti-blocking system to prevent clogs.
- **Indicator light is red:** This indicates a food shortage or low battery. Replenish food or replace batteries as needed. The indicator will disappear within 60 seconds after the issue is resolved.
- **Programming issues:** If settings are incorrect, long press the "Setting" button for 2 seconds to enter setting mode and re-adjust. You can also long press "Setting" and "OK" buttons for 3 seconds to reset to factory default.
- **Voice recording not playing:** Ensure the recording was saved correctly. Check the playback settings to confirm the desired number of plays per meal.

SPECIFICATIONS

Feature	Specification
Brand	Toozey
Model Number	PP013
Capacity	6 Liters (for dry food 5-15mm)
Meals Per Day	1-6 meals
Portions Per Meal	Up to 20 portions (approx. 200g / 7oz)
Voice Recorder	Up to 10 seconds, plays up to 5 times per meal
Power Supply	5V USB Adapter / 3 x D Batteries (not included)
Material	Plastic
Dimensions (LxWxH)	13.66 x 8.27 x 12.95 inches
Item Weight	7.05 ounces (200 Grams)

SUPPORT

For any questions or assistance with your Toozey Automatic Pet Feeder, please do not hesitate to contact us. We are always ready to serve you.

© 2023 Toozey. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

The time on my feeder isn't changing

If the time on your Toozey PP013 display is not advancing after you set it, the internal clock mechanism may be frozen or the unit may have a hardware defect. Since you have already...

[Read full answer](#)