

ZEYUMEE Udream

ZEYUMEE Udream Heated Eyelash Curler Instruction Manual

Brand: ZEYUMEE | Model: Udream

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using the ZEYUMEE Udream Heated Eyelash Curler. Keep this manual for future reference.

- Do not immerse the device in water or other liquids.
- Keep out of reach of children.
- Do not use on damaged or irritated skin.
- Avoid direct contact with the eyeball.
- Ensure the device is fully charged before first use.
- Do not attempt to disassemble or repair the device yourself. Contact customer support if needed.
- Unplug the device when not in use or during charging.

2. PRODUCT OVERVIEW

2.1 Components

- Heated Eyelash Curler
- USB Charging Cable (Type-C)
- Sensing Silicone Pad (integrated)

2.2 Features

- **Quick Heating:** Reaches optimal temperature in approximately 10 seconds.
- **Two Temperature Modes:**
 - Low Temperature (Green Light): 65 °C / 149 °F - Suitable for fine, soft eyelashes.
 - High Temperature (Blue Light): 85 °C / 185 °F - Suitable for hard, thick eyelashes.
- **Sensing Silicone Pad:** Designed to prevent burning, pinching, or discomfort during use.
- **USB Rechargeable:** Conveniently charged via Type-C cable.
- **Long-Lasting Battery:** Provides up to 60 minutes of continuous use on a full charge.

- **Automatic Shut-off:** Device powers off automatically after 5 minutes of inactivity for safety and power saving.
- **Compact Design:** Portable and easy to store in a wallet, handbag, or cosmetic case.



Figure 1: A white, sleekly designed heated eyelash curler with an ergonomic handle and a green indicator light on its body, shown with its handles open.

3. SETUP

3.1 Charging the Device

1. Locate the Type-C charging port on the device.
2. Connect the provided USB charging cable to the device and a suitable USB power source (e.g., computer, wall adapter).
3. The indicator light will show charging status (specific color/behavior not detailed, refer to product packaging if available).
4. A full charge provides approximately 60 minutes of continuous use.

4. OPERATING INSTRUCTIONS

4.1 Powering On and Temperature Selection

1. Press and hold the power button to turn on the device.
2. The device will begin to heat up, indicated by the light.
3. To switch between temperature modes, single press the power button:
 - **Green Light:** Low temperature (65 °C / 149 °F) for fine, soft eyelashes.
 - **Blue Light:** High temperature (85 °C / 185 °F) for hard, thick eyelashes.
4. Wait approximately 10 seconds for the device to reach the selected temperature.

4.2 How to Use

1. Ensure your eyelashes are clean and dry.
2. Select the desired temperature setting (green for soft, blue for thick lashes).
3. Once heated, gently place your eyelashes between the curler's silicone pad and the heated bar.
4. Press the handles together gently, holding for a few seconds (e.g., 5-10 seconds).
5. Release the handles and carefully remove the curler.
6. Repeat along the length of your lashes as desired for a more pronounced curl.
7. For best results and a long-lasting lift, apply mascara after curling.

Your browser does not support the video tag.

Video 1: This video demonstrates the features and usage of the ZEYUMEE Udream Heated Eyelash Curler, including how to power it on, select temperature settings, and apply it to eyelashes for curling.

5. MAINTENANCE

5.1 Cleaning

- Ensure the device is turned off and completely cooled before cleaning.
- Wipe the heated bar and silicone pad with a soft, dry cloth.
- Do not use abrasive cleaners or harsh chemicals.
- Do not rinse the device under water.

5.2 Storage

- Store the eyelash curler in a cool, dry place.
- Keep it away from direct sunlight and extreme temperatures.
- Protect the device from dust and moisture.

6. TROUBLESHOOTING

6.1 Common Issues

- **Device not heating up:**
 - Ensure the device is fully charged.
 - Confirm the power button has been pressed and the indicator light is on.
- **Eyelashes not curling effectively:**
 - Ensure lashes are clean and free of mascara before curling.
 - Try using the higher temperature setting (blue light) for thicker lashes.
 - Hold the curler in place for a slightly longer duration (e.g., 10-15 seconds).

- Apply mascara immediately after curling to help set the curl.
- **Device turns off unexpectedly:**
 - The device has an automatic 5-minute shut-off feature. If you are not actively using it, it will power down.
 - If it turns off during active use, it may need to be recharged.

7. SPECIFICATIONS

Feature	Detail
Model Number	Udream
Brand	ZEYUMEE
Item Weight	4.2 ounces
Package Dimensions	6.26 x 3.39 x 1.85 inches
Battery Capacity	230mAh
Charging Type	Type-C USB
Low Temperature Setting	65 °C / 149 °F (Green Light)
High Temperature Setting	85 °C / 185 °F (Blue Light)
Automatic Shut-off	After 5 minutes of stopping use

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact the retailer where the ZEYUMEE Udream Heated Eyelash Curler was purchased. Keep your proof of purchase for any warranty claims.