

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [ABUS](#) /

› [ABUS Adaptor Chain 6KS Instruction Manual](#)

ABUS 11267

ABUS Adaptor Chain 6KS Instruction Manual

Model: 11267

PRODUCT OVERVIEW

The ABUS Adaptor Chain 6KS is designed to enhance the security of your bicycle when used in conjunction with compatible ABUS frame locks. This 6 mm thick square chain, made from hardened steel, provides an additional layer of protection by allowing you to secure your bicycle to a fixed object, preventing it from being easily carried away. Its plastic coating protects your bicycle's paintwork from scratches and damage.



This image displays the ABUS Adaptor Chain 6KS in its coiled state, highlighting the robust 6 mm thick square chain links. The black fabric sleeve protects the bicycle frame from scratches. The specialized insertion bolt, designed to connect with compatible ABUS frame locks, is visible at one end.

SETUP AND INSTALLATION

The Adaptor Chain 6KS is designed for seamless integration with specific ABUS frame locks. No additional key is required, as the existing key for your frame lock will operate both components.

Compatible ABUS Frame Locks:

- Pro Tectic 4960
- Pro Tectic 5750L
- Pro Shield 5850
- Pro Shield 5650
- Pro Shield Plus 5950
- Also compatible with 4650 and 4750 models.

Installation Steps:

1. Ensure your bicycle is stationary and stable.
2. Locate the lock housing on your compatible ABUS frame lock.
3. Insert the specialized bolt of the Adaptor Chain 6KS into the designated slot on the frame lock.
4. Once inserted, the chain is ready for use. The frame lock's key will now control both the frame lock and the adaptor chain.



Rahmenschlosskette
aus gehärtetem Stahl

6 mm starke
Vierkantkette

Passend für die Rahmen-
schlösser 4650, 4750, 4960,
5850, 5650, 5750 und 5950



This diagram provides a visual breakdown of the ABUS Adaptor Chain 6KS's key features. It highlights that the chain is made from hardened steel for enhanced security and features a 6 mm thick square chain design. The diagram also lists the compatible ABUS frame lock models: 4650, 4750, 4960, 5850, 5650, 5750, and 5950, indicating the versatility of this accessory.

OPERATING INSTRUCTIONS

To secure your bicycle using the Adaptor Chain 6KS:

1. Ensure the Adaptor Chain 6KS is properly inserted into your compatible ABUS frame lock.
2. Wrap the chain around a sturdy, fixed object such as a lamppost, bike rack, or railing.
3. Pass the free end of the chain through a part of your bicycle's frame or wheel.
4. Connect the free end of the chain back to the frame lock, if applicable, or ensure it is securely looped around the fixed object and the bicycle.
5. Engage the frame lock using its key to secure both the frame lock and the adaptor chain.



Here, the ABUS Adaptor Chain 6KS is shown in practical use, securing a bicycle to a sturdy pole. The chain wraps around both the bicycle frame and the fixed object, providing additional security beyond the frame lock alone. This demonstrates how the chain extends the locking capabilities of the bicycle.



This image illustrates another practical application of the ABUS Adaptor Chain 6KS, where it is used to secure a bicycle to a bridge railing. The chain's length allows for flexible attachment to various fixed objects, enhancing the bicycle's security by preventing it from being easily carried away.

MAINTENANCE

To ensure the longevity and optimal performance of your ABUS Adaptor Chain 6KS, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the chain and its plastic coating with a damp cloth to remove dirt and grime. Avoid harsh chemicals that could damage the coating.
- **Lubrication:** Periodically apply a small amount of bicycle chain lubricant to the metal parts of the insertion bolt to ensure smooth operation.
- **Storage:** Store the chain in a dry place when not in use to prevent rust, especially if it has been exposed to moisture.
- **Inspection:** Regularly inspect the chain for any signs of wear, damage, or corrosion. If significant damage is observed, consider replacing the chain for continued security.

TROUBLESHOOTING

If you encounter any issues with your ABUS Adaptor Chain 6KS, please consider the following:

- **Difficulty Inserting/Removing:** Ensure the insertion bolt is clean and free of debris. A small amount of lubricant on the bolt may help. Verify that you are using a compatible ABUS frame lock.
- **Chain Not Securing:** Double-check that the chain is fully inserted into the frame lock and that the frame lock itself is functioning correctly.
- **Damage to Coating:** While the plastic coating is durable, sharp objects can damage it. This does not affect the security of the hardened steel chain but may reduce aesthetic appeal.

For persistent issues or concerns not addressed here, please contact ABUS customer support.

SPECIFICATIONS

Model Number	11267
Length	85 cm
Chain Thickness	6 mm (square chain)
Material	Hardened Alloy Steel
Weight	700 g
Color	Black
Special Features	Key Unlock (operates with compatible frame lock key)

Compatible Frame Locks

ABUS Pro Tectic 4960, 5750L; Pro Shield 5850, 5650; Pro Shield Plus 5950; 4650, 4750

WARRANTY AND SUPPORT

For information regarding warranty coverage for your ABUS Adaptor Chain 6KS, please refer to the warranty documentation provided with your original purchase or visit the official ABUS website. ABUS stands by the quality of its products.

If you require technical assistance, have questions about product compatibility, or need to report an issue, please contact ABUS customer support through their official channels. Contact details can typically be found on the ABUS website or product packaging.

© 2024 ABUS. All rights reserved.