Milwaukee 2367-20

Milwaukee M12 Rover Service Repair Flood Light with USB Charging - Model 2367-20 Instruction Manual

Introduction Safety Information Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

This manual provides essential instructions for the safe and effective use of your Milwaukee M12 Rover Service Repair Flood Light with USB Charging, Model 2367-20. Please read this manual thoroughly before operating the tool and retain it for future reference. This flood light is designed to provide high-definition illumination for various service and repair tasks, featuring a durable construction and a convenient USB charging port for mobile devices.



Figure 1: Front view of the Milwaukee M12 Rover Flood Light.

2. Important Safety Information

WARNING: Read all safety warnings, instructions, illustrations, and specifications provided with this power tool. Failure to follow all instructions listed below may result in electric shock, fire, and/or serious injury.

- **Eye Protection:** Always wear appropriate eye protection when operating the flood light.
- **Avoid Direct Eye Exposure:** Do not stare directly into the light beam. The intense light can cause temporary vision impairment or permanent eye damage.
- **Flammable Materials:** Do not operate the light near flammable liquids, gases, or dust. The light can generate heat

that may ignite these materials.

- **Battery Safety:** Use only Milwaukee M12 batteries and chargers. Refer to the battery and charger manuals for specific safety instructions.
- **Water Resistance:** The light is water-resistant (IP54 rated), but it is not submersible. Do not immerse the light in water.
- **Children:** Keep the light out of reach of children.

3. Setup

3.1 Package Contents

The Milwaukee M12 Rover Service Repair Flood Light (Model 2367-20) is typically sold as a bare tool. Battery and charger are sold separately.

3.2 Battery Installation and Removal

1. To install the battery, align the battery pack with the base of the light. Slide the battery into the light until it latches securely into place.
2. To remove the battery, press the release button on the battery pack and slide the battery out of the light.



Figure 2: Back view showing the M12 battery slot.

3.3 Initial Charging

Ensure the M12 battery pack is fully charged before first use. Refer to your Milwaukee M12 battery charger's instruction manual for proper charging procedures.

4. Operating Instructions

4.1 Powering On/Off and Light Modes

The flood light features a power button and a battery fuel gauge. Press the power button to cycle through the available

light modes (if multiple are present) and to turn the light off. The light typically has a single brightness setting for flood illumination.



Figure 3: Top view showing controls and USB port.

4.2 USB Charging Function

The integrated USB-A port allows you to charge compatible electronic devices. To use this feature:

1. Ensure a charged M12 battery is installed in the flood light.
2. Connect your device's USB charging cable to the USB-A port on the flood light.
3. The flood light will begin charging your device. The battery fuel gauge LEDs may indicate the remaining battery

charge.

4.3 Battery Fuel Gauge

The battery fuel gauge consists of LED lights that indicate the remaining charge of the M12 battery pack. Press the fuel gauge button to activate the indicators. The number of illuminated LEDs corresponds to the approximate remaining battery capacity.

4.4 Mounting Options

The flood light is designed with versatile mounting options, including an integrated keyhole hanger for hanging and a magnetic base for attaching to metal surfaces. This allows for hands-free operation in various work environments.

5. Maintenance

5.1 Cleaning

Keep the light clean from dust, dirt, oil, and grease. Use a soft, damp cloth for cleaning. Do not use caustic agents or solvents, as these can damage plastic parts.

5.2 Storage

Store the flood light in a dry, secure location away from direct sunlight and extreme temperatures. Remove the battery pack if storing for extended periods.

5.3 Battery Care

For optimal battery life, store M12 battery packs in a cool, dry place. Do not store fully discharged batteries. Recharge them periodically if not in use.

6. Troubleshooting

Problem	Possible Cause	Solution
Light does not turn on.	Battery is not installed correctly or is discharged.	Ensure battery is fully seated. Charge the battery pack.
USB port not charging device.	Battery is too low or device is incompatible.	Charge the M12 battery. Verify device compatibility and cable connection.
Light output is dim.	Battery is low.	Recharge the M12 battery pack.

7. Specifications

Feature	Detail
Model Number	2367-20
Power Source	Battery Powered (M12 Lithium-Ion)
Voltage	12.0 V
Light Source Type	LED

Feature	Detail
Light Output Maximum	700 Lumens
Color Rendering Index (CRI)	85
Beam Angle	120 Degrees
Material	Plastic, Iron
Weight	0.74 Pounds
Dimensions (L x W x H)	1"L x 1"W x 1"H (Approximate, refer to product for exact)
Ingress Protection (IP) Rating	IP54

8. Warranty and Support

8.1 Warranty Information

This Milwaukee product is covered by a manufacturer's warranty. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty card included with your product or visit the official Milwaukee website. Keep your proof of purchase for warranty claims.

8.2 Customer Support

For technical assistance, service, or replacement parts, please contact Milwaukee customer support. You can find contact information on the official Milwaukee website or in the documentation provided with your product.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question