

Heller HLPFH2

Heller 2000W Low Profile Fan Heater

Instruction Manual

1. INTRODUCTION

This manual provides important information for the safe and efficient operation of your Heller 2000W Low Profile Fan Heater. Please read it thoroughly before use and retain it for future reference.

The Heller 2000W Low Profile Fan Heater delivers powerful warmth in a sleek and unobtrusive design. It is perfect for use in small to medium-sized rooms, such as bedrooms, living rooms, or home offices, rapidly warming up your space for a comfortable environment during colder months.

Key Features:

- Low-profile construction ideal for discreet placement in any room.
- Multiple heat and fan speed settings for customized warmth.
- Overheat protection and tip-over safety switch.
- Silent performance suitable for bedrooms or living spaces.
- Lightweight and easy to move from room to room.

2. SAFETY INFORMATION

IMPORTANT SAFETY INSTRUCTIONS: Read all instructions before using this heater.

- Do not use this heater in bathrooms, laundry areas, or similar indoor locations where water may be present.
- Do not operate any heater with a damaged cord or plug, or after the heater malfunctions or has been dropped or damaged in any manner.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect heater, turn controls to OFF, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.

- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. If provided, use handles when moving this heater.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Always unplug heater when not in use.

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Heller Fan Heater.



Figure 3.1: Front view of the Heller 2000W Low Profile Fan Heater, showing the main grille and control knobs on top.



Figure 3.2: Side view of the Heller 2000W Low Profile Fan Heater, illustrating its dimensions: 28.2cm height, 21.7cm width, and 13.7cm depth.

Components:

1. Power Indicator Light
2. Thermostat Control Knob
3. Function Selector Knob (Off/Fan/Low Heat/High Heat)
4. Air Outlet Grille
5. Power Switch (On/Off)
6. Base

4. SETUP

1. **Unpacking:** Carefully remove the heater from its packaging. Retain the packaging for storage or future transport.
2. **Placement:** Place the heater on a firm, level surface. Ensure there is at least 1 meter (3 feet) of clear space around the heater from walls, furniture, curtains, and other flammable materials.
3. **Power Connection:** Ensure the heater is switched OFF (Function Selector Knob to 'OFF' and Power Switch to 'O'). Plug the power cord into a standard 220-240V AC, 50Hz electrical outlet. Do not use extension cords or power boards.

5. OPERATING INSTRUCTIONS

1. **Power On:** Turn the Power Switch to the 'I' (On) position. The power indicator light will illuminate.
2. **Select Function:**
 - **Fan Only:** Turn the Function Selector Knob to the fan symbol (usually a fan blade icon). The heater will operate as a fan without heat.
 - **Low Heat (1000W):** Turn the Function Selector Knob to 'I' or 'Low Heat'.
 - **High Heat (2000W):** Turn the Function Selector Knob to 'II' or 'High Heat'.
3. **Set Thermostat:** Turn the Thermostat Control Knob clockwise to increase the desired temperature setting. Turn it

counter-clockwise to decrease. The heater will cycle on and off to maintain the set temperature. For continuous heating, turn the thermostat to its maximum setting.

4. **Power Off:** To turn off the heater, first turn the Function Selector Knob to 'OFF', then turn the Power Switch to 'O'. Finally, unplug the heater from the wall outlet.

6. MAINTENANCE

Cleaning:

- Always unplug the heater from the power outlet and allow it to cool completely before cleaning.
- Use a soft, damp cloth to wipe the exterior surfaces of the heater. Do not use abrasive cleaners or solvents.
- Use a vacuum cleaner with a brush attachment to remove dust from the air intake and outlet grilles.
- Never immerse the heater in water or any other liquid.

Storage:

- When not in use, store the heater in a cool, dry place.
- It is recommended to store the heater in its original packaging to protect it from dust and damage.
- Do not wrap the power cord tightly around the heater.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Heater does not turn on.	No power to the unit. Overheat protection activated. Tip-over switch activated.	Check if the power cord is securely plugged into a working outlet. Unplug the heater, wait 30 minutes for it to cool down, then plug it back in. Ensure the heater is on a firm, level surface.
Heater produces no heat.	Function selector set to Fan Only. Thermostat set too low.	Turn the Function Selector Knob to 'I' (Low Heat) or 'II' (High Heat). Turn the Thermostat Control Knob clockwise to a higher setting.
Heater cycles on and off frequently.	Thermostat setting is close to room temperature.	Adjust the thermostat to a higher setting if more heat is desired, or a lower setting if the room is too warm.

8. SPECIFICATIONS

Brand	Heller
Model Number	HLPFH2

Colour	White
Product Dimensions	13.7 x 21.7 x 28.2 cm
Item Weight	1 kg
Power Output	2000W
Special Features	Portable, Overheat Protection, Tip-over Safety Switch

9. WARRANTY AND SUPPORT



This Heller product comes with a standard manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details.





For technical support, troubleshooting assistance, or warranty claims, please contact Heller customer service. Contact details can typically be found on the product packaging or the official Heller website.

Please have your model number (HLPFH2) and proof of purchase ready when contacting support.

© 2024 Heller. All rights reserved.
Model: HLPFH2
Date of Manual: July 2024

Related Documents - HLPFH2

	<p>Heller HIH20 Infrared Instant Heater 2000W User Manual</p> <p>User manual for the Heller HIH20 Infrared Instant Heater 2000W, providing comprehensive safety instructions, assembly guidance, operating procedures, and maintenance tips for optimal performance and longevity.</p>
	<p>Heller HCFHU2000 Ceramic Oscillating Fan Heater 2000W User Manual</p> <p>User manual for the Heller HCFHU2000 Ceramic Oscillating Fan Heater 2000W, providing essential safety instructions, operation guidance, features, and technical specifications for optimal use.</p>

 <p>The image shows the cover of the user manual for the HELLER HBH2000 Wall-Mounted Fan Heater. It features the HELLER logo at the top, followed by the product name and model number. Below the text is a photograph of the white, rectangular wall-mounted heater.</p>	<p>HELLER HBH2000 Wall-Mounted Fan Heater User Manual 1800-2000W</p> <p>Comprehensive user manual for the HELLER HBH2000 wall-mounted fan heater. Includes installation, operation, safety guidelines, and cleaning instructions for this 1800-2000W appliance.</p>
 <p>The image shows the cover of the user manual for the HELLER HWH2000 Ceramic Wall Heater with LED Display. It features the HELLER logo at the top, followed by the product name and model number. Below the text is a photograph of the white, rectangular wall heater with a small digital display on the right side.</p>	<p>HELLER HWH2000 Ceramic Wall Heater User Manual - Installation, Operation & Safety Guide</p> <p>Comprehensive user manual for the HELLER HWH2000 Ceramic Wall Heater with LED Display. Includes installation instructions, operating procedures, safety precautions, controls, specifications, and customer service information.</p>
 <p>The image shows the cover of the user manual for the HELLER HTF2000 Ceramic Oscillating Tower Heater. It features the HELLER logo at the top, followed by the product name and model number. Below the text is a photograph of the white, vertical tower heater with a circular oscillating head.</p>	<p>Heller HTF2000 Ceramic Oscillating Tower Heater User Manual</p> <p>Comprehensive user manual for the Heller HTF2000 Ceramic Oscillating Tower Heater, detailing important safety precautions, operating instructions, product features, cleaning and maintenance, and customer service information.</p>
 <p>The image shows the cover of the instruction manual for the HELLER HPH20 Aluminium WiFi Panel Heater. It features the HELLER logo at the top, followed by the product name and model number. Below the text is a photograph of the white, rectangular panel heater with a small control panel on the right side.</p>	<p>Heller HPH20 Aluminium WiFi Panel Heater 2000W Instruction Manual</p> <p>This instruction manual provides comprehensive guidance for the Heller HPH20 Aluminium WiFi Panel Heater (2000W). It covers important safety precautions, installation steps, product operation, control panel functions, Wi-Fi connectivity via the GAFSmartLife app, maintenance procedures, warranty information, and environmentally friendly disposal.</p>