

[Manuals.plus](#) /

› [Torchlet](#) /

› Torchlet Floor Lamp User Manual

Torchlet FL123

Torchlet Floor Lamp User Manual

Model: FL123 | Brand: Torchlet

INTRODUCTION

The Torchlet Floor Lamp is a modern RGB floor lamp designed to enhance your living space with customizable lighting. Featuring 16 million DIY colors, various scene modes, and music sync capabilities, it offers versatile illumination for living rooms, game rooms, and bedrooms. Control is convenient via app, remote, or base buttons.




Image: The Torchlet Floor Lamp displaying a spectrum of colors in a modern living room setting, highlighting its aesthetic appeal and color-changing capabilities.

What's in the Box

Please ensure all the following components are present in your package:

- 1 x Fabric Lampshade
- 1 x Remote Control
- 1 x Power Adapter
- 1 x LED Strip Light (integrated)
- 1 x Balance Heavy Base
- 1 x Plastic Head Screw
- 8 x Supporting Tubes (for lamp pole assembly)
- 2 x Internal Tooth Rings

SETUP AND INSTALLATION

Follow these steps to assemble your Torchlet Floor Lamp:

1. **Assemble the Base:** Screw the first pole segment into the heavy base until secure.
2. **Connect Pole Segments:** Connect the remaining supporting tubes one by one, ensuring they are firmly joined to form the complete lamp pole.
3. **Install LED Strip:** Carefully unroll and attach the LED strip light along the length of the assembled pole. Ensure the strip is securely fastened and its connector is accessible at the top.
4. **Attach Lampshade:** Gently slide the fabric lampshade over the pole. Secure the lampshade to the top of the pole using the provided internal tooth rings and plastic head screw. Ensure the shade is taut and evenly distributed.
5. **Connect Power:** Plug the power adapter into the lamp's control unit, and then plug the adapter into a standard power outlet.

Your browser does not support the video tag.

Video: A step-by-step guide demonstrating the assembly process of the Torchlet Floor Lamp, from connecting the base to attaching the lampshade and LED strip.

OPERATING INSTRUCTIONS

Control Methods

The Torchlet Floor Lamp offers three convenient control methods:

- **Remote Control:** Use the included remote to power on/off, change colors, adjust brightness, and select scene modes.
- **Base Buttons:** The lamp's base features physical buttons for basic power and mode control.
- **"duoCo StripX" APP:** For full functionality, download and use the "duoCo StripX" app on your smartphone. The app allows for color selection, brightness/speed adjustment, timer settings, and access to multiple scene and music modes.



Image: Visual representation of the three control methods available for the Torchlet Floor Lamp: a smartphone displaying the app interface, the physical remote control, and the control buttons located on the lamp's base.

App Pairing (WiFi)

To unlock all smart features, pair your lamp with the "duoCo StripX" app:

1. Download the "duoCo StripX" app from your device's app store.
2. Open the app and select "Add Device". Choose "Lighting" then "Light Source (WiFi)".
3. Ensure your mobile phone is connected to a 2.4 GHz WiFi network. Enter the WiFi network name and password in the app.
4. Power on the lamp. Turn it off and on three times (on-off-on-off-on) to put it into pairing mode. The light should blink rapidly.
5. Confirm in the app that the light is blinking rapidly and follow the on-screen instructions to complete the connection.

Your browser does not support the video tag.

Video: A detailed tutorial on how to pair your smartphone with the Torchlet Floor Lamp using the dedicated mobile application, including steps for WiFi connection and device reset for pairing.

Color and Scene Modes

Explore 16 million DIY colors and over 213 static and dynamic scene modes to create your desired ambiance. Use the app to customize colors, adjust brightness, and set timers for automated lighting.



Image: The Torchlet Floor Lamp showcasing a wide spectrum of colors and dynamic lighting effects, illustrating the 16 million color options and various scene modes available.

Music Sync Mode

Activate the music rhythm mode via the app to synchronize the lamp's lighting with music or other sounds from your computer, TV, or films. This creates an immersive atmosphere for parties, gaming, or relaxation.



Image: A room with the Torchlet Floor Lamp displaying dynamic lighting, synchronized with music, creating a lively atmosphere.

Your browser does not support the video tag.

Video: A demonstration of the Torchlet RGB Floor Lamp's music sync feature, showing the lamp's lights changing in rhythm with music playing in the background.

MAINTENANCE

To ensure the longevity and optimal performance of your Torchlet Floor Lamp, follow these maintenance guidelines:

- **Cleaning:** Gently wipe the fabric lampshade with a soft, dry cloth to remove dust. For the base and pole, use a slightly damp cloth and dry immediately. Avoid abrasive cleaners or solvents.
- **Bulb Replacement:** The LED strip is designed for long-term use and is not user-replaceable. If you experience issues with the lighting, please contact customer support.
- **Placement:** Place the lamp on a stable, flat surface away from direct sunlight, heat sources, and excessive moisture. Ensure adequate ventilation around the lamp.
- **Cable Care:** Regularly inspect the power cord and adapter for any signs of damage. Do not use if damaged.

TROUBLESHOOTING

If you encounter any issues with your Torchlet Floor Lamp, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lamp does not turn on.	No power, loose connection, faulty adapter.	Check power outlet. Ensure all connections are secure. Try a different outlet.
Remote control not working.	Dead battery, remote out of range, obstruction.	Replace remote battery. Ensure remote is pointed at the lamp's receiver and within range. Remove any obstructions.
App cannot connect to the lamp.	Incorrect WiFi password, 5GHz WiFi, lamp not in pairing mode.	Verify WiFi password. Ensure your phone is on a 2.4 GHz network. Reset the lamp to pairing mode (on-off-on-off-on).
Colors are not accurate or flickering.	Loose LED strip connection, software glitch.	Check the LED strip connection to the control unit. Restart the lamp by unplugging and replugging it. Update the app to the latest version.

SPECIFICATIONS

Feature	Detail
Brand	Torchlet
Model Number	FL123
Product Dimensions	9.1"D x 9.1"W x 61"H
Item Weight	3.3 Pounds
Lamp Type	Floor Lamp

Feature	Detail
Shade Material	Fabric
Light Source Type	LED
Special Feature	Color Changing, Dimmable, Adjustable Color Temperature
Control Method	App, Remote
Connectivity Technology	Bluetooth
Brightness	1500 Lumen
Voltage	265 Volts
Wattage	11 Watt-hours
Indoor/Outdoor Usage	Indoor

WARRANTY AND SUPPORT

Torchlet products are manufactured with high-quality materials and craftsmanship. For warranty information, technical support, or any inquiries regarding your Torchlet Floor Lamp, please refer to the official Torchlet website or contact their customer service directly.

You can also find additional resources and a downloadable user guide at:[Torchlet User Guide \(PDF\)](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question