

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [vidaXL](#) /

> [vidaXL Scandi-Style Engineered Wood Drawer Bottom Cabinet - 15.7" x 18.1" x 32.1" - Instruction Manual](#)

vidaXL 1x bottom cabinet (1 door 1 drawer)

vidaXL Scandi-Style Engineered Wood Drawer Bottom Cabinet - Instruction Manual

Model: 1x bottom cabinet (1 door 1 drawer)

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your vidaXL Scandi-Style Engineered Wood Drawer Bottom Cabinet. This durable kitchen storage solution is designed to optimize your space with its well-organized shelves and drawer. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Product Dimensions: 15.7" (W) x 18.1" (D) x 32.1" (H)

2. SAFETY INFORMATION

- **Wall Attachment:** For stability and safety, this product **must** be used with the wall attachment device provided. Securely fasten the cabinet to a wall to prevent tipping.
- **Weight Limit:** Do not exceed the maximum weight limit of 25 kilograms (approximately 55 pounds) for the entire cabinet. Distribute weight evenly.
- **Assembly:** Ensure all components are correctly assembled and tightened according to the instructions. Loose parts can cause instability.
- **Children:** Keep small parts and packaging materials away from children during assembly to prevent choking hazards.
- **Proposition 65 Warning:** This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

3. PACKAGE CONTENTS

Before assembly, verify that all parts are present and undamaged. If any parts are missing or damaged, contact customer support immediately. The package typically includes:

- Engineered wood panels (sides, top, bottom, back, door, drawer front, shelf)
- Hardware kit (screws, dowels, cam locks, hinges, drawer runners, handles, adjustable feet, wall

attachment device)

- Assembly instructions (may be in German, refer to this manual for English guidance)

4. ASSEMBLY INSTRUCTIONS

Assembly is required for this cabinet. Follow these general steps. Refer to the included diagram for specific part identification and orientation.

4.1. Tools Required

- Phillips head screwdriver
- Hammer (optional, for dowels)
- Drill (for wall attachment, if not pre-drilled)
- Level

4.2. Step-by-Step Assembly

1. **Unpack and Identify Parts:** Lay out all panels and hardware on a clean, soft surface to prevent scratches. Identify each part using the provided diagrams.
2. **Assemble the Base:** Attach the adjustable feet to the bottom panel of the cabinet. Ensure they are securely fastened.
3. **Construct the Frame:** Connect the side panels to the bottom and top panels using dowels and cam locks. Ensure all connections are tight and the frame is square.
4. **Install Drawer Runners:** Attach the drawer runners to the interior side panels of the cabinet according to the instructions. Ensure they are level and aligned.
5. **Assemble the Drawer:** Construct the drawer box using the smaller panels and hardware. Attach the drawer front and handles. Insert the assembled drawer into the cabinet runners.
6. **Attach Door Hinges:** Secure the hinges to the cabinet door and then to the cabinet frame. Adjust hinges as needed for proper door alignment.
7. **Insert Shelf:** Place the adjustable shelf into the desired position using the pre-drilled holes and shelf pins.
8. **Attach Back Panel:** Secure the back panel to the cabinet frame using small nails or screws.
9. **Wall Attachment:** Position the cabinet in its desired location. Using the provided wall attachment device, secure the cabinet to a sturdy wall stud. This is critical for safety.




Figure 1: Cabinet dimensions and internal measurements. The cabinet measures 40 cm wide, 81.5 cm high, with a drawer height of 9 cm and internal shelf space of 33.5 cm and 17.5 cm. The depth is 46 cm.



Figure 2: Cabinet with door open, revealing an adjustable internal shelf for storage.



Quality
metal
runners

Smooth movement

Easy access to your stored items

Elegant
handles

Figure 3: Detail of the quality metal drawer runners for smooth movement and the elegant metal handles.




Figure 4: An adjustable cabinet foot, allowing for height customization and leveling on uneven surfaces.

5. USAGE INSTRUCTIONS

This cabinet is designed for general kitchen storage, suitable for items such as crockery, utensils, and pantry goods.

- **Drawer Operation:** Pull the handle gently to open the drawer. Push firmly to close. Avoid slamming the drawer to ensure longevity of the runners.
- **Door Operation:** Pull the handle to open the cabinet door. Push firmly to close. The hinges allow for smooth opening and closing.

- **Shelf Adjustment:** The internal shelf can be adjusted to different heights. To adjust, remove any items from the shelf, lift the shelf, remove the shelf pins from their current holes, reinsert them into the desired holes, and then place the shelf back on the pins.
- **Weight Distribution:** Distribute items evenly across shelves and within the drawer to maintain stability and prevent damage to the cabinet structure.

6. MAINTENANCE

Proper care will ensure the longevity and appearance of your cabinet.

- **Cleaning:** Wipe the cabinet surfaces with a damp cloth. For stubborn marks, a mild, non-abrasive cleaner can be used. Dry immediately with a clean cloth.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or strong chemical agents, as these can damage the painted finish and engineered wood.
- **Spills:** Clean up spills immediately to prevent moisture damage to the engineered wood.
- **Hardware Check:** Periodically check all screws, bolts, and fittings to ensure they remain tight. Retighten as necessary.

7. TROUBLESHOOTING

If you encounter issues during assembly or use, refer to these common solutions.

- **Missing Parts:** If any parts are missing from the package, contact vidaXL customer support with your product model number and a description of the missing part.
- **Difficulty Assembling:** Ensure you are following the steps in the correct order. Check that all cam locks and dowels are properly aligned and fully inserted. Do not force parts together.
- **Wobbly Cabinet:** Verify that all screws are tightened. Ensure the adjustable feet are properly leveled on the floor. Confirm the cabinet is securely attached to the wall using the provided anti-tip device.
- **Drawer/Door Not Closing Properly:** Check that the drawer runners or door hinges are correctly installed and aligned. Adjust hinges if necessary. Ensure no obstructions are preventing full closure.

8. SPECIFICATIONS

Brand	vidaXL
Model Name	Drawer Bottom Cabinet
Item Model Number	1x bottom cabinet (1 door 1 drawer)
Color	White
Material	Engineered Wood
Product Dimensions (W x D x H)	15.7" x 18.1" x 32.1" (40 cm x 46 cm x 81.5 cm)
Item Weight	17 Kilograms (37.4 pounds)
Weight Limit	25 Kilograms
Number of Shelves	2 (1 adjustable)
Number of Compartments	3 (1 drawer, 2 behind door)

Mounting Type	Floor Mount (with wall attachment)
Assembly Required	Yes
Care Instructions	Wipe with Damp Cloth

9. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the purchase documentation or contact vidaXL directly through their official website or the retailer where the product was purchased. Ensure you have your proof of purchase and product model number available when contacting support.

vidaXL Official Website: www.vidaxl.com