

[Manuals.plus](#) /

› [Scosche](#) /

› Scosche Base3 3-in-1 Wireless Charging Dock (Model CSQ3N1WT-SP) Instruction Manual

Scosche CSQ3N1WT-SP

Scosche Base3 3-in-1 Wireless Charging Dock

Model: CSQ3N1WT-SP

INTRODUCTION

The Scosche Base3 3-in-1 wireless charging dock is a Qi-certified wireless charging station designed for convenience. It allows for simultaneous wireless charging of a Qi-enabled smartphone, an Apple Watch, and a Wireless Charging Case for earbuds. This device is Qi-Certified for safety and compatibility, ensuring efficient charging for compatible devices. It also features foreign object detection to prevent charging when obstructions are present.



Front view of the white Scosche Base3 3-in-1 Wireless Charging Dock, showcasing its design for charging multiple devices.

PACKAGE CONTENTS

Verify that all items are present in the package:

- Scosche Base3 3-in-1 Wireless Charging Dock
- 3 ft. USB-C to USB-C power cable
- 20W USB wall adapter plug

KEY FEATURES

- **Qi-Certified Wireless Charging:** Compatible with Qi-enabled smartphones, smartwatches, earbuds, and wireless charging cases.
- **Foreign Object Detection:** Prevents charging when foreign objects obstruct the charging areas.
- **Simultaneous Charging:** Capable of charging three devices concurrently.

- **Apple MFi Certified:** Ensures full compatibility with all Apple Watch series.
- **Wide Compatibility:** Supports most smartphones, smartwatches, earbuds, and wireless carrying cases that are Qi-enabled.

SETUP INSTRUCTIONS

1. **Unpack:** Carefully remove the charging dock, USB-C cable, and wall adapter from the packaging.
2. **Connect Power Cable:** Insert one end of the included 3 ft. USB-C to USB-C power cable into the USB-C port located on the back of the Base3 charging dock.
3. **Connect Wall Adapter:** Plug the other end of the USB-C cable into the 20W USB wall adapter plug.
4. **Power On:** Insert the wall adapter into a standard electrical outlet. The LED indicator on the charging dock will illuminate, signaling that the device is powered on and ready for use.



Rear view of the white Scosche Base3 3-in-1 Wireless Charging Dock, showing the USB-C port for power connection.

OPERATING INSTRUCTIONS

The Base3 charging dock allows for wireless charging of up to three compatible devices simultaneously.

Charging a Smartphone

1. Ensure the charging dock is powered on.
2. Place your Qi-enabled smartphone vertically on the left charging pad of the dock.
3. Ensure the phone is centered on the charging area for optimal contact. Charging will begin automatically.

Charging an Apple Watch

1. Ensure the charging dock is powered on.
2. Place your Apple Watch on the dedicated magnetic charging module on the right side of the dock.
3. The watch will magnetically align and charging will commence.

Charging Earbuds (with Wireless Charging Case)

1. Ensure the charging dock is powered on.
2. Place your earbuds' wireless charging case into the designated slot above the Apple Watch charging module.
3. Ensure the case is properly seated. Charging will begin automatically.



The Scosche Base3 3-in-1 Wireless Charging Dock in white, efficiently charging an iPhone, Apple Watch, and AirPods simultaneously.

QUICKLY AND SAFELY CHARGE

Your Phone, Apple® Watch and AirPods®

**20W USB-C Charger
and 3ft Cable Included** ▶



The Scosche Base3 3-in-1 Wireless Charging Dock in white, shown connected to a wall outlet and actively charging an iPhone, Apple Watch, and AirPods.



MFi CERTIFIED

Apple Watch® and AirPods® Charger

A close-up view of the Apple Watch and AirPods charging section of the Scosche Base3 dock, highlighting its MFi certification.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surface of the charging dock. Avoid abrasive cleaners or solvents.
- **Power Disconnection:** Disconnect the power adapter from the wall outlet when the device is not in use for extended periods.
- **Avoid Obstructions:** Ensure no foreign objects are placed on the charging surfaces to prevent interference with the foreign object detection feature and potential damage.

TROUBLESHOOTING

Issue	Possible Cause	Solution
-------	----------------	----------

Issue	Possible Cause	Solution
Device not charging	1. Device not Qi-enabled. 2. Improper placement. 3. Foreign object detected. 4. Power not connected.	1. Verify device compatibility. 2. Re-position device centrally on the charging pad. 3. Remove any objects (e.g., metal, credit cards) from the charging surface. 4. Ensure power cable and adapter are securely connected and plugged into a live outlet.
Slow charging	1. Device case thickness. 2. Background apps/usage.	1. Remove thick phone cases. Wireless charging works best with cases 3mm or thinner. 2. Close unnecessary applications on your device.
LED indicator not lit	No power supply.	Check all power connections from the wall outlet to the charging dock. Try a different outlet.

SPECIFICATIONS

- **Model Number:** CSQ3N1WT-SP
- **Product Dimensions:** 3.4 x 8.25 x 8.75 inches
- **Item Weight:** 10.4 ounces
- **Connector Type:** USB Type C
- **Input Voltage:** 1 Volts
- **Amperage:** 10 Amps
- **Total USB Ports:** 1 (for power input)
- **Special Feature:** Charging Indicator, Wireless Charging
- **Color:** White
- **Manufacturer:** SCOSCHE
- **First Available:** October 25, 2021

WARRANTY AND SUPPORT

The Scosche Base3 3-in-1 Wireless Charging Dock (Model CSQ3N1WT-SP) is backed by a **three-year warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical support, or additional product information, please visit the official Scosche website or contact their customer service department.

You can also find more information and support resources by visiting the [Scosche Store on Amazon](#).

© 2023 Scosche Industries. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09K9DLQ84>

More documents and user manuals: <https://manuals.plus/>