

DeLUX M618XSU

DeLUX Seeker M618XSU Wired Ergonomic Vertical Mouse User Manual

Model: M618XSU

1. INTRODUCTION

The DeLUX Seeker M618XSU is a wired ergonomic vertical mouse designed to provide a comfortable and natural hand position, reducing wrist strain often associated with traditional mice. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your new mouse. Key features include a unique vertical design, a thumb wheel for horizontal scrolling, adjustable DPI settings, RGB backlighting, and a magnetic detachable wrist rest.



Image 1.1: The DeLUX Seeker M618XSU vertical mouse, highlighting its ergonomic design and thumb wheel feature.

2. PACKAGE CONTENTS

- DeLUX Seeker M618XSU Wired Ergonomic Vertical Mouse
- Magnetic Detachable Wrist Rest
- User Manual (this document)

3. PRODUCT DIAGRAM & COMPONENTS

Familiarize yourself with the various parts of your DeLUX Seeker M618XSU mouse.



Image 3.1: Front-side view of the DeLUX Seeker M618XSU mouse with its ergonomic vertical design and RGB lighting.

EXPLORE IN A NEW DIRECTION



4 way navigation.
Horizontally and vertically scrolling.



◀ **NORMAL
WHEEL**

**THUMB
WHEEL**



Image 3.2: Detail showing the normal scroll wheel for vertical navigation and the thumb wheel for horizontal navigation.

1. **Left Click Button:** Standard left mouse button.
2. **Right Click Button:** Standard right mouse button.
3. **Scroll Wheel:** For vertical scrolling.
4. **Thumb Wheel:** For horizontal scrolling (Note: Not available for Office software and Mac OS).
5. **DPI Button:** To adjust mouse sensitivity.
6. **Forward/Backward Buttons:** For web browser navigation.
7. **RGB Backlight:** Customizable lighting effects.
8. **Magnetic Detachable Wrist Rest:** Provides additional wrist support.

4. SETUP GUIDE

4.1 Connecting the Mouse

1. Locate an available USB port on your computer.
2. Plug the USB connector of the DeLUX Seeker M618XSU mouse into the USB port.
3. Your operating system should automatically detect and install the necessary drivers.

4.2 Attaching the Wrist Rest

The mouse comes with a magnetic detachable wrist rest for enhanced comfort.

1. Align the magnetic connectors on the wrist rest with those on the base of the mouse.
2. The wrist rest will snap into place securely.

YOUR WRIST DESERVE A REST



Magnetic detachable wrist rest



Image 4.1: The DeLUX Seeker M618XSU mouse with its magnetic detachable wrist rest, designed to support the forearm and wrist.

5. BASIC OPERATION

5.1 Left and Right Click

The left and right buttons function as standard mouse clicks. These buttons feature a silent click design, reducing operational noise by over 90%.

5.2 Scroll Wheel (Vertical)

Use the main scroll wheel located on the top of the mouse for vertical scrolling through documents and web pages.

5.3 Thumb Wheel (Horizontal)

The thumb wheel allows for horizontal scrolling, useful for navigating wide spreadsheets or web pages. To use, simply roll the thumb wheel left or right.

Note: The thumb wheel functionality for horizontal scrolling is not available for Office software and Mac OS.

5.4 DPI Adjustment

The DPI (Dots Per Inch) button allows you to adjust the mouse sensitivity and pointer speed. The DeLUX Seeker M618XSU offers five adjustable DPI levels:


- 800 DPI
- 1200 DPI
- 1600 DPI
- 2400 DPI
- 4000 DPI

Press the DPI button repeatedly to cycle through these settings until you find your preferred responsiveness.

LESS MOVEMENT. LESS FATIGUE.



High precision-Up to 4000DPI



5 LEVEL DPI FOR SETTING
EASY ADJUSTMENT

Image 5.1: Illustration of the 5-level DPI settings (800/1200/1600/2400/4000) for precise tracking and easy adjustment.

6. ADVANCED FEATURES

6.1 RGB Lighting Effects

The mouse features five distinct RGB lighting effects. To change the lighting mode or turn off the light, press the main scroll wheel and the back/forward button simultaneously. Continue pressing until the desired lighting mode is active or the light turns off.

6.2 RGB Backlight Sensor

By default, the RGB backlight automatically turns off when the mouse is held to save power. To disable this sensor function:

1. Press and hold the left and right mouse buttons simultaneously.
2. The mouse will flash a white light twice, indicating that the sensor function is off.

Once disabled, the light will remain on even when the mouse is held.

6.3 Programmable Buttons (Windows Only)

The DeLUX Seeker M618XSU features 6 programmable buttons. Customization of these buttons, along with backlight effects and macro management, is available through dedicated software.

GET MORE DONE



On-board memory software setting
Software only for windows




Image 6.1: Screenshot of the DeLUX mouse software interface, showing options for light settings, button settings, macro management, and other configurations. This software is for Windows operating systems only.

7. SOFTWARE INSTALLATION (WINDOWS ONLY)

To unlock the full potential of your DeLUX Seeker M618XSU mouse, including customized backlight effects, programmable buttons, and DPI/report rate adjustments, you can install the official DeLUX software.

Note: This software is compatible with Windows operating systems only. Please visit the official DeLUX website for the latest software download and installation instructions.

8. MAINTENANCE & CARE

8.1 Cleaning the Mouse

To maintain optimal performance and appearance:

- Disconnect the mouse from your computer before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution.
- Avoid using harsh chemicals, abrasives, or solvents.
- Ensure no liquid enters the mouse's internal components.

8.2 Wrist Rest Care

The magnetic wrist rest is removable, replaceable, and cleanable. You can detach it for easier cleaning or replacement if needed.



Image 8.1: The DeLUX Seeker M618XSU mouse demonstrating its exchangeable back cover, which includes the wrist rest component, allowing for easy removal and cleaning.

9. TROUBLESHOOTING

- **Mouse not responding:**
Ensure the USB cable is securely plugged into a working USB port. Try a different USB port or computer to rule out port or system issues.
- **DPI not changing:**
Press the DPI button firmly. Ensure you are cycling through the 5 available DPI settings.
- **RGB lighting not working or behaving unexpectedly:**

Check if the RGB backlight sensor is enabled (default setting). If so, the light will turn off when held. Disable the sensor by holding the left and right buttons simultaneously until a white light flashes twice. Cycle through lighting effects by pressing the scroll wheel and back/forward button simultaneously.

- **Thumb wheel not scrolling horizontally:**

Remember that the thumb wheel's horizontal scrolling function is not supported in Office software or on Mac OS. Ensure you are using it in a compatible application and operating system.

- **Compatibility issues with Mac OS:**

While the mouse is compatible with Mac OS for basic functions, the forward and backward buttons, as well as the thumb wheel's horizontal scrolling, are not available. The customization software is also Windows-only.

10. SPECIFICATIONS

Feature	Detail
Brand	DeLUX
Model Number	M618XSU
Connectivity Technology	Wired
Movement Detection Technology	Optical
DPI Settings	800/1200/1600/2400/4000
Buttons	6 Programmable Buttons
Special Feature	Soundless (Silent Click), RGB Backlight, Removable Wrist Rest
Color	Black-Wired
Item Weight	5.6 ounces
Compatibility	Windows XP, Vista, 7, 8, 10, 11 (Limited support for Mac OS)

11. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or visit the official DeLUX website. The manufacturer of this product is DELUX.