



Manuals.plus /

› Satisfyer /

› Satisfyer Glorious Duo Cock Ring User Manual - Model 4009919

## Satisfyer 4009919

# Satisfyer Glorious Duo Cock Ring User Manual

Model: 4009919

## INTRODUCTION

This manual provides instructions for the safe and effective use of your Satisfyer Glorious Duo Cock Ring. Please read all instructions carefully before first use and retain this manual for future reference. This device is designed for adult use only.

## PRODUCT OVERVIEW AND FEATURES

The Satisfyer Glorious Duo is a vibrating ring designed for enhanced sensation and stamina. It features a dual-ring design and a vibrating tip.



Image: Satisfyer Glorious Duo with key features highlighted, including magnetic charging connection, control vibrations, voluminous clit stimulator, flexible body-friendly silicone, and greater stamina from restricted blood flow.

- **Enhanced Stamina:** The dual-ring design is intended to restrict blood flow when worn around the shaft and testicles, which may contribute to enhanced stamina.
- **Vibration Settings:** The device offers 12 distinct vibration settings for varied stimulation.
- **Partner Stimulation:** The vibrating tip is positioned to provide stimulation to the penis and can also be used to stimulate a partner's clitoris.
- **Body-Safe Material:** Constructed from body-safe silicone for comfort and ease of cleaning.
- **Waterproof Design:** The device is IPX7 waterproof, allowing for use in water up to 1 meter deep for 30 minutes. This also facilitates easy cleaning.

Your browser does not support the video tag.

Video: An overview of the Satisfyer Glorious Duo's features and design.

## SETUP

### Charging the Device

Before first use, fully charge the Satisfyer Glorious Duo. Connect the magnetic USB charging cable to the charging points on the device and plug the USB end into a compatible USB power source (e.g., computer, USB

wall adapter). The charging indicator will illuminate during charging and change when fully charged. A full charge typically takes approximately 2 hours.



Image: The magnetic USB charging cable included with the Satisfyer Glorious Duo.

## Initial Cleaning

Clean the device thoroughly before its first use. Refer to the 'Maintenance and Care' section for detailed cleaning instructions.

## OPERATING INSTRUCTIONS

### Power On/Off

To turn the device on, press and hold the power button (usually marked with a power symbol) for 2-3 seconds. To turn it off, press and hold the power button again for 2-3 seconds.

### Adjusting Vibration Modes

Once the device is on, short presses of the power button will cycle through the 12 available vibration settings. Experiment to find your preferred mode.

### Application

Gently stretch the larger ring and slide it over the penis shaft. Position the smaller ring around the testicles. Ensure a comfortable fit that is not too tight. The vibrating tip should be positioned for desired stimulation.

## MAINTENANCE AND CARE

### Cleaning

Clean the device after each use. Wash with warm water and a mild, toy-safe soap or a specialized toy cleaner. Rinse thoroughly and pat dry with a lint-free cloth. Do not use harsh chemicals, alcohol, or petroleum-based cleaners, as these can damage the silicone material. Since the device is IPX7 waterproof, it can be rinsed under running water.



Image: The Satisfyer Glorious Duo highlighting its IPX7 waterproof rating, indicating suitability for water exposure during cleaning.

### Storage

Store the device in a clean, dry place away from direct sunlight and extreme temperatures. Avoid storing it with other toys made of different materials to prevent potential material degradation.

## TROUBLESHOOTING

- **Device does not turn on:** Ensure the device is fully charged. If it still does not turn on, try connecting it to the charger to confirm the charging connection is secure.
- **Device does not charge:** Verify that the magnetic charging cable is correctly attached to the device's charging points and that the USB end is securely plugged into a working power source. Try a different USB port or adapter.
- **Vibrations are weak:** The battery may be low. Recharge the device.
- **Discomfort during use:** Ensure the device is applied correctly and is not too tight. Use a water-based lubricant for comfort. If discomfort persists, discontinue use.

If you experience issues not covered here, please contact customer support.

## SPECIFICATIONS

<b>Model Name</b>	Satisfyer Glorious Duo
<b>Item Model Number</b>	4009919
<b>Material</b>	Silicone
<b>Color</b>	Blue
<b>Product Dimensions</b>	1.14 x 2.05 x 4.13 inches
<b>Weight</b>	2.15 ounces
<b>Batteries</b>	1 Lithium Ion battery (included)
<b>Waterproof Rating</b>	IPX7

## WARRANTY AND SUPPORT

The Satisfyer Glorious Duo comes with a 15-year product protection guarantee. For warranty claims, technical support, or any questions regarding your device, please contact Satisfyer customer service through their official website or the retailer where the product was purchased. Please retain your proof of purchase for warranty purposes.



Image: Logo indicating 15-year product protection.