

[Manuals.plus](#) /

> [CHACEEF](#) /

> CHACEEF Travel Electric Kettle - Model 0911A User Manual

CHACEEF 0911A

CHACEEF Travel Electric Kettle - Model 0911A User Manual

Brand: CHACEEF | Model: 0911A

INTRODUCTION

The CHACEEF Travel Electric Kettle, Model 0911A, is a compact and portable water heating device designed for convenience on the go. With a 350ml capacity and 304 stainless steel interior, it offers multiple temperature settings, a keep-warm function, and an intuitive LED indicator for water temperature visualization. Its double-wall design ensures safe handling and efficient insulation.

SAFETY INSTRUCTIONS

- Read all instructions before use.
- Do not immerse the kettle base or power cord in water or other liquids.
- Ensure the power outlet voltage matches the kettle's specifications (100-240V).
- Always turn off the power and unplug the kettle before cleaning or when not in use.
- Exercise caution when handling hot water. Do not open the lid immediately after boiling water due to steam pressure. Allow it to stand for 5 minutes before opening.
- Keep out of reach of children.
- Do not operate the kettle if the power cord or plug is damaged.
- Only fill water up to the MAX line indicated inside the kettle. If boiling with the lid on, fill only up to two-thirds of the capacity to prevent overflow.

PRODUCT OVERVIEW

The CHACEEF Travel Electric Kettle is designed for ease of use and portability. Key components and features include:

- **304 Stainless Steel Inner Liner:** Ensures food-grade safety and prevents plastic contamination.
- **Double-Wall Structure:** Provides insulation to keep the exterior cool to the touch and reduce boiling noise.

- **Leakage Proof Lid:** Features a sealing ring to prevent spills, even when inverted.
- **Vent Hole:** Located on the lid to safely release steam pressure during operation.
- **LED Indicator:** A vertical light strip that changes color to indicate water temperature.
- **Touch Button Control:** For powering on/off and selecting temperature modes.
- **Detachable Power Plug:** For easy storage and portability.
- **Silicone Pad:** On the base for stability.



Exploded view of the CHACEEF Travel Electric Kettle, highlighting its internal components and features such as the vent hole, leakage-proof lid, double-wall structure, customized thermostat, and touch button.

SETUP

1. **Initial Cleaning:** Before first use, wash the interior of the kettle with warm water and a mild detergent. Rinse thoroughly.
2. **Fill Water:** Open the lid and fill the kettle with water. Observe the MAX fill line inside. If boiling with the lid on, do not exceed two-thirds of the capacity.
3. **Secure Lid:** Ensure the lid is securely fastened to prevent leakage.
4. **Connect Power:** Plug the detachable power cord into the kettle's port and then into a compatible

electrical outlet.

Functional Preset for 4 Different Temperatures

113°F



KEEP WARM

176°F



TEA

195°F



COFFEE

203°F



BOIL WATER



Filling the CHACEEF Travel Electric Kettle with water. Ensure not to exceed the MAX fill line, especially if boiling with the lid on.

OPERATING INSTRUCTIONS

The kettle offers multiple modes for heating water to your desired temperature.

1. **Power On:** Once plugged in, the kettle will display the current water temperature.
2. **Select Temperature Mode:** Press the power button (ON/OFF) to cycle through the available modes:
 - **Boil Water:** Heats water to 212°F (Red LED).
 - **Coffee Mode:** Heats water to 195°F (Red LED).
 - **Tea Mode:** Heats water to 176°F (Orange LED).
 - **Keep Warm:** Maintains water temperature at approximately 113°F (Blue LED).
3. **Start Heating:** After selecting your desired mode, the kettle will automatically begin heating. The LED indicator will change color according to the temperature range.
4. **Automatic Shut-Off & Keep Warm:** Once the water reaches the selected temperature, the kettle will automatically shut off the heating element and, in some modes, switch to the Keep Warm function.

Water Temperature Visualization

The color of the light strip changes with temperature



Water Temperature Visualization: The LED light strip changes color to indicate the water temperature inside the kettle.

Food Grade Stainless Steel Material

No plastic touch the water inside



Functional Presets for 4 Different Temperatures: Select from Keep Warm, Tea, Coffee, or Boil Water modes. Always allow 5 minutes after boiling before opening the lid.

This video demonstrates the dual voltage capability of a similar portable kettle, highlighting its suitability for both local and international travel. It shows the kettle's components, temperature settings, boiling process, and leak-proof design.

MAINTENANCE & CLEANING

Proper maintenance ensures the longevity and hygiene of your kettle.

- **Hand Wash Only:** The kettle is not dishwasher safe. Hand wash the interior with warm, soapy water.
- **Exterior Cleaning:** Wipe the exterior with a damp cloth. Do not use abrasive cleaners or immerse the base in water.
- **Descaling:** Over time, mineral deposits may accumulate. To descale, fill the kettle with a mixture of water and white vinegar (or a commercial descaling solution) and let it sit for a few hours or boil the mixture. Rinse thoroughly afterward.

Portable Travel Kettle



Suitcase



Handbag

The compact size of the CHACEEF Travel Electric Kettle makes it ideal for travel and easy to clean.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Kettle does not heat.	Not properly plugged in; power outage; incorrect mode selected.	Check power connection; ensure outlet is functional; re-select heating mode.
Water not boiling to 212°F.	Incorrect temperature mode selected; mineral buildup.	Ensure 'Boil Water' mode is selected; descale the kettle.
Water leaks from the lid.	Lid not securely fastened; overfilled.	Ensure lid is tightly screwed on; do not overfill, especially when boiling with lid.
Unpleasant taste/odor in water.	New product odor; mineral buildup.	Perform several boiling cycles with fresh water; descale if necessary.



The kettle features a leak-proof design, ensuring no spills even when inverted.

This short video demonstrates the compact and portable nature of a travel electric kettle, showing it in various settings and highlighting its ease of use for quick hot water preparation.

SPECIFICATIONS

Feature	Detail
Brand	CHACEEF
Model Name	0911A
Capacity	350 Milliliters
Material	304 Stainless Steel
Color	White
Special Features	304 Stainless Steel Inner Liner, Automatic Shut-Off, Indicator Light, Programmable, Rapid Boil

Feature	Detail
Product Dimensions	2.9"L x 2.9"W x 8.8"H
Item Weight	1.5 Pounds
Cable Length	83 Centimeters

WARRANTY & SUPPORT

For warranty information or product support, please refer to the documentation included with your purchase or contact CHACEEF customer service. Keep your proof of purchase for any warranty claims.