

[Manuals.plus](#) /

› [Briloner](#) /

› Briloner 2-Light Ceiling Spot with Starlight Effect, Model 2078-024

Briloner 2078-024

Briloner 2-Light Ceiling Spot with Starlight Effect

Model: 2078-024

1. INTRODUCTION

Thank you for choosing the Briloner 2-Light Ceiling Spot with Starlight Effect. This product is designed to provide adjustable illumination and a unique aesthetic to your indoor spaces. Please read this manual carefully before installation and use to ensure safe and correct operation.



Image 1.1: Briloner 2-Light Ceiling Spot highlighting key features.

2. SAFETY INSTRUCTIONS

- **Electrical Safety:** Installation must be performed by a qualified electrician in accordance with local wiring regulations. Always switch off the main power supply before installation, maintenance, or bulb replacement.
- **Indoor Use Only:** This product has an IP20 rating, meaning it is protected against solid objects larger than 12.5mm but has no protection against water. It is designed exclusively for indoor use.
- **Bulb Compatibility:** Use only E27 bulbs with a maximum wattage of 25W per socket. Do not exceed the specified wattage.
- **Handling:** Do not touch the bulb immediately after use as it may be hot. Allow it to cool down before handling.
- **Cleaning:** Disconnect power before cleaning. Use a soft, dry cloth. Do not use abrasive cleaners or solvents.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- 1 x Briloner 2-Light Ceiling Spot (Model 2078-024)
- Mounting hardware (screws, wall plugs)
- Instruction Manual

Note: Light bulbs are not included and must be purchased separately.

4. SETUP AND INSTALLATION

Important: Ensure the main power supply is switched off at the circuit breaker before starting installation.

1. **Prepare Mounting Location:** Choose a suitable ceiling location for installation. Mark the drilling points for the mounting bracket.
2. **Mount the Bracket:** Drill holes at the marked points and insert the wall plugs. Secure the mounting bracket to the ceiling using the provided screws.
3. **Electrical Connection:** Connect the household electrical wires to the terminal block on the light fixture. Ensure correct polarity (Live, Neutral, Earth) as per local regulations. Double-check all connections for security.
4. **Attach the Fixture:** Carefully attach the light fixture to the mounted bracket, securing it with the provided screws or fasteners.
5. **Install Bulbs:** Screw two E27 bulbs (max. 25W each, not included) into the lamp holders.




Image 4.1: Product dimensions for installation planning.




Image 4.2: Detail of the E27 bulb socket.

5. OPERATING INSTRUCTIONS

Once installed and power is restored, the Briloner Ceiling Spot is ready for use.

- **Power On/Off:** Operate the light using your standard wall switch.
- **Adjusting Light Direction:** The two spot heads are rotatable and pivotable. Gently adjust each spot head to direct the light precisely where needed.



Schirm dreh- und schwenkbar
Lampshade rotatable and pivotable

Image 5.1: Demonstrating the adjustable lampshade.

6. MAINTENANCE

- **Cleaning:** To clean the fixture, ensure the power is off. Use a soft, dry, lint-free cloth. Do not use liquid or abrasive cleaners.
- **Bulb Replacement:** Before replacing a bulb, switch off the power supply and allow the bulb to cool completely. Unscrew the old bulb and screw in a new E27 bulb (max. 25W).

7. TROUBLESHOOTING

- **Light Does Not Turn On:**
 - Check if the main power supply is switched on.
 - Ensure the wall switch is in the 'ON' position.
 - Verify that the bulbs are correctly installed and not faulty. Try replacing them with known working bulbs.

- If the issue persists, consult a qualified electrician to check the wiring connections.

- **Flickering Light:**

- Ensure bulbs are screwed in tightly.
- Check for loose wiring connections (consult an electrician).

- **Circuit Breaker Trips:**

- Immediately switch off the power. This indicates a serious electrical fault.
- Do not attempt to fix this yourself. Contact a qualified electrician immediately for inspection and repair.

8. SPECIFICATIONS

Brand	Briloner
Model Number	2078-024
Dimensions (L x W x H)	28.5 x 13 x 15.5 cm
Weight	570 g
Material	Metal
Color	Grey/Black
Number of Bulbs	2
Cap Type	E27
Max. Wattage per Bulb	25 Watts
Voltage	240 Volts (AC)
IP Rating	IP20
Installation Type	Ceiling Mount
Special Features	Energy-saving, Rotatable/Pivotable Heads, Starlight Effect

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided at the point of purchase or contact your retailer. Keep your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B09KGCB362>

More documents and user manuals: <https://manuals.plus/>